


# FUEL AND EMISSION CONTROL SYSTEM (NON-TURBO)


<b>OUTLINE</b> .....	4A- 2	TROUBLESHOOTING .....	4A-52
SYSTEM DIAGRAM.....	4A- 2	REPLACEMENT .....	4A-54
COMPONENT LOCATION.....	4A- 3	FUEL TANK .....	4A-58
VACUUM HOSE ROUTING DIAGRAM.....	4A- 6	<b>DECELERATION CONTROL</b>	
SPECIFICATIONS .....	4A- 7	<b>SYSTEM</b> .....	4A-61
<b>TROUBLESHOOTING GUIDE</b> .....	4A- 8	COMPONENT DESCRIPTIONS.....	4A-62
TROUBLESHOOTING PROCEDURE .....	4A- 8	TROUBLESHOOTING.....	4A-62
<b>TROUBLESHOOTING WITH SST</b> ....	4A-10	<b>EXHAUST GAS RECIRCULATION</b>	
INSPECTION PROCEDURE .....	4A-11	<b>(EGR) SYSTEM</b> .....	4A-64
AFTER-REPAIR PROCEDURE .....	4A-11	COMPONENT DESCRIPTIONS.....	4A-64
PRINCIPLE OF CODE CYCLE .....	4A-13	TROUBLESHOOTING .....	4A-65
CODE NUMBER.....	4A-14	<b>EVAPORATIVE EMISSION CONTROL</b>	
<b>SWITCH MONITOR FUNCTION</b> .....	4A-25	<b>(EEC) SYSTEM</b> .....	4A-67
INSPECTION PROCEDURE .....	4A-26	COMPONENT DESCRIPTIONS.....	4A-67
<b>IDLE ADJUSTMENT</b> .....	4A-29	TROUBLESHOOTING.....	4A-68
IDLE SPEED.....	4A-29	<b>POSITIVE CRANKCASE</b>	
IDLE MIXTURE .....	4A-29	<b>VENTILATION (PCV) SYSTEM</b> ....	4A-72
<b>INTAKE AIR SYSTEM</b> .....	4A-30	COMPONENT DESCRIPTION .....	4A-72
COMPONENT DESCRIPTIONS.....	4A-30	PCV VALVE .....	4A-72
REMOVAL .....	4A-31	<b>EXHAUST SYSTEM</b> .....	4A-73
PARTS INSPECTION .....	4A-32	REMOVAL AND INSTALLATION ...	4A-74
REPLACEMENT .....	4A-33	INSPECTION .....	4A-74
INSTALLATION .....	4A-34	<b>CONTROL SYSTEM</b> .....	4A-75
<b>IDLE SPEED CONTROL (ISC)</b>		RELATIONSHIP CHART .....	4A-76
<b>SYSTEM</b> .....	4A-36	EGI MAIN FUSE.....	4A-78
COMPONENT DESCRIPTIONS.....	4A-37	MAIN RELAY .....	4A-78
TROUBLESHOOTING.....	4A-38	CIRCUIT OPENING RELAY .....	4A-78
<b>FUEL SYSTEM</b> .....	4A-41	ENGINE CONTROL UNIT .....	4A-79
COMPONENT DESCRIPTIONS.....	4A-42	NEUTRAL SWITCH .....	4A-86
TROUBLESHOOTING .....	4A-43	CLUTCH SWITCH.....	4A-86
FUEL PRESSURE RELEASE AND SERVICING FUEL SYSTEM .....	4A-44	BRAKE LIGHT SWITCH .....	4A-86
MULTI-PRESSURE TESTER.....	4A-45	P/S PRESSURE SWITCH.....	4A-87
FUEL PRESSURE .....	4A-46	INHIBITOR SWITCH .....	4A-87
FUEL PUMP .....	4A-47	E/L CONTROL UNIT .....	4A-88
PULSATION DAMPER .....	4A-48	AIR FLOW METER.....	4A-89
INJECTOR.....	4A-48	THROTTLE SENSOR .....	4A-90
PRESSURE REGULATOR CONTROL SYSTEM.....	4A-51	IDLE SWITCH .....	4A-92
COMPONENT DESCRIPTIONS.....	4A-52	WATER THERMO SENSOR .....	4A-92
		WATER THERMO SWITCH.....	4A-93
		OXYGEN SENSOR.....	4A-93
		ATMOSPHERIC PRESSURE SENSOR .....	4A-94

## OUTLINE

### SYSTEM DIAGRAM




COMPONENT LOCATION  
Input Devices




# 4A OUTLINE

## Fuel and Output Devices




Exhaust System



# 4A OUTLINE

## VACUUM HOSE ROUTING DIAGRAM



## SPECIFICATIONS

Item		Engine type	Non-Turbo Engine				
Idle speed		rpm	750 ± 25 (ATX: P range)*				
<b>Throttle body</b>							
Type		Horizontal draft (2-barrel)					
Throat diameter	mm (in)	No. 1	MTX: 40 (1.6), ATX: 46 (1.8)				
		No. 2	MTX: 46 (1.8), ATX: 40 (1.6)				
<b>Air flow meter</b>							
Resistor	Ω	E2—Vs	Fully closed: 20—400 Fully open: 20—1,000				
		E2—Vc	100—400				
		E2—Vb	200—400				
		E2—THA	<table style="width: 100%; border: none;"> <tr> <td style="width: 50%;">-20°C (-4°F)</td> <td style="width: 50%;">13,600—18,400</td> </tr> <tr> <td>20°C (68°F)</td> <td>2,210— 2,690</td> </tr> <tr> <td>60°C (140°F)</td> <td>493— 667</td> </tr> </table>	-20°C (-4°F)	13,600—18,400	20°C (68°F)	2,210— 2,690
-20°C (-4°F)	13,600—18,400						
20°C (68°F)	2,210— 2,690						
60°C (140°F)	493— 667						
<b>Fuel pump</b>							
Type		Impeller (in tank)					
Output pressure	kPa (kg/cm <sup>2</sup> , psi)	441—588 (4.5—6.0, 64—85)					
Feeding capacity	cc (cu in)/10 sec.	220 (13.4) min					
<b>Fuel filter</b>							
Type	Low pressure side		Nylon element				
	High pressure side		Paper element				
<b>Pressure regulator</b>							
Type		Diaphragm					
Regulating pressure	kPa (kg/cm <sup>2</sup> , psi)	235—275 (2.4—2.8, 34—40)					
<b>Injector</b>							
Type		High-ohmic					
Type of drive		Voltage					
Resistance	Ω	12—16					
Injection amount	cc (cu in)/15 seconds	44—61 (2.68—3.72)					
<b>Idle speed control valve</b>							
Solenoid resistance	Ω	6.3—9.9					
<b>Fuel tank</b>							
Capacity	liters (US gal, Imp gal)	60 (15.9, 13.2)					
<b>Air cleaner</b>							
Element type		Oil permeated					
<b>Fuel</b>							
Specification		Unleaded regular					

\* With test connector grounded

86U04A-007

# 4A TROUBLESHOOTING GUIDE

## TROUBLESHOOTING GUIDE

This troubleshooting guide shows the malfunction numbers and the symptoms of various failures. Perform troubleshooting as described below.

Possible cause	Input sensors and switches								Output solenoid valves																									
	Ignition pulse	Air flow meter	Water thermo sensor	Intake air thermo sensor	Throttle sensor	Atmospheric pressure sensor	Oxygen sensor	Feedback system	Solenoid valve (Pressure regulator)	Solenoid valve (Purge)	Solenoid valve (EGR)	Solenoid valve (Idle speed control)																						
Symptom	4A-15	4A-16	4A-17	4A-18	4A-19	4A-20	4A-21	4A-22	4A-23	4A-23	4A-24	4A-24																						
1 Fault Indicated by SST Code No.	01	08	09	10	12	14	15	17	25	26	28	34																						
2 Hard start or won't start (Crank OK)	<h3>TROUBLESHOOTING PROCEDURE</h3> <p><b>Note</b>  <b>Step 1</b> under symptom is to quickly determine what system or unit may be at fault by use of the SST. (Self-Diagnosis Checker 49 H018 9A1)</p> <p><b>1st:</b> Check input sensors and output solenoid valves with the SST. (Refer to page 4A-11.)</p> <p><b>2nd:</b> Check other switches with the SST. (Refer to page 4A-26.)</p> <p><b>3rd:</b> Check the following items:</p> <table border="0"> <tr> <td><b>Electrical system</b></td> <td><b>Ignition system</b></td> </tr> <tr> <td>1) Battery condition</td> <td>1) Ignition spark</td> </tr> <tr> <td>2) Fuses</td> <td>2) Ignition timing</td> </tr> <tr> <td><b>Fuel system</b></td> <td><b>Intake air system</b></td> </tr> <tr> <td>1) Fuel level</td> <td>1) Air cleaner element</td> </tr> <tr> <td>2) Fuel leakage</td> <td>2) Vacuum or air leakage</td> </tr> <tr> <td>3) Fuel filter</td> <td>2) Vacuum hose routing</td> </tr> <tr> <td>4) Idle speed (with test connector grounded)</td> <td>4) Accelerator cable</td> </tr> <tr> <td><b>Engine</b></td> <td><b>Others</b></td> </tr> <tr> <td>1) Compression</td> <td>1) Clutch slippage</td> </tr> <tr> <td>2) Overheating</td> <td>2) Brake dragging</td> </tr> </table> <p>4th: Check Fuel and Emission Control Systems. (Refer to page 4A-9.)</p>												<b>Electrical system</b>	<b>Ignition system</b>	1) Battery condition	1) Ignition spark	2) Fuses	2) Ignition timing	<b>Fuel system</b>	<b>Intake air system</b>	1) Fuel level	1) Air cleaner element	2) Fuel leakage	2) Vacuum or air leakage	3) Fuel filter	2) Vacuum hose routing	4) Idle speed (with test connector grounded)	4) Accelerator cable	<b>Engine</b>	<b>Others</b>	1) Compression	1) Clutch slippage	2) Overheating	2) Brake dragging
<b>Electrical system</b>													<b>Ignition system</b>																					
1) Battery condition													1) Ignition spark																					
2) Fuses													2) Ignition timing																					
<b>Fuel system</b>													<b>Intake air system</b>																					
1) Fuel level													1) Air cleaner element																					
2) Fuel leakage													2) Vacuum or air leakage																					
3) Fuel filter													2) Vacuum hose routing																					
4) Idle speed (with test connector grounded)													4) Accelerator cable																					
<b>Engine</b>													<b>Others</b>																					
1) Compression													1) Clutch slippage																					
2) Overheating	2) Brake dragging																																	
3 Engine stalls																																		
4 Rough idle																																		
5 High idle speed after warming up																																		
6 Poor acceleration, hesitation or lack of power																																		
7 Runs rough on deceleration																																		
8 Afterburn in exhaust system																																		
9 Poor fuel consumption																																		
10 Engine stalls or rough after hot starting																																		
11 Fails emission test																																		

86U04A-008



# TROUBLESHOOTING GUIDE 4A

The Troubleshooting Guide lists the systems most likely to cause a given symptom. After finding systems to check, refer to the pages shown for detailed guides for each system.

Fuel and Emission Control Systems										
Possible cause		Intake Air System (Poor connection of components, throttle body)	Fuel System (Fuel Injection, Fuel pressure)	Pressure Regulator Control System	Idle Speed Control (ISC) System (Air valve, Idle speed control solenoid malfunction)	EGR System (EGR control valve stuck and open)	EEC system (Vacuum switch valve, No.1 purge valve malfunction)	PCV System (System clogged)	Deceleration System (Fuel cut operation malfunction)	Exhaust system (System clogged)
Page		4A—32	4A—43	4A—52	4A—38	4A—65	4A—68	4A—72	4A—62	4A—74
Symptom	2	2	1							
	3	4	3		1	2				
		5	4		2	3		1		
	4	5	4		1	3		2		
		6	5		2	3	4	1		
	5	2			1					
	6	3	4			1	2			5
	7		3		2				1	
	8	3	4		1				2	
	9		2				3		1	4
	10		2	1						
11	6	7			4	2	5	3	1	


96U04A-002

The numbers of the list show the priorities of inspections from the most possible to that with the lowest possibility. These were determined on the following basis:

- Ease of inspection
- Most possible system
- Most possible point in system

# 4A TROUBLESHOOTING WITH SST

## TROUBLESHOOTING WITH SST



86U04A-010


When troubles occur in the main input devices or output devices, check for the cause using the **SST**. Failures of each input and output device are indicated and retrieved from the control unit as malfunction code numbers.

### Note

The control unit constantly checks for malfunction of the input devices. But, the control unit checks for malfunction of output devices only in a 3 second period after the ignition switch is turned ON and the test connector is grounded.

TROUBLESHOOTING WITH SST **4A**

Check connector: Green (6 pin)

**49 H018 9A1**

86U04A-011

**INSPECTION PROCEDURE**

1. Connect the **SST** to the check connector. (Green, 6-pin) and the negative battery terminal.
2. Set the select switch to position A.

**Note**


**The check connector is located at the rear of the left side wheel housing.**

3. Ground the test connector (Green, 1-pin) with a jumper wire.

**Note**

**The test connector is located near the Self-Diagnosis Checker check connector.**

Test connector: Green (1 pin)

**49 H018 9A1**

86U04A-012

4. Turn the ignition switch ON.
5. Verify that **88** flashes on the digital display and that the buzzer sounds for **three seconds** after turning the ignition switch ON.
6. If **88** does not flash, check the main relay (Refer to page 4A—78), power supply circuit, and check connector wiring.
7. If **88** flashes and the buzzer sounds continuously for more than **20 seconds**, replace the engine control unit and perform steps 3 and 4 again.
8. Note the code numbers and check for the causes by referring to the check sequences shown on pages **from 4A—15 to 4A—24**. Repair as necessary.

**Note**


**Cancel the code numbers by performing the after-repair procedure after repairing.**

**AFTER-REPAIR PROCEDURE**

1. Cancel the memory of malfunctions by disconnecting the negative battery cable and depressing the brake pedal for **at least five seconds**; then reconnect the negative battery cable.

2. Connect the **SST** to the check connector.

3. Ground the test connector (Green, 1-pin) with a jumper wire.

**49 H018 9A1**

Test connector: Green (1 pin)

86U04A-015

## 4A TROUBLESHOOTING WITH SST

**Ignition switch: ON  
for six seconds**

86U04A-016

4. Turn the ignition switch ON, but do not start the engine for **six seconds**.
5. Start and warm up the engine, then run it at **2,000 rpm** for **two** minutes.
6. Verify that no code numbers are displayed.


## PRINCIPLE OF CODE CYCLE

Malfunction codes are determined as shown below

86U04A-017

### 1. Code cycle break


The time between malfunction code cycles is 4.0 sec (the time the light is off).



86U04A-018

### 2. Second digit of malfunction code (ones position)

The digit in the ones position of the malfunction code represents the number of times the buzzer is on 0.4 sec during one cycle.




86U04A-019

### 3. First digit of warning code (tens position)

The digit in the tens position of the malfunction code represents the number of times the buzzer is on 1.2 sec during one cycle.













It should also be noted that the light goes off for 1.6 sec. between the long and short pulses of the buzzer.



69G04C-554

# 4A TROUBLESHOOTING WITH SST

## CODE NUMBER

Malfunction display		Sensor or subsystem	Self-diagnosis	Fail-safe
Code No.	MIL output signal pattern			
01	ON  OFF	Ignition pulse	No ignition signal	—
08	ON  OFF	Air flow meter	Open or short circuit	Maintains basic signal at preset value
09	ON  OFF	Water thermo sensor	Open or short circuit	Maintains constant command • 35°C (95°F) for EGI • 50°C (122°F) for ISC control use
10	ON  OFF	Intake air thermo sensor (air flow meter)	Open or short circuit	Maintains constant 20°C (68°F) command
12	ON  OFF	Throttle sensor	Open or short circuit	Maintains constant command of throttle valve fully open
14	ON  OFF	Atmospheric pressure sensor	Open or short circuit	Maintains constant command of sea level pressure
15	ON  OFF	Oxygen sensor	Sensor output continues less than 0.55V 120 sec. after engine starts (1,500 rpm)	Cancels EGI feedback operation
17	ON  OFF	Feedback system	Sensor output not changed 20 sec. after engine exceeds 1,500 rpm	Cancels EGI feedback operation
25	ON  OFF	Solenoid valve (pressure regulator)	Open or short circuit	—
26	ON  OFF	Solenoid valve (purge control)		—
28	ON  OFF	Solenoid valve (EGR)		—
34	ON  OFF	Solenoid valve (Idle speed control)		—

86U04A-020


### Caution

- If there is more than one failure present, the lowest number malfunction code is displayed first, the remaining codes are displayed sequentially.
- After repairing a failure, turn off the ignition switch and disconnect the negative battery cable and depress the brake pedal for at least 5 seconds to erase the memory of a malfunction code.

If a malfunction code number is shown on the **SST**, check the following chart along with the wiring diagram.

## Code No. 01 (Ignition pulse)

**PC: Possible Cause**




96U04A-004

# 4A TROUBLESHOOTING WITH SST

## Code No. 08 (Air flow meter)

PC: Possible Cause




96U04A.005



## Code No. 09 (Water thermo sensor)

**PC: Possible Cause**



96U04A-006

# 4A TROUBLESHOOTING WITH SST

## Code No. 10 (Intake air thermo sensor)

PC: Possible Cause

Are there poor connections in air flow meter circuit?

YES

Repair or replace connector

NO

Is there continuity between intake air thermo sensor (in air flow meter) and engine control unit?

Intake air temperature sensor (in air flow meter)	Control unit
THA (R wire)	2J
E2 (LG/Y wire)	2C

NO

PC: Open circuit in wiring harness from intake air thermo sensor (in air flow meter) to engine control unit

YES

Is resistance of intake air thermo sensor (in air flow meter) OK?  
Resistance:

Terminal	Resistance
E2 ↔ THA	-20°C (-4°F) : 13.6—18.4 kΩ
	20°C (68°F) : 2.21—2.69 kΩ
	60°C (140°F) : 493—667 Ω

NO

Replace air flow meter

YES

Is same Code No. present after performing after-repair procedure? (Refer to page 4A-11)

NO

Intake air thermo sensor and circuit OK

YES

Are engine control unit 2J and 2C terminal voltages OK? (Refer to page 4A-84)

NO

PC: Short circuit in wiring harness


YES

PC: Engine control unit malfunction

96U04A-007

## Code No. 12 (Throttle sensor)

**PC: Possible cause**




96U04A-008

# 4A TROUBLESHOOTING WITH SST

## Code No. 14 (Atmospheric pressure sensor)

PC: Possible cause




96U04A-009

## Code No. 15 (Oxygen sensor)

PC: Possible Cause

**Note**  
When Codes No.15 and 17 are present at the same time, first perform the checking procedure for Code No.17. (Refer to page 4A—22.)




96U04A-010

# 4A TROUBLESHOOTING WITH SST

## Code No. 17 (Feedback system)


PC: Possible Cause



96U04A-011


## Code No. 25 (Solenoid valve-Pressure regulator)

**PC: Possible Cause**



86U04A-029

## Code No. 26 (Solenoid valve-Purge)




86U04A-030

# 4A TROUBLESHOOTING WITH SST


## Code No. 28 (Solenoid valve—EGR)

PC: Possible Cause



86U04A-031

## Code No. 34 (Solenoid valve—Idle speed control valve (ISC))




96U04A-012



## SWITCH MONITOR FUNCTION

Individual switches can be monitored by the SST.


**Note**  
The test connector must be grounded and the ignition switch ON (engine stopped).




86U04A-033

Switch	Self-Diagnosis Checker (Monitor lamp)		Remarks
	Light ON	Light OFF	
Clutch switch	Pedal released	Pedal depressed	Gear: 1N
Neutral switch	In gear	Neutral	Clutch pedal released
Idle switch	Pedal depressed	Pedal released	—
Brake light switch	Pedal depressed	Pedal released	—
A/C switch	ON	OFF	Blower motor position: "1" position
Headlight switch	ON	OFF	—
Rear defroster switch	ON	OFF	—
Blower switch	ON	OFF	Blower motor position: "3" or "4" position
Inhibitor switch and EC-AT control unit	D, 1, 2 and R range	P and N range	—
Water thermo switch (Electrical fan)	Terminal disconnected	Terminal connected	While fan not operating

# 4A SWITCH MONITOR FUNCTION



86U04A-034



86U04A-035

## INSPECTION PROCEDURE


1. Warm up the engine to normal operating temperature and stop it.
2. Connect the **SST** to the check connector (Green, 6-pin) and the negative battery terminal.
3. Connect a jumper wire between the test connector (Green, 1-pin) and a ground.
4. Turn the ignition switch ON. Check if monitor lamp illuminates when each switch is made to function as described below.

### Caution

a) If any one of the switches is activated, the monitor lamp will stay on.


b) Do not start the engine.

## Procedure




96U04A-013

## Neutral and Clutch switch (MTX)




96U04A-014

## Idle switch




96U04A-015

## Brake light switch




96U04A-016

## Blower switch



96U04A-017


## A/C switch



96U04A-018


# 4A SWITCH MONITOR FUNCTION

## Headlight switch




96U04A-019

## Rear defroster switch



96U04A-020

## Inhibitor switch




96U04A-021

## Water thermo switch circuit (not included in switch inspection)

### Warning

The electrical fan operates when the connector is disconnected. Use caution.



96U04A-022

## IDLE ADJUSTMENT

### IDLE SPEED

Because the idle speed is controlled automatically by the engine control unit through the idle speed control (ISC) solenoid valve, usually it is not necessary to check and adjust the idle speed.

However, the idle speed should be adjusted when rough idling occurs when the test connector (Green, 1-pin) is grounded.

Idle speed  
Automatic  
Control  
Function

Engine Control Unit

86U04A-045

### Preparation

- 1) Check the condition of the engine (plugs, leaks in hoses, etc.).
- 2) Make sure all accessories are OFF.
- 3) Warm up the engine and run it for **Three minutes at 2,500—3,000 rpm** in neutral.
- 4) Check the initial ignition timing and adjust if necessary.

### Inspection and Adjustment

1. Ground the test connector with a jumper wire.

2. Check that the idle speed is within specification.

**Idle speed: 750 ± 25 rpm MTX: Neutral  
ATX: P range**

3. If the idle speed is not within specification, remove the blind cap from the throttle body and adjust it by turning the air adjust screw.
4. After adjusting the idle speed, install the blind cap and disconnect the jumper wire from the test connector.

### IDLE MIXTURE

Because an automatic compensation function for air/fuel mixture is built into the engine control unit, it is not necessary to check and adjust the idle mixture.


Idle mixture  
Automatic  
Control  
Function

Engine Control Unit

86U04A-049

# 4A INTAKE AIR SYSTEM

## INTAKE AIR SYSTEM



86U04A-051

This system controls the air required by the engine for operation. The system consists of the air duct, air cleaner, air flow meter, throttle body, dynamic chamber, and intake manifold.

This system also has a resonance chamber to improve mid-range torque characteristics.

### COMPONENT DESCRIPTIONS

Component	Function	Remarks	Application	
			New model	Previous model
<b>Air cleaner</b>	Filters air into throttle body		○	○
<b>Air flow meter</b>	Detects amount of intake air; sends signal to control unit	Intake air temp sensor and fuel pump switch are integrated	○	○
<b>Throttle sensor</b>	Detects throttle valve opening angle; sends signal to control unit	Installed on throttle body	○	○
<b>Throttle body</b>	Controls intake air quantity	Integrated throttle sensor and idle switch	○	○


86U04A-051

## REMOVAL

### Caution

Before removing the following parts, release the fuel pressure from fuel system to reduce the possibility of injury or fire. (Refer to page 4A-44.)


Remove in the sequence shown in the figure.



96U04A-023

- |                             |                          |                             |
|-----------------------------|--------------------------|-----------------------------|
| 1. Air flow meter connector | 9. Water hoses           | 17. Wiring harness          |
| 2. Air cleaner              | 10. Vacuum hoses         | 18. Delivery pipe assembly  |
| 3. Air duct                 | 11. Accelerator cable    | 19. Vacuum hoses            |
| 4. Resonance chamber No.1   | 12. Throttle body        | 20. EGR pipe                |
| 5. Air flow meter           | 13. PCV hose             | 21. Intake manifold bracket |
| 6. Resonance chamber No.2   | 14. Vacuum pipe assembly | 22. Intake manifold         |
| 7. Air hose                 | 15. Dynamic chamber      | 23. Gasket                  |
| 8. Connectors               | 16. Gasket               |                             |

# 4A INTAKE AIR SYSTEM



69G04A-059


## PARTS INSPECTION

### Air Cleaner Element

1. Check the condition of the air cleaner element.
2. Replace, if necessary.

### Caution


**Do not use the compressed air to clean the air cleaner element.**



86U04A-053

### Accelerator Cable

1. Inspect the deflection of the cable. If the deflection is not within **1—3 mm (0.04—0.12 in.)**, adjust by turning nuts A.
2. Depress the accelerator pedal to the floor and confirm that the throttle valve is fully opened. Adjust by turning bolt B if necessary.



86U04A-054

### Throttle Body


### Note

**The No. 2 throttle valve is preset at the factory to begin opening after the No. 1 throttle valve has opened approx. 25 degrees (MTX) or 10 degrees (ATX).**

1. Check that the No. 1 and No. 2 throttle valves move smoothly when the throttle lever is moved from fully closed to fully open.
2. Replace, if necessary.

### Caution


**Do not remove the thin sealing coating from the throttle valve or bore.**



69G04C-050


### Dynamic Chamber

1. Visually check the dynamic chamber for damage.
2. Replace, if necessary.



69G04A-062






69G04A-064

### Intake Manifold

1. Visually check the intake manifold for damage.
2. Replace, if necessary.



69G04C-054

### Resonance Chamber

1. Visually check the resonance chamber for damage.
2. Replace, if necessary.


## REPLACEMENT

### Throttle Lever Removal

#### Caution

**When loosening the throttle lever nut, hold the throttle valves fully open to prevent damaging the idle switch.**

Remove the throttle lever in the sequence shown in the figure.



69G04C-130

### Installation

1. Check that the inner washer is in the proper position as shown in the figure.
2. Assemble the spacer and outer washer and install them onto the throttle shaft.
3. Install the throttle lever onto the throttle shaft.

#### Caution


**When tightening the throttle lever nut, hold the throttle valves fully closed to prevent bending the stopper lever.**

4. Tighten the throttle lever nut.


#### Tightening torque:

**16—23 Nm (1.6—2.3 m·kg, 12—17 ft·lb)**

5. Check that the inner and outer washer and spacer are assembled correctly as shown.
6. Check that No.1 and No.2 throttle valves move smoothly and that No.2 throttle valve is closed completely when the No.1 throttle valve is closed.
7. Check the operation of the idle switch. (Refer to page 4A—92)



69G04C-131




96U04A-024


# 4A INTAKE AIR SYSTEM

## INSTALLATION


Install in the reverse order of removal, referring to the installation note.

## Torque Specification






86U04A-056



96U04A-025



96U04A-026

## Installation Note

### Water hose spring clamps

Face the clamp end as shown in the figure.

### Gasket

Use new gaskets at the intake manifold, dynamic chamber, and throttle body.

### Air flow meter

1. Mount the gasket onto the air cleaner housing, being sure that the holes (B) are fit over pins (A).
2. Make sure the top pointer of the gasket faces upward.

3. Install the air flow meter.

### Torque specification:



**8—11 N·m (0.8—1.1 m·kg, 5.8—8.0 ft·lb)**

### Caution

If nuts are tightened below specified torque, the nuts loosen and the loose of nuts may cause damage to the engine.

# 4A ISC SYSTEM

## IDLE SPEED CONTROL (ISC) SYSTEM



86U04A-057

To improve idle smoothness, the ISC system controls the intake air amount by regulating the bypass air amount that passes through the throttle body.

This system consists of the BAC valve and the control system.

The BAC valve consists of the air valve which functions only during cold engine conditions (**below 50°C (122°F)**) and the ISC valve which works throughout the entire engine speed range.

## COMPONENT DESCRIPTIONS

Component	Function	Remarks	Application	
			New model	Previous model
<b>Air valve</b>	When cold, supplies bypass air into dynamic chamber	<ul style="list-style-type: none"> <li>• Engine speed increased to shorten warm-up period</li> <li>• Thermo wax type</li> <li>• Installed in BAC valve</li> </ul>	○	○
<b>Clutch switch</b>	Detects in-gear condition; sends signal to control unit	Switch ON when clutch pedal released	○	○
<b>E/L control unit</b>	Detects that E/L is being applied; sends signal to control unit		○	X
<b>Engine control unit</b>	Detects signals from input sensors and switches; controls solenoid valve (Idle speed control)		○	○
<b>Idle switch</b>	Detects when throttle valve fully closed; sends signal to control unit	Installed on throttle body	○	○
<b>Ignition coil (-) terminal</b>	Detects engine speed; sends signal to control unit		○	○
<b>Inhibitor switch</b>	Detects in-gear condition; sends signal to EC-AT control unit	Switch ON in "N" or "P" range	○	○
<b>Neutral switch</b>	Detects in-gear condition; sends signal to control unit	Switch ON when in-gear	○	○
<b>P/S pressure switch</b>	Detects P/S operation; sends signal to control unit	P/S: ON when steering wheel turned right or left	○	○
<b>Solenoid valve (Idle speed control)</b>	Controls bypass air amount	<ul style="list-style-type: none"> <li>• Controlled by duty signal from control unit</li> <li>• With integrated air valve</li> <li>• Works idle-up</li> </ul>	○	X
<b>Test connector</b>	For Self-Diagnosis Checker and idle speed adjustment	1-pin connector (Green)	○	X
<b>Throttle sensor</b>	Detects throttle valve opening angle; sends signal to control unit	Installed on throttle body	○	○

86U04A-058

# 4A ISC SYSTEM

## TROUBLESHOOTING


Check the condition of the wiring harness and connectors before checking the sensors or switch.

**Note**


Make the system inspection first. If no problem is found, continue with the next system inspection of the Troubleshooting Guide. (Refer to pages 4A—8 and 9.)

Possible cause Page		Air valve	P/S pressure switch	Solenoid valve (Idle speed control)	Electrical load control unit	Engine control unit terminal			System inspection
						1K	1W	2Q	
Symptom		4A—39	4A—87	4A—39	4A—88	4A—83	4A—84	4A—85	4A—39
Engine stalls	While warming up	4		1			2	3	
	After warming up		2	1	3	5	4	6	
Rough idle	While warming up	5		2			3	4	1
	After warming up		3	2	4	6	5	7	1
High idle speed after warming up		8	3	2	4	6	5	7	1
Runs rough on deceleration				2			3	4	1
Afterburn in exhaust system		5		2			3	4	1
Fails emission test		5		2			3	4	1


96U04A-027




86U04A-060




86U04A-061



86U04A-062



86U04A-063



86U04A-064

## System Inspection (Air valve)

1. Disconnect the ISC valve connector when the engine is cold and idling.
2. Note the engine speed and reconnect the connector.
3. Warm up the engine to the normal operating temperature and disconnect the connector again.
4. Check that the engine speed is lower when the connector is disconnected warm than when disconnected when it is cold.

## (ISC valve)

5. Connect the ISC valve connector.

### Note

**Make sure that the test connector is not grounded and that the idle speed is set to specification.**

6. Again disconnect the ISC valve connector with the engine is at normal operating temperature.
7. Check that the engine speed decreases.
8. Reconnect the ISC valve connector.

## BAC Valve Air valve

1. Remove the BAC valve from the throttle body.
2. Blow air through the valve from port A and check that air comes out of port B when the BAC valve is cold.
3. If not correct, replace the BAC valve.

### Note

**Refer to "Installation" on this page for the BAC valve installation.**


## ISC valve

1. Disconnect the ISC valve connector.
2. Connect an ohmmeter to the terminals of the ISC valve.
3. Check the resistance.

**Resistance (normal operating temperature):  
6.3—9.9  $\Omega$**

4. If not correct, replace the BAC valve.

## 4A ISC SYSTEM



69G04C-070

### Removal


1. Remove the screws.
2. Remove the BAC valve from the throttle body.

### Installation

#### Caution

**Use a new gasket.**


1. Remove any dirt or old sealant from the contact surfaces.
2. Apply sealant to both sides of the gasket.
3. Tighten the screws.



69G04C-071



## FUEL SYSTEM



86U04A-065

This system supplies the fuel necessary for combustion at a constant pressure to the injectors. Fuel is metered and injected into the intake manifold according to the injection control signals from the engine control unit. It consists of the fuel pump, fuel filters, delivery pipe, pulsation damper, pressure regulator, injectors, fuel pump switch (incorporated in the air flow meter), and the circuit opening relay. The fuel pump is mounted in the fuel tank to minimize the operating noise of the fuel pump. The injectors are directly supplied with battery voltage through the main relay. The connector of the injectors is blue to distinguish the injectors for the non-turbocharged engine from those of the turbocharged engine.

# 4A FUEL SYSTEM

## COMPONENT DESCRIPTIONS

Component	Function	Remarks	Application	
			New model	Previous model
<b>Air flow meter</b>	Detects amount of intake air; sends signal to control unit	Intake air temp sensor and fuel pump switch are integrated	○	○
<b>Atmospheric pressure sensor</b>	Detects atmospheric pressure; sends signal to control unit		○	○
<b>Circuit opening relay</b>	Voltage for fuel pump while engine running		○	○
<b>Clutch switch</b>	Detects in-gear condition; sends signal to control unit	Switch ON when clutch pedal released	○	○
<b>EC-AT control unit</b>	Detects N or P range; sends signal to control unit		○	X
<b>Engine control unit</b>	Detects signals from input sensors and switches; controls injector operation		○	○
<b>Fuel filter</b>	Filters particles from fuel		○	○
<b>Fuel pump</b>	Provides fuel to injectors	<ul style="list-style-type: none"> <li>Operates while engine running</li> <li>Installed in fuel tank</li> </ul>	○	○
<b>Idle switch</b>	Detects when throttle valve fully closed; sends signal to control unit	Installed on throttle body	○	○
<b>Ignition coil (-) terminal</b>	Detects engine speed; sends signal to control unit		○	○
<b>Ignition switch (ST position)</b>	Sends engine cranking signal to control unit		○	○
<b>Inhibitor switch</b>	Detects in-gear condition; sends signal to EC-AT control unit	Switch ON in "N" or "P" range	○	○
<b>Injector</b>	Injects fuel into intake port	<ul style="list-style-type: none"> <li>Controlled by signals from control unit</li> <li>High-ohmic injector</li> </ul>	○	○
<b>Intake air thermo sensor</b>	Detects intake air temperature; sends signal to control unit	Installed in air flow meter	○	○
<b>Main relay</b>	Supplies electric current to injectors and control unit		○	○
<b>Neutral switch</b>	Detects in-gear condition; sends signal to control unit	Switch ON when in-gear	○	○
<b>Oxygen sensor</b>	Detects Oxygen concentration; sends signal to control unit	Zirconia ceramic and platinum coating	○	○
<b>Pressure regulator</b>	Adjusts fuel pressure supplied to injectors		○	○
<b>Pulsation damper</b>	Absorbs fuel pulsation		○	○
<b>Speedometer</b>	Detects vehicle speed; sends signal to control unit	ON: Above 113 mph (180 km/h)	○	X
<b>Throttle sensor</b>	Detects throttle valve opening angle; sends signal to control unit	Installed on throttle body	○	○
<b>Water thermo sensor</b>	Detects coolant temperature; sends signal to control unit		○	○
<b>Water thermo switch</b>	Detects radiator coolant temperature; sends signal to control unit	ON: above 17°C (63°F)	○	○

86U04A-086



## TROUBLESHOOTING

Check the condition of the wiring harness and connectors before checking the sensors or switches.

Possible cause		Air flow meter	Atmospheric pressure sensor	Oxygen sensor	Throttle sensor	Water thermo sensor	Water thermo switch	Fuel pump	Injector	Fuel pressure	Engine control unit terminal	
											3C	3E
Page		4A-89	4A-94	4A-93	4A-90	4A-92	4A-93	4A-47	4A-48	4A-46	4A-85	4A-85
Symptom		4A-89	4A-94	4A-93	4A-90	4A-92	4A-93	4A-47	4A-48	4A-46	4A-85	4A-85
Hard start or won't start (Crank OK)			5			4		1	3			2
Engine stalls	While warming up	4				3			2	1	5	
	After warming up	1							3	2	4	
Rough idle	While warming up	4				3			2	1		
	After warming up	1	2						4	3		
Poor acceleration, hesitation, or lack of power		1			3				4	2		
Runs rough on deceleration		1							2			
Afterburn on deceleration		1							2			
Poor fuel consumption		5	6	4		3			2	1		
Fails emission test				1			2					
Engine stalls or rough after hot starting		1							3	2		

96U04A-028

# 4A FUEL SYSTEM




## FUEL PRESSURE RELEASE AND SERVICING FUEL SYSTEM

Fuel in the fuel system remains under high pressure even when the engine is not running.


- a) Before disconnecting any fuel line, release the fuel pressure from the fuel system to reduce the possibility of injury or fire.
  1. Start the engine.
  2. Disconnect the circuit opening relay.
  3. After the engine stalls, turn OFF the ignition switch.
  4. Reconnect the circuit opening relay.
- b) Use a rag as protection from fuel spray when disconnecting the hoses.

Plug the hoses after removal.
- c) When inspecting the fuel system, use the **SST**.

**MULTI-PRESSURE TESTER (49 9200 750A)**



**49 9200 750A**




**49 9200 750A**


69G04A-099

The **MULTI-PRESSURE TESTER (49 9200 750A)** has been developed to check the fuel pressure and intake manifold vacuum. These can easily be inspected by setting the buttons on the tester.


# 4A FUEL SYSTEM




96U04A-029




96U04A-058



86U04A-072



96U04A-030



86U04A-074

## How to Connect Multi-Pressure Tester

### Warning

**Before connecting the SST, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page 4A-44.)**

1. Disconnect the negative battery terminal.
2. Disconnect the fuel main hose from the fuel filter.
3. Connect the **SST** between the fuel main hose and fuel filter with the adapter.

### Caution

**Do not reverse the adapter connection.**

4. Disconnect the vacuum hose from the pressure regulator and connect the **SST** vacuum hose with a three-way joint.
5. Connect the negative battery terminal.
6. Connect the **SST** to the battery.

7. Connect the terminals of the test connector (Yellow) with a jumper wire. Turn the ignition switch ON to operate the fuel pump.
8. Check for fuel leaks.

### Caution

**After checking for fuel leakage, turn the ignition switch OFF and disconnect the jumper wire from the test connector.**

## FUEL PRESSURE

### Note

**a) When inspecting fuel pressure, use the SST.**  
(Refer to page 4A-46).

**b) Warm up the engine to normal operating temperature.**


### Injection Pressure

1. Set the lever on the adapter as shown in the figure.
2. Run the engine and measure the injection pressure at various speeds.


### Injection pressure:

**Approx. 235—275 kPa (2.4—2.8 kg/cm<sup>2</sup>, 34—40 psi)**


3. If not within specification, check the fuel pump pressure and fuel line pressure.




86U04A-075




96U04A-031



86U04A-077



86U04A-078



86U04A-079

## Fuel Pump Pressure

1. Connect the terminals of the test connector (Yellow) with a jumper wire.
2. Turn the ignition switch ON to operate the fuel pump.
3. Set the lever on the adapter as shown in the figure.
4. Check the fuel pump pressure.

### Fuel pump pressure:

**441—588 kPa (4.5—6.0 kg/cm<sup>2</sup>, 64—85 psi)**

5. If the fuel pump pressure is not within specification, check the following;

### No pressure

•Fuel pump operation (Refer to page 4A—47.)

### Low pressure

•Fuel pump feeding capacity (Refer to page 4A—48.)

### High pressure

•Replace the fuel pump

6. After checking the fuel pump pressure, disconnect the jumper wire from the test connector.

## Fuel Line Pressure

1. Start the engine and run it idle.
2. Set the lever on the adapter as shown in the figure.
3. Check the fuel line pressure.

### Fuel line pressure:

**Approx. 186—226 kPa (1.9—2.3 kg/cm<sup>2</sup>, 27—33 psi)**

4. If not within specification, check the vacuum hose.

5. Disconnect the vacuum hose from pressure regulator, and place a finger over the end of the hose.
6. Check the fuel line pressure.

### Fuel line pressure:

**235—275 kPa (2.4—2.8 kg/cm<sup>2</sup>, 34—40 psi)**


7. If not within specification, replace the pressure regulator.
8. Connect the vacuum hose to pressure regulator.

## FUEL PUMP

### Operation Test

1. Connect a jumper wire to the check connector (Yellow).
2. Remove the fuel filler cap.
3. Turn the ignition switch ON.
4. Listen for operational sound of the fuel pump at the filler inlet.
5. Install the fuel filler cap.

# 4A FUEL SYSTEM



6. If no sound is heard, check the voltage at the fuel pump connector (W/Y wire and a ground).

## Voltage: 12V

7. If the voltage is normal, replace the fuel pump.
8. If not correct, check the circuit opening relay (Refer to page 4A—80) and its circuits.
9. Disconnect the jumper wire.

## Volume Test

### Warning

**Before performing following procedures, release the fuel pressure to reduce the possibility of injury or fire. (Refer to page 4A—44)**

1. Connect a jumper wire to test connector (Yellow).
2. Disconnect the fuel return hose from fuel return pipe.
3. Turn the ignition switch ON for 10 seconds, and check the feeding capacity with graduated cylinder.
4. If not within specification, check the fuel filter, and fuel line.
5. Turn the ignition switch OFF and disconnect the jumper wire.

### Feeding capacity: 220 cc (13.4 cu in) min/10 sec.

## PULSATION DAMPER

1. Run the engine at idle.
2. Place a finger on the screw of the pulsation damper head.
3. Check that pulsation is felt.

## INJECTOR





### On-vehicle Inspection

### Engine does not start


Perform "Quick Inspection for Electrical Signal" below.

### Engine runs

1. Warm up the engine and run it at idle.
2. Listen for operational sound of the injector with a screwdriver or a sound scope.









86U04A-085


Test connector Green 1 pin




86U04A-086



96U04A-034



96U04A-035



96U04A-036

3. Disconnect the connector from each injector respectively.
4. Check that the engine speed decreases about **100—200 rpm** each time.
5. If not correct, check the following:

**No operating sound and no speed drop**

**Perform "Quick Inspection for Electrical Signal" below.**

**No speed drop only**

**Injector resistance**

**Injection volume of injector**

### Quick Inspection for Electrical Signal

1. Ground the test connector (Green, 1-pin) with a jumper wire.
2. Turn the ignition switch ON.
3. Open the throttle valve and check for a "click" at the injector with a screwdriver or sound scope as it is opened.
4. If nothing is heard, check the injector wiring circuit.
5. If nothing is heard at all injectors, check the main relay (Refer to page 4A—78) and circuit.

### Inspection

There are 3 inspections which must be performed for the injectors.

### Resistance

1. Remove the injectors from the engine. (Refer to page 4A—54.)
2. Check the resistance of each injector with an ohmmeter.
3. If not correct, replace the injector.

**Resistance: 12—16  $\Omega$**

### Fuel leakage test and volume test

1. Lift the dynamic chamber upward.
2. Remove the injectors and delivery pipe. (Refer to pages 4A—54 and 56.)
3. Affix the injectors to the delivery pipe with wire.


### Caution

**Affix the injectors firmly to the delivery pipe so that no movement of the injectors is possible.**

### Warning

**Be extremely careful when working with fuel. Always work away from sparks or open flames.**


## 4A FUEL SYSTEM



4. Connect the terminals of the fuel pump test connector with a jumper wire. Turn the ignition switch ON.
5. Check that no fuel leaks from the injector nozzles.

### Note

After 1 minute a drop of fuel from the injector is acceptable.



6. Connect the **SST** to the battery and injector.
7. Check the injection volume with a graduated container.

### Injection volume:


Approx. 44—61 cc (2.68—3.72 cu in) /15 sec.

### Caution

When using the SST, make sure of the SST number and use correct one.

8. If not correct, replace the injectors.

## PRESSURE REGULATOR CONTROL SYSTEM



86U04A-092

To prevent percolation of the fuel during idle after the engine is restarted, vacuum is cut to the pressure regulator, increasing the fuel pressure.

**Specified time:** Approx. 120 sec.

**Operating condition:** Coolant temperature — above 70°C (158°F)

Intake air temperature — above 20°C (68°F)

# 4A FUEL SYSTEM

## COMPONENT DESCRIPTIONS

Component	Function	Remarks	Application	
			New model	Previous model
<b>Engine control unit</b>	Detects signals from input sensors and switches; controls solenoid valve (Pressure regulator control)		○	○
<b>Ignition coil (-) terminal</b>	Detects engine speed; sends signal to control unit		○	○
<b>Ignition switch (ST position)</b>	Sends engine cranking signal to control unit		○	○
<b>Intake air thermo sensor</b>	Detects intake air temperature; sends signal to control unit	Installed in air flow meter	○	○
<b>Pressure regulator</b>	Adjusts fuel pressure supplied to injectors		○	○
<b>Solenoid valve (Pressure regulator control)</b>	Controls vacuum line to pressure regulator	Closes vacuum line when hot	○	○
<b>Throttle sensor</b>	Detects throttle valve opening angle; sends signal to control unit	Installed on throttle body	○	○
<b>Water thermo sensor</b>	Detects coolant temperature; sends signal to control unit		○	○

86U04A-093

## TROUBLESHOOTING


Check the condition of the wiring harness and connections before checking the sensors or switches below.

### Note


**Make the system inspection first. If no problem is found, continue with the next system inspection of the Troubleshooting Guide. (Refer to pages 4A—8 and 9.)**

Possible cause Page	Solenoid valve (Pressure regulator control)	Water thermo sensor	Intake air thermo sensor	Throttle sensor	Engine control unit terminal	System inspection
	4A—53	4A—92	4A—89	4A—90	2K 4A—84	4A—53
Symptom						
Engine stalls or rough after hot starting	2	3	4	5	6	1

96U04A-037



96U04A-038



86U04A-096

Operating time	Fuel line pressure kPa (kg/cm <sup>2</sup> , psi)
After starting: for 120 sec.	235—275 (2.4—2.8, 34—40)
After 120 sec.	186—226 (1.9—2.3, 27—33)

86U04A-097

## System Inspection


1. Connect the **SST** to the engine. (Refer to page 4A—46.)
2. Start the engine.

3. Warm up the engine to normal operating temperature and stop the engine.


### Warning

**Be careful when disconnecting the water thermo sensor connector because the surrounding area is very hot.**

4. Disconnect the water thermo sensor connector. Connect a resistor (**200 Ω**) to the sensor connector.
5. Lift the air cleaner upper cover assembly.
6. Heat the intake air thermo sensor to **above 30°C (86°F)**.
7. Restart the engine.
8. Check the fuel line pressure and operating times as shown in the chart.



86U04A-098




86U04A-099


## Solenoid Valve (Pressure Regulator Control) Inspection

1. Disconnect the vacuum hose from the solenoid valve and vacuum pipe.
  2. Blow through the solenoid valve from vacuum hose A.
  3. Check that air flows from port B.
- 
4. Disconnect the solenoid valve connector.
  5. Connect 12V and a ground to the terminals of the solenoid valve.
  6. Blow through the solenoid valve from the vacuum hose A.
  7. Check that air flows from the valve air filter.


# 4A FUEL SYSTEM




86U04A-039




86U04A-101



86U04A-102



86U04A-103



86U04A-104

## REPLACEMENT

### Caution

- Before performing the following procedure, release the fuel pressure from the fuel system to reduce the possibility of injury or fire (Refer to page 4A-44).
- When servicing the fuel system, keep sparks, cigarettes, and open flames away from the fuel.

### Fuel Pump

- Remove the rear seat and disconnect the fuel pump connector.
- Remove the service hole cover.
- Disconnect the fuel hoses.
- Remove the fuel pump and fuel tank gauge assembly.
- Replace the fuel pump.

### Caution


Secure the fuel pump terminals and fuel hoses securely.

- Install in the reverse order of removal.


### Injector

- Remove the wiring harness bracket.
- Remove the EGR modulator valve bracket.
- Disconnect the vacuum pipe mounting bolts.


- Disconnect the air hose from the throttle body.




86U04A-105




86U04A-106



86U04A-107



86U04A-108



86U04A-109

5. Remove the engine hanger.
6. Remove the dynamic chamber mounting bolts and nuts.

7. Lift the dynamic chamber.
8. Disconnect the fuel return pipe bracket from the intake manifold.
9. Disconnect the injector connectors.
10. Remove the delivery pipe along with the pressure regulator and pulsation damper.

11. Remove the grommets, injectors, and insulators.
12. Install in the reverse order of removal, referring to installation note.

### Tightening torque:

**Delivery pipe**  
**Dynamic chamber**  
**Engine hanger**

**19—25 Nm**  
**(1.9—2.6 m·kg, 14—19 ft·lb)**


### Installation note

#### Injector


1. Use new O-rings.
2. Apply a small amount of engine oil to the O-rings when installing.

3. Install the injectors and the injector insulators.


# 4A FUEL SYSTEM




96U04A-040




86U04A-111



96U04A-041



96U04A-042



96U04A-043

## Delivery Pipe

1. Perform steps 1 to 7 of removal procedure for injectors. (Refer to page 4A—54.)
2. Remove the pulsation damper, pressure regulator, and injectors.

3. Replace the delivery pipe.
4. Install in the reverse order of removal, referring to installation note.

## Tightening torque:

### Pressure regulator

8—11 N·m (0.8—1.1 m·kg, 69—95 in·lb)

### Delivery pipe

19—25 N·m

### Engine hanger

(1.9—2.6 m·kg, 14—19 ft·lb)

### Dynamic chamber

## Installation note

### Insulator

Install the insulators between the intake manifold and delivery pipe.

### Injector

Refer to page 4A—55.

## Pressure Regulator

1. Perform steps 1 to 8 of removal procedure for the injector. (Refer to page 4A—54.)
2. Disconnect the vacuum hose and fuel return hose.
3. Remove the pressure regulator.
4. Install in the reverse order of removal.


## Tightening torque:

8—11 N·m (0.8—1.1 m·kg, 69—95 in·lb)


## Pulsation Damper

1. Perform steps 1 to 7 of removal procedure for the injectors. (Refer to page 4A—54.)
2. Remove the pulsation damper.
3. Install in the reverse order of removal.





96U04A-044



86U04A-116

## Fuel Filter

### Low pressure side

Refer to page 4A—54.

### High pressure side

The fuel filter must be replaced at the intervals outlined in the maintenance schedule.

### Warning

**Always work away from sparks or open flames.**

1. Disconnect the fuel hoses from the fuel filter.
2. Remove the fuel filter and the bracket.
3. Install a new filter and the bracket.
4. Connect the fuel hoses.

### Note

**When installing the filter, push the fuel hoses fully onto the fuel filter and secure the hoses with spring clamps.**

# 4A FUEL SYSTEM


## FUEL TANK

### Removal

#### Caution

- a) Before performing the following procedure, release the fuel pressure from the fuel system to reduce the possibility of injury or fire. (Refer to page 4A-44)
- b) When removing the fuel tank, keep sparks, cigarettes, and open flames away from the fuel tank.

Remove in the sequence shown in the figure.




86U04A-11

#### Note

Drain the fuel from the fuel tank before removing the tank.

- |                         |                    |
|-------------------------|--------------------|
| 1. Fuel pump connectors | 5. Breather hose   |
| 2. Fuel hoses           | 6. Fuel tank strap |
| 3. Evaporative hoses    | 7. Fuel tank       |
| 4. Fuel filler hose     |                    |



86U04A-118

### Inspection

1. Check the fuel tank for cracks and corrosion.
2. If any defect is found, repair or replace the tank.


### Warning

**Before repairing, clean the fuel tank thoroughly with steam to sufficiently remove all explosive gas.**


### Installation

Install in the reverse order of removal, referring to the installation note.

### Torque Specifications



## 4A FUEL SYSTEM




96U04A-120

### Installation note

1. Push the hose ends of the main fuel hose, fuel return hose and evaporation hoses onto the fuel tank fittings **at least 25 mm (1.0 in)**.
2. Push the fuel filler hose ends onto the fuel tank pipe and filler pipe **at least 35 mm (1.4 in)**.

## DECELERATION CONTROL SYSTEM



86U04A-121

The fuel cut system is provided as a deceleration control system.  
This system is to improve fuel economy.

# 4A DECELERATION CONTROL SYSTEM

## COMPONENT DESCRIPTIONS

Component	Function	Remarks	Application	
			New model	Previous model
<b>Brake light switch</b>	Detects braking operation (deceleration); sends signal to control unit		○	○
<b>Clutch switch</b>	Detects in-gear condition; sends signal to control unit	Switch ON when clutch pedal released	○	○
<b>EC-AT control unit</b>	Detects N or P range; sends signal to control unit		○	X
<b>Engine control unit</b>	Detects signals from input sensors and switches; cuts fuel injection		○	○
<b>Idle switch</b>	Detects when throttle valve fully closed; sends signal to control unit	Installed on throttle body	○	○
<b>Ignition coil (-) terminal</b>	Detects engine speed; sends signal to control unit		○	○
<b>Inhibitor switch</b>	Detects in-gear condition; sends signal to EC-AT control unit	Switch ON in "N" or "P" range	○	○
<b>Neutral switch</b>	Detects in-gear condition; sends signal to control unit	Switch ON when in-gear	○	○
<b>Water thermo sensor</b>	Detects coolant temperature; sends signal to control unit		○	○

86U04A-122

## TROUBLESHOOTING

Check the condition of the wiring harness and connectors before checking the sensor or switches below.

### Note

**Make the system inspection first. If no problem is found, continue with the next system inspection of the Troubleshooting Guide. (Refer to page 4A-8 and 9.)**

Possible cause	Water thermo sensor	System inspection
Page	4A-92	4A-63
Checking order	2	1

96U04A-045


# DECELERATION CONTROL SYSTEM 4A

## System Inspection (Electrical Signal)

1. Connect the **SST** between the wiring harness and control unit.
2. Set 3C or 3E position on the **SST**.

### Note

- 3C** — For No. 2 and No. 4 injectors  
**3E** — For No. 1 and No. 3 injectors




86U04A-124

0-5V



0-20V




86U04A-125

0-5V



0-20V




86U04A-126

3. Check that the indicator lamps alternately flash at idle.

4. Increase the engine speed to **4,000 rpm**, then suddenly decrease the engine speed.
5. Check that the red indicator lamp stays illuminated during deceleration.

# 4A EGR SYSTEM

## EXHAUST GAS RECIRCULATION (EGR) SYSTEM



86U04A-128

This system introduces exhaust gas into the intake manifold to reduce NOx in the exhaust gas. It operates depending on the engine load, engine speed (**above 1,500 rpm**), engine coolant temperature (**above 70°C, 158°F**), and radiator coolant temperature (**above 17°C, 63°F**).

### COMPONENT DESCRIPTIONS

Component	Function	Remarks	Application	
			New model	Previous model
<b>EGR control valve</b>	Recirculates portion of exhaust gas		<input type="radio"/>	<input type="radio"/>
<b>EGR modulator valve</b>	Controls vacuum acting on EGR control valve		<input type="radio"/>	<input type="radio"/>
<b>Engine control unit</b>	Detects signals from input sensors and switches; controls solenoid valve (EGR)		<input type="radio"/>	<input type="radio"/>
<b>Ignition coil (-) terminal</b>	Detects engine speed; sends signal to control unit		<input type="radio"/>	<input type="radio"/>
<b>Solenoid valve (EGR)</b>	Controls vacuum line to EGR control valve		<input type="radio"/>	<input type="radio"/>
<b>Throttle sensor</b>	Detects throttle valve opening angle; sends signal to control unit	Installed on throttle body	<input type="radio"/>	<input type="radio"/>
<b>Water thermo sensor</b>	Detects coolant temperature; sends signal to control unit		<input type="radio"/>	<input type="radio"/>
<b>Water thermo switch</b>	Detects radiator coolant temperature; sends signal to control unit	ON: above 17°C (63°F)	<input type="radio"/>	<input type="radio"/>

86U04A-128




## TROUBLESHOOTING

Check the condition of the wiring harness and connectors before checking the sensors or switches.


**Note**  
**Make the system inspection first. If no problem is found, continue with the next system inspection of the Troubleshooting Guide. (Refer to pages 4A—8 and 9.)**

Possible cause	Solenoid valve (EGR)	EGR modulator valve	EGR control valve	Water thermo sensor	Water thermo switch	Engine control unit terminal		System inspection
						1H	2N	
Page	4A—65	4A—66	4A—66	4A—92	4A—93	4A—83	4A—85	4A—65
Checking order	3	2	4	6	5	7	8	1


96U04A-046



86U04A-130



86U04A-131



86U04A-132

### System Inspection

1. Start the engine.
2. Accelerate the engine and verify that the diaphragm of the EGR control valve does not move while the engine is still cold.
3. Warm up the engine to normal operating temperature and run it at idle.

### Warning


**Be careful when checking the EGR control valve because the surrounding area is very hot.**

4. Accelerate the engine and check that the diaphragm of the EGR control valve moves upward.


### Solenoid Valve (EGR)

1. Disconnect the vacuum hose from the solenoid valve and vacuum pipe.
2. Blow through the solenoid valve from vacuum hose A.
3. Check that air flows from port B.
4. Disconnect the solenoid valve connector.
5. Connect 12V and a ground to the terminals of the solenoid valve.
6. Blow through the solenoid valve from vacuum hose A.
7. Check that air flows from the valve air filter.


# 4A EGR SYSTEM



86U04A-133



86U04A-134



## EGR Modulator Valve

1. Remove the EGR modulator valve.
2. Plug the No. 1 port and connect a vacuum pump to the No. 3 port.
3. Blow into the exhaust gas port. Operate the vacuum pump and verify that vacuum is held.
4. Release the exhaust gas port and confirm that vacuum is released.

## EGR Control Valve

1. Manually actuate the valve by pushing on the diaphragm with finger.
2. Check that the spring resistance is present and the diaphragm moves freely with no sticking or binding.

### Note


**Before replacing the EGR control valve, check the intake air and control systems.**

3. Warm up the engine and run it at idle.
4. Connect a vacuum pump to the valve and apply vacuum.
5. Check that the engine runs roughly or stalls at more than the specified vacuum.

**Specification: 40—60 mmHg (1.6—2.4 inHg)**

6. If not correct, replace the EGR control valve.

EVAPORATIVE EMISSION CONTROL (EEC) SYSTEM



86U04A-136

This system stores fuel vapor generated in the fuel tank in the canister when the engine is not running. The fuel vapor is stored in the canister until it is drawn into the dynamic chamber and burned when the engine is started.

COMPONENT DESCRIPTIONS

Component	Function	Remarks	Application	
			New model	Previous model
Air flow meter	Detects amount of intake air; sends signal to control unit	Intake air temp sensor and fuel pump switch are integrated	○	○
Charcoal canister	Stores gas tank fumes when engine stopped		○	○
Check and cut valve	Releases excessive pressure or vacuum in fuel tank to atmosphere		○	X
Engine control unit	Detects signals from input sensors and switches; controls solenoid valve (Purge control)		○	○
Ignition coil (-) terminal	Detects engine speed; sends signal to control unit		○	○
Separator	Prevents fuel from flowing into charcoal canister		○	X
Solenoid valve (Purge control)	Controls vacuum line to vacuum switch valve		○	○
Three-way check valve	Controls pressure in fuel tank		○	○
Vacuum switch valve	Regulates evaporative fumes from canister to intake manifold		○	○
Water thermo sensor	Detects coolant temperature; sends signal to control unit		○	○
Water thermo valve	Controls vacuum applied to No.1 purge control valve and solenoid valve (Purge)	Opens vacuum line above 54°C (129°F)	○	○

86U04A-137

## TROUBLESHOOTING


Check the condition of the wiring harness or connectors before checking the sensors or switches.

### Note


Make the system inspection first. If no problem is found, continue with the next system inspection of the Troubleshooting Guide. (Refer to pages 4A—8 and 9.)

Possible cause	Vacuum switch valve	Solenoid valve (purge control)	Three-way check valve	Check and cut valve	Separator	No. 1 purge valve	No. 2 purge valve	Water thermo valve	Water thermo sensor	Engine control unit terminal 2P	System inspection
Page	4A—69	4A—70	4A—70	4A—71	4A—71	4A—69	4A—69	4A—70	4A—92	4A—85	4A—88
Checking order	3	2	9	10	11	4	5	6	7	8	1

96U04A-046



86U04A-139




86U04A-141

### System Inspection

1. Check the vacuum hose routing.
2. If there is a poor connection, clog, or leak, repair or replace as necessary.
3. Warm up the engine and run it at idle.
4. Disconnect vacuum hose A from No. 1 purge control valve and connect the **SST** to the hose.
5. Increase the engine speed to above **2,500 rpm** and verify that the gauge shows more than **150 mmHg (5.9 inHg)**.
6. If not correct, check the water thermo valve.
7. Reconnect hose A to No. 1 purge control valve.


86U04A-140

8. Disconnect vacuum hose B from the canister and place a finger over the end of the hose.
9. Accelerate the engine rapidly and check that vacuum is felt at **above 1,500 rpm**.
10. Reconnect hose B to the canister.




86U04A-142

11. Disconnect vacuum hose C from the canister and place a finger over the end of the hose.
12. Check that vacuum is felt.
13. If not correct, check the vacuum line between the canister and the dynamic chamber for clogging.



86U04A-143


14. Disconnect the evaporation hose from the evaporation pipe.
15. Connect the vacuum pump to the evaporation pipe.
16. Operate the vacuum pump and verify that no vacuum is held.
17. If vacuum is held, check the evaporation pipe for clogging.



86U04A-144

### No. 1 Purge Control Valve


1. Blow through the purge control valve from port A and check that air does not flow.
2. Connect a vacuum pump to the purge control valve.
3. Apply **110 mmHg (4.33 inHg)** vacuum, and blow through port A again; air should flow.



86U04A-145

### No. 2 Purge Control Valve

1. Disconnect vacuum hose B from the evaporation pipe.
2. Blow through the hose and verify that air flows freely.




86U04A-146

### Vacuum Switch Valve

1. Remove vacuum switch valve.
2. Connect a vacuum pump to the valve.
3. Blow through the valve from port A and verify that air comes out of port B when vacuum is applied.

**Specified vacuum: 66—106 mmHg (2.6—4.2 inHg)**


# 4A EEC SYSTEM



86U04A-147

## Water Thermo Valve


1. Remove the water thermo valve.
2. Immerse the valve in a water-filled container.
3. Heat the water gradually and observe the temperature.
4. Blow through the valve from one vacuum port and verify that air comes out of the other port at **46—54°C (115—129°F)**.



86U04A-148


## Three-Way Check Valve

1. Remove the check valve.



86U04A-149


2. Blow through the valve from port A, and check that air comes out of port B.  
Next, block port B and check that air comes out of port C.
3. Block port B.
4. Connect a vacuum pump to port A and verify that no vacuum is held.



86U04A-150


## Solenoid Valve (Purge)

1. Remove the solenoid valve.




86U04A-151


2. Connect vacuum hoses to the valve as shown in the figure.
3. Blow air through the valve from hose A and check that air comes out of the valve air filter.
4. Apply 12V and ground the solenoid valve with jumper wires.
5. Blow air through the valve from hose A and check that the air comes out of port B.
6. Replace, if necessary.



86U04A-152



86U04A-153



86U04A-154

## Check and Cut Valve

1. Remove the check and cut valve.

2. Connect a pressure gauge to the passage that normally is connected to the fuel tank.
3. Blow through the valve from port A. Verify that the valve opens at **5.39—6.87 kPa (0.055—0.07 kg/cm<sup>2</sup>, 0.78—1.00 psi)**.
4. Remove the pressure gauge and connect it to the passage to atmosphere.
5. Blow through the valve from port B. Verify that the valve opens at **0.98—4.91 kPa (0.01—0.05 kg/cm<sup>2</sup>, 0.14—0.71 psi)**.

### Note


**The test must be performed with the valve horizontal. Otherwise, the ball in the valve will move out of position and close the passage.**

## Separator

1. Remove the separator.
2. Visually check the separator for damage.
3. Replace, if necessary.

# 4A PCV SYSTEM

## POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM




86U04A-157

The PCV valve is operated by the intake manifold vacuum. When the engine is running at idle, the PCV valve is opened slightly and a small amount of blow-by gas is drawn into the dynamic chamber. At high engine speeds, the PCV valve is further opened and a larger amount of blow-by gas is drawn into the dynamic chamber.

### COMPONENT DESCRIPTION

Component	Function	Remarks	Application	
			New model	Previous model
PCV valve	Controls blowby gas amount pulled into engine		<input type="radio"/>	<input type="radio"/>




### PCV VALVE

1. Warm up the engine to the normal operating temperature and run it at idle.
2. Disconnect the PCV valve and the ventilation hose from the cylinder head cover.
3. Close the PCV valve opening.
4. Check that vacuum is felt.



## EXHAUST SYSTEM



86U04A-158


The catalytic converter is used to reduce CO, HC and NOx. The converter contains a compound of platinum and rhodium. It is a three-way catalyst type with a volume of **2,100 cc (128 cu in)**.

# 4A EXHAUST SYSTEM

## REMOVAL AND INSTALLATION


1. Remove in the sequence shown in the figure.
2. Install in the reverse order of removal.

## Torque Specifications



1. Main silencer
2. Middle pipe
3. Pre-silencer

4. Catalytic converter
5. Bracket
6. Front pipe




## INSPECTION

1. Check the catalytic converter and exhaust pipe for deterioration or restriction.
2. Check the insulation covers welded onto the catalytic converter for damage.

## Note

If the insulation cover is touching the catalytic converter housing, excessive heat at the floor will occur.

## CONTROL SYSTEM



86U04A-166

The control system consists of the input devices and the control unit. The control unit controls the fuel injection amount (EGI), fuel injection pressure, bypass air amount, switch monitor function, and fail-safe function.

# 4A CONTROL SYSTEM

## RELATIONSHIP CHART Output Devices and Input Devices


TEST CONNECTOR	X	X	X	O	X	X	X	
BRAKE LIGHT SWITCH	O	X	X	X	X	X	X	
VEHICLE SPEED SWITCH	O	X	X	X	X	X	X	
ELECTRICAL LOAD CONTROL UNIT	X	X	X	O	X	X	X	
P/S PRESSURE SWITCH	X	X	X	O	X	X	X	
A/C SWITCH	O	X	X	O	X	O	X	
IGNITION SWITCH (STA POSITION)	O	O	X	X	X	X	O	
INHIBITOR SWITCH and EC-AT CONTROL UNIT	O	X	X	O	O	X	X	
NEUTRAL AND CLUTCH SWITCH	O	X	X	O	X	X	X	
OXYGEN SENSOR	O	X	X	X	X	X	X	
WATER THERMO SWITCH (RADIATOR)	O	X	X	X	O	X	X	
ATMOSPHERIC PRESSURE SENSOR	O	X	X	O	X	X	X	
INTAKE AIR THERMO SENSOR	O	X	X	O	X	X	O	
WATER THERMO SENSOR	O	X	X	O	O	O	O	
IDLE SWITCH	O	O	X	O	X	X	X	
THROTTLE SENSOR	O	O	X	O	O	X	O	
AIR FLOW METER	O	X	X	X	X	O	X	
IGNITION COIL	O	O	X	O	O	O	O	
INPUT DEVICES	OUTPUT DEVICES	INJECTOR	FUEL INJECTION AMOUNT					
			FUEL INJECTION TIMING					
		BAC VALVE	AIR VALVE					
			ISC VALVE					
		SOLENOID VALVE (EGR)						
		SOLENOID VALVE (PURGE)						
SOLENOID VALVE (PRESSURE REGULATOR)								

O : Related  
X : Not related


## Output Devices and Engine Conditions

ENGINE CONDITIONS		MEDIUM LOAD		ACCELERATION	HEAVY LOAD	DECELERATION	IDLE (THROTTLE VALVE FULLY CLOSED)	IGN: ON (ENGINE NOT RUNNING)	REMARKS	
		COLD	WARM							
OUTPUT DEVICES	INJECTOR	Rich	Rich and lean	Rich	Rich	Fuel cut	Rich and lean	No injection	Above 6,300 rpm: fuel cut * Above 4,500 rpm	
	INJECTION TIMING	1 group (once per revolution)		1 group (once per revolution) (once per two revolutions)*			1 group (once per revolution)			
BAC VALVE	AIR VALVE	Open*		Close					*Coolant temp. below 50°C (122°F)	
	ISC VALVE	Large amount of bypass air	Small amount of bypass air					No bypass	*In extreme cold condition	
SOLENOID VALVE (EGR)	SOLENOID VALVE (EGR)	ON (EGR cut)	OFF (EGR)	ON (EGR cut)	OFF (EGR)	ON (EGR cut)	ON (EGR cut)*	ON	*ATX D range: OFF (NO EGR due to no vacuum to system)	
	SOLENOID VALVE (PURGE)	OFF (2nd stage not operated)	ON (2nd stage operates)				OFF (2nd stage not operated)	OFF	1st stage: controlled by water thermo valve	
SOLENOID VALVE (PRESSURE REGULATOR CONTROL)		OFF (Vacuum to pressure regulator)								*During hot start only


# 4A CONTROL SYSTEM




69G04A-161



86U04A-169



86U04A-170



69G04A-164

## EGI MAIN FUSE

### Inspection

Check the continuity of EGI main fuse.

## MAIN RELAY

1. Check that a "clicking" sound is heard at the main relay when turning the ignition switch ON and OFF.
2. Apply 12V and a ground to (A) and (B) terminals of the main relay.
3. Check continuity at terminals using an ohmmeter.

Operation	12V Not applied	12V Applied
Terminals C — D	No continuity	Continuity

## CIRCUIT OPENING RELAY

### Relay Circuit

1. Remove the circuit opening relay.
2. Check the circuit as described.

Terminal	Checking item	Correct result
Fp	Resistance	0.2—30Ω
Fc	Continuity (cranking)	∞
B	Voltage (Ign: ON)	Battery voltage
STA	Voltage (Cranking)	Approx. 9V
E1	Continuity	∞

### Circuit Opening Relay

1. Apply 12V and a ground to the terminals below and check the circuit opening relay as described.

12V	Grounded	Correct result
STA	E1	B ↔ Fp: Continuity
B	Fc	Fp: Battery voltage


### Resistance

Check the resistance between the terminals using an ohmmeter.

Between terminals	Resistance (Ω)
STA ↔ E1	15—30
B ↔ Fc	80—150
B ↔ Fp	∞

## ENGINE CONTROL UNIT

Engine Signal Monitor (49 9200 162) and Adapter (49 9200 163).



86U04A-171

The **Engine Signal Monitor** (49 9200 162) was developed to check the control unit terminal voltages. This monitor easily inspects the individual terminal voltages through selection of the monitor switch.

**How to Use the Engine Signal Monitor**


1. Connect the **Engine Signal Monitor** (49 9200 162) between the engine control unit and the engine harness using the **adapter** (49 9200 163).
2. Turn the selector switch and monitor switch to select the terminal number.
3. Check the terminal voltage.

**Caution**

Never apply voltage to terminals A and B.


# 4A CONTROL SYSTEM

## Wiring Diagram






## FOR NON TURBO ■ ENGINE & FUEL CONTROL SYSTEM



# 4A CONTROL SYSTEM

## ■ FOR EC-AT COOLING FAN SYSTEM



## Terminal Voltage

If the input and output devices and related wiring are normal, but the engine control unit terminal voltage is incorrect, replace the engine control unit.


Terminal	Input	Output	Connection to	Voltage (After warming-up)		Remarks
				IGN: ON	Idle	
1A		○	Malfunction indicator light	For 3sec. after ignition switch OFF → ON: below 4.8V (light illuminates) After 3sec.: Battery voltage (light does not illuminate)		<ul style="list-style-type: none"> <li>• Test connector grounded</li> <li>• Light illuminates: below 4.8V</li> <li>• Light does not illuminate: Battery voltage</li> </ul>
1B		○	Self-Diagnosis Checker (Code number)	For 3sec. after ignition switch OFF → ON: below 6.2V (Buzzer sounds) After 3sec.: Battery voltage (Buzzer does not sound)		<ul style="list-style-type: none"> <li>• Using Self-Diagnosis Checker and test connector grounded</li> <li>• Buzzer sounds: below 6.2V</li> <li>• Buzzer does not sound: Battery voltage</li> </ul>
1C	—	—	—	—		—
1D		○	Self-Diagnosis Checker (Monitor lamp)	Test connector grounded For 3sec. after ignition switch OFF → ON: below 6.2V (light illuminates) After 3sec.: Battery voltage (light does not illuminate)	(Test connector grounded) approx. 5V (Test connector not grounded) Monitor lamp ON: below 6.2V Monitor lamp OFF: Battery voltage	With Self-Diagnosis Checker
1E	○		Idle switch	Accelerator pedal released: below 0.5V Accelerator pedal depressed: above 7.7V		
1F		○	A/C relay	Battery voltage	A/C switch ON: below 2.5V A/C switch OFF: Battery voltage	Blower motor ON
1G	—	—	—	—		—
1H	○		Water thermo switch	Above 7.3V		Radiator temp.: below 17°C (63°F)
				Below 1.5V		Radiator temp.: above 17°C (63°F)
1I	○		Electrical load control unit	Electrical load ON: below 1.5V Electrical load OFF: above 7.3V		Electrical load: Rear defroster Headlight Blower motor (3rd & 4th position) Electrical fan
1J	○		Brake light switch	Brake pedal released: below 3.6V Brake pedal depressed: above 10.0V		
1K	○		P/S pressure switch	Constant above 10.5V	P/S ON: below 1.5V P/S OFF: above 10.5V	
1L	○		A/C switch	A/C switch ON: below 1.5V A/C switch OFF: above 10.0V		Blower motor: ON
1M	○		Ignition coil ⊖ terminal	Battery voltage	*1 Battery voltage	*1 Engine Signal Monitor: green and red lights flash
1N	—	—	—	—		—

# 4A CONTROL SYSTEM


Terminal	Input	Output	Connection to	Voltage (After warming-up)		Remarks
				IGN: ON	Idle	
1O	—	—	—	—	—	—
1P	—	—	—	—	—	—
1Q	—	—	—	—	—	—
1R	—	—	—	—	—	—
1S	—	—	—	—	—	—
1T	—	—	—	—	—	—
1U	—	—	—	—	—	—
1V	○	—	—	Constant below 1.5V Constant above 10.5V	—	MTX ATX
1W	○	—	Test connector	Test connector grounded: below 0.5V Test connector not grounded: above 10.5V	—	Green connector, 1-pin
1X	—	—	—	—	—	—
2A	—	○	V ref	4.5—5.5V	—	—
2B	○	—	Air flow meter (Vc)	7—9V	—	—
2C	—	—	Ground (E2)	0V	0V	—
2D	○	—	Oxygen sensor	0V	0—1.0V	<ul style="list-style-type: none"> <li>• Cold engine: 0V at idle</li> <li>• After warming-up: Increase engine speed: 0.5—1.0V Deceleration: 0—0.4V</li> </ul>
2E	○	—	Air flow meter (Vs)	Approx. 1.7V	Approx. 3—5V	Increase engine speed: voltage increases
2F	—	—	—	—	—	—
2G	○	—	Throttle sensor	Accelerator pedal released: approx. 0.5V (depends on 2A terminal voltage)	—	Max. voltage (Throttle valve fully open): approx. 4.3V
2H	○	—	Atmospheric pressure sensor	At sea level: approx. 4.0V	—	—
2I	○	—	Water thermo sensor	0.3—0.6 V	—	Engine coolant temp. 20°C (68°F): approx. 2.5V
2J	○	—	Air flow meter (Intake air thermo sensor)	Approx. 2.5V at 20°C (68°F)	—	—
2K	—	○	Solenoid valve (Pressure regulator control)	For 120 sec. after ignition switch OFF → ON: below 3.5V	For 120 sec. after starting: below 3.5V	Hot condition: Coolant temp. above 70°C (158°F) Intake air temp. above 20°C (63°F)
2L	○	—	Speedometer	Battery voltage	Battery voltage	Other conditions <ul style="list-style-type: none"> <li>• Above 113 mph (180 km/h): below 1.0V</li> </ul>
2M	—	—	—	—	—	—

Terminal	Input	Output	Connection to	Voltage (After warming-up)		Remarks
				IGN: ON	Idle	
2N		○	Solenoid valve (EGR)	Below 3.5V		<ul style="list-style-type: none"> <li>Cold engine: below 3.5V Radiator coolant temp.—below 17°C (63°F) or Engine coolant temp.—below 70°C (158°F)</li> <li>Engine above approx. 1,500 rpm: Battery voltage</li> </ul>
2O		—		—		
2P		○	Solenoid valve (Purge control valve)	Battery voltage		<ul style="list-style-type: none"> <li>Medium and high load: below 3.5V</li> </ul>
2Q		○	Solenoid valve (Idle speed control valve)	Approx. 1.7—11V		
2R	—	—	Ground (E02)	0V		
3A	—	—	Ground (E01)	0V		
3B	○	—	Ignition switch (Start position)	Below 2.5V		While cranking: battery voltage
3C		○	Injector (No. 4 and No. 2)	Battery voltage	*1 Battery voltage	*1 Engine Signal Monitor green and red lights flash
3D	○	—	Inhibitor switch through EC-AT unit	"N" or "P" range: below 2.5V Other ranges: battery voltage		ATX
			Neutral and clutch switch	In-gear condition Clutch pedal depressed: battery voltage Clutch pedal released: below 0.5V		MTX (Neutral: constant battery voltage)
3E		○	Injector (No. 1 and No. 3)	Battery voltage	*1 Battery voltage	*1 Engine Signal Monitor: green and red lights flash
3F	—	—		—		
3G	—	—	Ground (E1)	0V		
3H	—	—		—		
3I	○	—	Main relay	Battery voltage		
3J	—	—	Battery	Battery voltage		For back-up


96U04A-056




# 4A CONTROL SYSTEM




86U04A-174



69G04A-171



69G04A-172



86U04A-175

## Replacement

1. Disconnect the negative battery cable.
2. Remove the front console covers (right and left).
3. Disconnect the connectors from the control unit.
4. Replace the control unit.

## NEUTRAL SWITCH

### Inspection

1. Disconnect the neutral switch connector.
2. Connect an ohmmeter to the switch.
3. Check continuity of the switch.

Transmission	Continuity
In neutral	No
In other ranges	Yes

4. After checking, connect the switch connector.

### Note

Refer to section 7A for replacement of the neutral switch.

## CLUTCH SWITCH

### Inspection

1. Disconnect the clutch switch connector.
2. Connect an ohmmeter to the switch.
3. Check continuity of the switch.

Pedal	Continuity
Depressed	No
Released	Yes

4. After checking, connect the switch connector.

### Note

Refer to section 6 for replacement of the clutch switch.

## BRAKE LIGHT SWITCH

### Inspection


1. Disconnect the brake light switch connector.
2. Connect an ohmmeter to the switch.
3. Check the continuity of the switch.

Pedal	Continuity
Depressed	Yes
Released	No

4. After checking, connect the switch connector.

### Note

Refer to section 11 for replacement of the brake switch.



86U04A-176

## P/S PRESSURE SWITCH

### Inspection


1. Disconnect the P/S pressure switch connector.
2. Connect an ohmmeter to the switch.
3. Start the engine. Check continuity of the switch while turning the steering wheel at idle.

P/S	Continuity
Turning	Yes
Not turning	No

4. Connect the switch connector after checking.

### Note

**Refer to section 10 for replacement of the P/S pressure switch.**



86U04A-177

## INHIBITOR SWITCH

### Inspection

1. Disconnect the inhibitor switch connector.
2. Connect an ohmmeter to the switch.
3. Check continuity of the switch.


Position	Continuity
P and N ranges	Yes
Other ranges	No

4. Connect the switch connector after checking.

### Note

**Refer to Section 7B for replacement of the inhibitor switch.**

# 4A CONTROL SYSTEM



96U04A-057


## E/L CONTROL UNIT

### Inspection

1. Connect a voltmeter between the E/L control unit and ground.
2. Start the engine and check the terminal voltages as described below.

Terminal	Input	Output	Connection to	Voltage (after warm-up)		Remarks
				Ignition switch: ON	Idle	
A (B/W)	—	—	Ignition switch	Battery voltage		
B	—	—	—	—	—	—
C (B)	—	—	Ground	0V		
D (L/Y)	○		Electrical fan relay	Battery voltage		Coolant temp.: below 97°C (207°F)
				Below 1.5V		Coolant temp.: above 97°C (207°F)
E (G/Y)		○	Control unit (1l)	0V		E/L: ON
				Battery voltage		E/L: OFF
F (W)	○		Headlight switch	Battery voltage		Headlight switch: ON
				Below 1.5V		Headlight switch: OFF
G (L/B)	○		Blower motor switch	Below 1.5V		Blower motor switch: ON (3rd or 4th position)
				Approx. 5V		Others
H (B/L)	○		Rear defroster switch	Below 1.5V		Rear defroster switch: ON
				Battery voltage		Rear defroster switch: OFF

86U04A-179




96U04A-049

### Replacement



1. Remove the engine control unit. (Refer to page 4A-86)
2. Replace the E/L control unit.
3. Install in the reverse order of removal.



## AIR FLOW METER



69G04C-100



### Inspection


1. Remove the air flow meter. (Refer to page 4A—31)
2. Check the air flow meter body for cracks.
3. Verify that the measuring plate moves smoothly.
4. Disconnect the connector from the air flow meter.
5. Using an ohmmeter, check resistance between the terminals with the measuring plate fully closed and fully open.
6. Connect the connector to the air flow meter after inspecting.

Terminal	Resistance ( $\Omega$ )	
	Fully closed	Fully open
E2↔Vs	20—400	20—1,000
E2↔Vc	100—400	
E2↔Vb	200—400	
E2↔THA (Intake air thermo sensor)	-20°C (-4°F) 20°C (68°F)	13.6—18.4 k $\Omega$ 2.21—2.69 k $\Omega$
E1↔Fc	$\infty$	0


### Note

Refer to page 4A—31 for replacement of the air flow meter.


# 4A CONTROL SYSTEM




86U04A-183




86U04A-184



86U04A-185



86U04A-186



96U04A-052

## THROTTLE SENSOR

### Caution

Use a precision voltmeter with a scale of 0.01V to inspect or adjust the throttle sensor.

### Inspection

1. Remove the air hose from the throttle body.
2. Disconnect the throttle sensor connector (3-pin).
3. Connect the **SST** between the throttle sensor and the wiring harness.
4. Turn the ignition switch ON.
5. Make sure that the throttle valve is fully closed.
6. Measure **BLACK** and **RED** wire voltages. Check that the voltages are as specified.

### Specification:

**BLACK wire — Approx. 0V**  
**RED wire — 4.5—5.5V**

7. If not correct, check the battery voltage and wiring harness. If these are OK, replace the engine control unit.
8. Record the **RED** wire voltage.
9. Check that **BLUE** wire voltage for the recorded **RED** wire voltage is as specified below.

### Specification:


RED wire voltage (V)	BLUE wire voltage (V)	RED wire voltage (V)	BLUE wire voltage (V)
4.50—4.59	0.37—0.54	5.10—5.19	0.42—0.61
4.60—4.69	0.38—0.55	5.20—5.29	0.43—0.62
4.70—4.79	0.39—0.56	5.30—5.39	0.44—0.63
4.80—4.89	0.40—0.57	5.40—5.49	0.44—0.64
4.90—4.99	0.40—0.58	5.50	0.44—0.66
5.00—5.09	0.41—0.60		

10. Hold the throttle valve fully open.
11. Check that **BLUE** wire voltage for the recorded **RED** wire voltage is as specified.


### Specification:

RED wire voltage (V)	BLUE wire voltage (V)	RED wire voltage (V)	BLUE wire voltage (V)
4.50—4.59	3.58—4.23	5.10—5.19	4.05—4.79
4.60—4.69	3.66—4.32	5.20—5.29	4.13—4.88
4.70—4.79	3.74—4.41	5.30—5.39	4.21—4.98
4.80—4.89	3.82—4.51	5.40—5.49	4.29—5.07
4.90—4.99	3.90—4.60	5.50	4.29—5.17
5.00—5.09	3.97—4.70		


12. Check that **BLUE** wire voltage increases smoothly when opening the throttle valve from closed to fully open.
13. If not correct, replace the throttle sensor.
14. Turn the ignition OFF.
15. Disconnect the **SST** and reconnect the throttle sensor connector.
16. Disconnect the negative battery terminal and depress the brake pedal for at least 5 seconds to eliminate the control unit malfunction memory.




86U04A-188




86U04A-189



86U04A-190



86U04A-191



86U04A-192

## Adjustment

1. Remove the air hose from the throttle body.
2. Disconnect the throttle sensor connector (3-pin).
3. Connect the **SST** between the throttle sensor and the wiring harness.
4. Turn the ignition switch ON.
5. Make sure the throttle valve is fully closed.

6. Measure **RED** wire voltage and record it.

7. Change the voltmeter connection to the **BLUE** wire.
8. Loosen the throttle sensor mounting screws.


9. Turn the throttle sensor to adjust **BLUE** wire voltage within the range specified for the recorded **RED** wire voltage.

## Specification:


RED wire voltage (V)	BLUE wire voltage (V)	RED wire voltage (V)	BLUE wire voltage (V)
4.50—4.59	0.37—0.54	5.10—5.19	0.42—0.61
4.60—4.69	0.38—0.55	5.20—5.29	0.43—0.62
4.70—4.79	0.39—0.56	5.30—5.39	0.44—0.63
4.80—4.89	0.40—0.57	5.40—5.49	0.44—0.64
4.90—4.99	0.40—0.58	5.50	0.44—0.66
5.00—5.09	0.41—0.60		

10. Tighten the throttle sensor mounting screws.
11. Recheck that **BLUE** wire voltage is within specification.
12. Hold the throttle valve fully open.


# 4A CONTROL SYSTEM




86U04A-193




96U04A-053



86U04A-196



86U04A-202



86U04A-203

13. Check that **BLUE** wire voltage is within specification.

### Specification:

RED wire voltage (V)	BLUE wire voltage (V)	RED wire voltage (V)	BLUE wire voltage (V)
4.50—4.59	3.58—4.23	5.10—5.19	4.05—4.79
4.60—4.69	3.66—4.32	5.20—5.29	4.13—4.88
4.70—4.79	3.74—4.41	5.30—5.39	4.21—4.98
4.80—4.89	3.82—4.51	5.40—5.49	4.29—5.07
4.90—4.99	3.90—4.60	5.50	4.29—5.17
5.00—5.09	3.97—4.70		

14. Check that **BLUE** wire voltage increases smoothly when opening the throttle valve from closed to fully open.
15. If not correct, replace the throttle sensor.
16. Turn the ignition OFF.
17. Disconnect the **SST** and reconnect the throttle sensor connector.
18. Disconnect the negative battery terminal and depress the brake pedal for at least 5 seconds to eliminate the control unit malfunction memory.

### IDLE SWITCH

#### Inspection

1. Disconnect the idle switch connector (1-pin).
2. Check continuity between the switch and ground.

Throttle valve condition	Continuity
Fully closed	Yes*
Open	No

\* Less than 30Ω is acceptable

3. If not correct, check condition of wiring harness of the idle switch. Replace the idle switch and throttle body as an assembly, if necessary.

### WATER THERMO SENSOR

#### Inspection

1. Remove the water thermo sensor from the cylinder head.
2. Place the sensor in water with a thermometer and heat the water gradually.
3. Check resistance of the sensor with an ohmmeter.

Coolant	Resistance
-20°C (-4°F)	14.5—17.8 kΩ
20°C (68°F)	2.2—2.7 kΩ
40°C (104°F)	1.0—1.3 kΩ
60°C (140°F)	500—640 Ω
80°C (176°F)	280—350 Ω

4. If not correct, replace the water thermo sensor.

## WATER THERMO SWITCH

### Inspection

1. Remove the switch from the radiator.
2. Place the switch in water with a thermometer, and heat the water gradually.
3. Check for continuity of the switch with an ohmmeter.

Coolant temp.	Continuity
More than approx. 17°C (63°F)	Yes
Less than approx. 17°C (63°F)	No

4. If not correct, replace the water thermo switch.

## OXYGEN SENSOR

### Inspection of Output Voltage

1. Warm up the engine and run it at idle.
2. Disconnect the oxygen sensor connector.
3. Connect a voltmeter between the oxygen sensor and ground.
4. Run the engine at **4,500 rpm** until the voltmeter indicates **approx. 0.7V**.


5. Increase and decrease the engine speed suddenly several times. Check to see that when the speed is increased the meter reads between **0.5V—1.0V**, and when the speed is decreased it reads between **0V—0.4V**.
6. If the voltmeter doesn't indicate as specified, replace the oxygen sensor.

### Inspection of Sensitivity


1. Warm up the engine to the normal operating temperature and run it at idle.
2. Connect the **SST** to the check connector.

3. Increase the engine speed to between **2,000 and 3,000 rpm**, and check that the monitor lamp flashes for 10 seconds.


**Monitor lamp: Flashes ON and OFF more than 8 times/10 sec**




86U04A-204




86U04A-205



86U04A-206




86U04A-207



86U04A-208

## 4A CONTROL SYSTEM



67U04X-154

### ATMOSPHERIC PRESSURE SENSOR

#### Inspection

1. Connect a voltmeter to the atmospheric pressure sensor (D terminal).
2. Turn the ignition switch on and take a voltage reading.

**Voltage: 3.5—4.5V at sea level 2.5—3.5V at high altitude [2,000m (6,500 ft)]**

3. Replace the sensor if necessary.