

MANUAL TRANSAXLE (G5MX-R)

INDEX..... J2- 2

FEATURES

OUTLINE..... J2- 3

 OUTLINE OF CONSTRUCTION J2- 3

 SPECIFICATIONS..... J2- 4

 STRUCTURAL VIEW J2- 5

TRANSAXLE..... J2- 6

 DOUBLE CONE SYNCHRO
 MECHANISM..... J2- 6

 SHIFT ROD..... J2- 8

 INTERLOCK MECHANISM..... J2- 8

 SECONDARY SHAFT,
 1ST/2ND GEAR,
 1ST/2ND CLUTCH HUB,
 1ST/2ND SHIFT FORK J2- 9

TRANSFER UNIT J2-10

 CENTER DIFFERENTIAL J2-11

 VISCOUS COUPLING J2-16

 CENTER DIFFERENTIAL
 LOCK SYSTEM (MANUAL)..... J2-19

 IDLER GEAR SHAFT J2-20

SERVICE

TROUBLESHOOTING GUIDE..... J2-21

TRANSAXLE OIL J2-22

 INSPECTION J2-22

 REPLACEMENT..... J2-22

TRANSFER UNIT OIL J2-22

 INSPECTION J2-22

 REPLACEMENT..... J2-23

VISCOUS COUPLING J2-23

 OPERATION INSPECTION..... J2-23

TRANSAXLE..... J2-24

 PREPARATION J2-24

 REMOVAL J2-26

 DISASSEMBLY J2-30

 INSPECTION J2-43

 ASSEMBLY J2-46

 INSTALLATION J2-68

TRANSFER UNIT J2-72

 PREPARATION J2-72

 DISASSEMBLY J2-74

 INSPECTION J2-80


 ASSEMBLY J2-81

SHIFT MECHANISM..... J2-93

 OVERHAUL J2-93

96E0J2-001

INDEX



96E0J2-002

1. Transaxle		3. Shift mechanism	
Removal	page J2-26	Overhaul	page J2-93
Disassembly	page J2-30	4. Transaxle oil	
Inspection	page J2-43	Inspection / Replacement ...	page J2-22
Assembly	page J2-46	5. Transfer unit oil	
Installation	page J2-68	Inspection / Replacement..	pages J2-22, 23
2. Transfer unit			
Disassembly	page J2-74		
Inspection	page J2-80		
Assembly	page J2-81		

OUTLINE**OUTLINE OF CONSTRUCTION**

- Full-time 4-wheel drive, incorporating a viscous coupling is used. With this system all driving conditions are easily contended with; from good roads to bad roads and inclement weather.
- The transaxle and transfer unit were developed based on the transaxle of the previous 626. The transaxle, center differential, viscous coupling, and front differential are a single, compact unit.
- The center differential employs a planetary carrier system and a viscous coupling, and functions to distribute the driving force to the front and rear differentials as needed. Through the use of this center differential, tire scuffing common to 4-wheel-drive vehicles during tight cornering, is eliminated.
- The speedometer driven gear (for detection of vehicle speed) is installed in the transfer carrier and detects the speed of the rear wheels.
- Lubrication oil of the transaxle and transfer unit and the carrier is contained separately.

96EQJ2-003

SPECIFICATIONS
Transaxle and Transfer Unit


Item	Engine model		New	Previous
			F2 12-valve (4WD)	FE 12-valve
Transaxle control			Floor shift	
Synchronmesh system	Forward	Synchronmesh		
	Reverse	Selective sliding and synchronmesh		
Gear ratio	1st		3.307	3.307
	2nd		1.833	1.833
	3rd		1.233	1.310
	4th		0.914	1.030
	5th		0.717	0.837
	Reverse		3.166	3.166
Final gear ratio			4.388	3.850
Speedometer gear ratio			0.95	0.80, 0.84
Center differential	Type	Planetary carrier		
	Number of ring gear teeth	Outer	79	—
		Inner	66	—
	Number of pinion gear teeth	Outer	14	—
		Inner	14	—
	Number of sun gear teeth	Pinion gear side	33	—
		Idler gear side	43	—
Number of idler gear teeth		43	—	
Oil	Type	ATF: DEXRON-II or M-III Above 0°F: API: GL-4 or GL-5 SAE: 80W-90 or SAE 90	ATF: DEXRON-II API: GL-4 or GL-5 SAE: 80W-90 or SAE 90	
	Capacity	2.6 liters (2.7 US qt, 2.3 Imp qt)	3.35 liters (3.6 US qt, 3.9 Imp qt)	

Transfer Carrier

Number of teeth	Ring gear	37
	Pinion gear	11
Oil	Type	API: GL-5 Above 0°F: SAE 90 Below 0°F: SAE 80W
	Capacity	0.5 liter (0.5 US qt, 0.4 Imp qt)

96E0J2

STRUCTURAL VIEW




(b) p


002-004

TRANSAXLE

DOUBLE CONE SYNCHRO MECHANISM

- The double cone synchro mechanism is employed for 1st and 2nd gears of the G5MX-R type transaxle in order to shorten the synchro time and to lessen the force required to shift the transmission.
- The adoption of the double cone synchro mechanism also makes possible a more compact configuration and a greater synchro capacity.
- The double cone synchro mechanism is composed of the outer cone, the double cone, the inner cone, and the inner cone hub.






96EQJ2-007

Operation Description

1. When the hub sleeve moves leftward (in the direction of the arrow), the synchronizer key presses against the outer cone.
2. As the hub sleeve moves leftward, the key causes friction to be produced between the outer cone, double cone, and inner cone, with the result that the outer cone turns by the amount of the gap of the key channel. Consequently, the teeth of the hub sleeve and the outer cone are aligned. As the hub sleeve continues moving, the friction between the cones becomes greater, and the difference of the rotational speeds of the outer cone, the inner cone and the double cone (unified with gear) gradually disappears.
3. The hub sleeve then moves up onto the synchronizer key, and engages the outer cone.
4. The hub sleeve then engages the synchro teeth of the gear to complete the shift.


SHIFT ROD



96EQJ2-008

To assure smooth shifting, there are three separate shift rods for activation of 1st-2nd, 3rd-4th, and 5th-Rev shifts.

INTERLOCK MECHANISM













96EQJ2-009

A pin type of interlock mechanism is used. It is designed so that as one rod is moved, it pushes the interlock pins out and prevents the other rods from moving.

TRANSAXLE

J2


SECONDARY SHAFT, 1ST/2ND GEAR, 1ST/2ND CLUTCH HUB, 1ST/2ND SHIFT FORK

	NEW	PREVIOUS	mm (in)
SECONDARY SHAFT	 285.0 (11.220)	 278.5 (10.965)	
1ST GEAR	 33.5 (1.319)	 38 (1.496)	
2ND GEAR	 27 (1.063)	 21 (0.827)	
1ST/2ND CLUTCH HUB			
1ST/2ND SHIFT FORK			

96EQJ2-010

The gears in the transaxle are redesigned along with the change to the double cone synchro mechanism.

TRANSFER UNIT




96E0J2-011

The transaxle and transfer unit carry out two separate functions, that of transmission of power and separation of power.

The transfer unit consists of; the center differential which separates the flow of power 50/50 front and rear and also compensates for the speed differential of the front and rear differentials, the viscous coupling which interlocks the front and rear axles under slippery road conditions, the front differential which drives the front wheels, and the transfer carrier to drive the rear wheels through the rear differential.

CENTER DIFFERENTIAL



96E0J2-012


The center differential is composed of the ring gear, planetary carrier, pinion gears, sun gear, viscous coupling, and front differential gear case.

The outer teeth of the ring gear mesh with the final gear of the transaxle secondary shaft, and the ring gear inner teeth mesh with the outer pinion gears of the planetary carrier.

The center differential lock sleeve slides on the other end of the ring gear case.

There are three sets of pinion gears (each set consisting of one outer pinion gear and one inner pinion gear) spaced at regular intervals. The outer pinion gears mesh with the inner teeth of the ring gear, and the inner pinion gears mesh with the sun gear. The outer and inner pinion gears also mesh with each other.


The outer teeth of the viscous coupling mesh with the sun gear, and the inner teeth of the viscous coupling mesh with the front differential gear case.



96E0J2-013

The center differential employs a planetary carrier system similar to that used in an automatic transaxle. In addition, the planetary carrier is coupled to the front differential gear case and can be manually coupled to the ring gear case by the center differential lock sleeve. (Refer to page J2-20.) The sun gear is meshed with the inner pinion gears of the planetary carrier. The other side of the sun gear provides power to the rear differential through the idler gear, transfer carrier, and propeller shaft. The ring gear is the input driving force, and the output forces are the planetary carrier (front differential) and the sun gear (rear differential).

Operation




96E0J2-014

During straight-ahead travel

Driving force from the engine is transmitted from the final gear of the transaxle secondary shaft to the ring gear of the center differential, causing the ring gear to rotate.

Because the speed of the front wheels and of the rear wheels are the same during straight-ahead travel, the planetary carrier (output force to the front wheels) and the sun gear (output force to the rear wheels) act united (fixed condition) and rotate together with the ring gear.




96E0J

Front wheel speed greater than rear wheels

The speed of the sun gear (output force to the rear wheels) is less than that of the planetary carrier (output force to the front wheels), thus effectively fixed.

As a result, the outer pinion gears rotate clockwise and the inner pinion gears rotate counterclockwise, thus rotating the planetary carrier counterclockwise.

In this way, the center differential absorbs the speed difference between the front and rear wheels and driving force is distributed uniformly to the front and rear differentials.




96E0J2-016

Rear wheel speed greater than front wheels

The speed of the planetary carrier (output force to front wheels) is less than that of the sun gear (output force to rear wheels), thus effectively becoming fixed. As a result, the outer pinion gears rotate counterclockwise and the inner pinion gears rotate clockwise, thus rotating the sun gear counterclockwise.

VISCOUS COUPLING



96EQJ2-017

Operation

If the vehicle encounters very slippery conditions and one wheel starts to spin, the center differential absorbs the speed difference and the other three wheels lose driving force. At times like this, the viscous coupling automatically causes the center differential to lock so that the front and rear axles are interconnected, and driving force is transmitted to all wheels.

Construction


The viscous coupling consists of a number of thin steel inner and outer plates and high-viscosity silicone oil. The outer plates couple the housing and the spline. The housing, via the sun gear and transfer carrier, is linked to the rear wheels. Between the outer plates are spacer rings. The inner plates are coupled to the hub, and the hub, via the front differential gear case and the driveshafts, is linked to the front wheels. The inner plates can move side to side on the hub. The slots in the plates create the shearing of the silicone oil and cause the fluid coupling effect. The viscous coupling unit is sealed by heat- and pressure-resistant oil seals, and is not rebuildable.

Characteristics of Silicone Oil


1. Viscosity changes little relative to temperature.
2. Expands greatly relative to temperature.
3. Viscosity change small relative to shearing.

The viscous coupling housing is filled 80% to 90% full with silicone oil.


96EQJ2-018




97U0MX-508



97U0MX-509



97U0MX-510



96EQJ2-019

Principle of Operation

Suppose that there is fluid between two parallel plates (A and B), and that plate B is fixed and plate A moves in parallel at a constant speed. The molecules of the fluid that contact the plates at points a and b adhere to the plates, and for that reason the fluid at point a moves at the same speed as plate A, and at point b the fluid speed remains 0.

Because the fluid has a certain viscosity, a related degree of force is required to move plate A.

Seen another way, because of the difference in the speed of plates A and B, shearing stress* is produced within the fluid, and an equal frictional force is caused to act upon plate A, acting as resistance trying to impede its movement. At the same time, this fluid-generated frictional force also acts upon plate B in the opposite direction.

How, then, does this principle apply to the viscous coupling unit? Suppose, for example, that the rotational speed of the inner plate is, as shown in the illustration, faster than that of the outer plate. Because there is a speed difference between the two plates, shearing stress is produced in the silicone oil, and an equal frictional force acts upon the faster-turning inner plate as resistance. This resistance becomes differential-limiting torque. This frictional force then also acts upon the slower-turning outer plate (in the opposite direction), thus increasing its rotational speed.


*** Shearing stress**

Consider fluid (A and B) held in extremely close proximity to each other, and further suppose that the speed at which A moves is faster than the speed at which B moves. There is, consequently, a mutual "sliding" that occurs at the boundary layer between A and B, and, in the same manner as when two rough solid surfaces slide against one another, a force acts to hinder the mutual parallel sliding at the boundary. This force per unit surface area at the boundary is known as shearing stress.

Operation


Power transmission at normal mode

In normal use, differential-limiting force (driving force) is transmitted according to the difference in the rotational speed of the front and rear wheels.




Power transmission at hump mode

When the rotational speed continues at a fixed amount over a period of time (i.e. one wheel in mud), an increase in transmission of power occurs suddenly. This called the "hump phenomenon." The figure shows the relationship of time and the hump phenomenon. What happens is, as the silicone oil is sheared by the plates, its temperature increases, suddenly breaking down the air bubbles in the oil. As the air bubbles break down, the oil expands and causes the inner plates to move and contact the outer plates. Because torque transmission occurs as a result of the friction between the plates, the transmitted torque increases suddenly (hump mode). In the hump mode, as the rotational speed of the plates equalizes, the oil temperature falls, and the inner plates again move away from the outer plates. There is, then, a return to the original torque transmission according to the silicone oil viscosity.



97U0MX-512


CENTER DIFFERENTIAL LOCK SYSTEM (MANUAL)



96E0J2-020

The center differential should not be locked for normal driving. If the vehicle is to be tested on a speedometer tester or a chassis dynamometer, the propeller shaft must be removed to prevent the vehicle from jumping off the tester. And, because the propeller shaft is removed, the center differential must be manually locked to provide power to the front wheels. The center differential is manually locked by pulling the differential lock rod outward.

IDLER GEAR SHAFT



TAPERED ROLLER BEARING


96EQJ2-021

For improved transaxle reliability, a tapered roller bearing is newly fitted at the ring gear end of the idler gear shaft for better support; in addition, the previously fitted bearing is changed from a ball bearing to a tapered roller bearing.


TROUBLESHOOTING GUIDE

Problem	Possible cause	Action	Page
Shift lever hard to shift	Worn select or shift cable	Replace	J2-93
Difficult to shift	Worn change rod	Replace	J2-93
	No grease in transaxle control	Lubricate	J2-93
	Insufficient oil	Add oil	J2-22
	Deterioration of oil quality	Replace with oil of specified quality	J2-22
	Wear or play of shift fork or shift rod	Replace	J2-45
	Worn synchronizer ring	Replace	J2-43
	Worn synchronizer cone of gear	Replace	J2-43
	Bad contact of synchronizer ring and cone of gear	Replace	J2-43
	Excessive longitudinal play of gears	Replace	J2-38, 40, 47, 50
	Worn bearing	Replace	J2-38, 40, 47, 50
	Worn synchronizer key spring	Replace	J2-38, 40, 47, 50
	Excessive primary shaft gear bearing preload	Adjust	J2-56
Won't stay in gear	Worn change control cable	Replace	J2-93
	Weak shift lever ball spring	Replace	J2-93
	Worn shift fork	Replace	J2-34, 64
	Worn clutch hub	Replace	J2-38, 40, 47, 50
	Worn clutch hub sleeve	Replace	J2-38, 40, 47, 50
	Worn shaft gear(s)	Replace	J2-38, 40, 47, 50
	Worn detent of control end	Replace	J2-30, 64
	Weak spring pressing against steel ball	Replace	J2-30, 64
	Excessive thrust clearance	Replace	J2-38, 40, 47, 50
	Worn bearing	Replace	J2-38, 40, 47, 50
	Improperly installed or loose engine mount	Tighten	J2-68
Abnormal noise	Insufficient oil	Add oil	J2-22
	Deterioration of oil quality	Replace	J2-22
	Worn bearing	Adjust or replace	J2-38, 40, 47, 50
	Worn sliding surfaces of gears or shafts	Replace	J2-38
	Excessive gear backlash	Replace	J2-38, 40, 47, 50
	Damaged gear teeth	Replace	J2-38, 40, 47, 50
	Foreign material in gears	Replace	J2-38, 40, 47, 50
	Damaged differential gear or excessive backlash	Adjust or replace	J2-74, 77, 81, 88


96E0J2-022




96EOJ2-023




96EOJ2-024



96EOJ2-025



96EOJ2-026



96EOJ2-027

TRANSAXLE OIL

INSPECTION

1. Remove the check plug.
2. Verify that the oil is at the bottom of the check plug port. If it is low, add the specified oil through the fill plug.
3. Wipe clean the plug threads and install the plugs.

Tightening torque:

Fill plug and check plug
39—59 N·m (4.0—6.0 m·kg, 29—43 ft·lb)

REPLACEMENT

Note

- Replace the drain plug washer with a new one when ever the drain plug is removed.

1. Remove the fill plug and check plug; then remove the drain plug and drain the oil.

2. Install the drain plug, and add the specified oil through the fill plug port.
3. Fill to the bottom of the check plug port.

Capacity: 2.6 liters (2.7 US qt, 2.3 Imp qt)

4. Install the fill and check plugs.

Tightening torque:

39—59 N·m (4.0—6.0 m·kg, 29—43 ft·lb)

TRANSFER UNIT OIL


INSPECTION

1. Remove the check plug.


2. Verify that the oil is at the bottom of the port. If it is low, add the specified oil through the check plug port.
3. Install the check plug and a new washer.

Tightening torque:


39—59 N·m (4.0—6.0 m·kg, 29—43 ft·lb)




96E0J2-028



96E0J2-029



96E0J2-030



96E0J2-031

REPLACEMENT

Note

- Replace drain plug washer with a new one whenever the drain plug is removed.

1. Remove the check plug; then remove the drain plug and drain the oil.

2. Install the drain plug, and add the specified oil from the check plug port.

3. Fill to the bottom of the check plug port.

Capacity: 0.5 liter (0.53 US qt, 0.44 Imp qt)

VISCOUS COUPLING

OPERATION INSPECTION

1. Turn off the engine and shift the transaxle into reverse.
2. Block the rear wheels with wheel chocks.
3. Jack up the front wheels and support the vehicle with jack stands.
4. Release the parking brake.
5. Measure the time it takes to turn the wheel 90° while applying the specified torque.

Specified torque: 15 N·m (1.5 m·kg, 11 ft·lb)

Specified time: 1.5 sec. min.

















6. If not as specified, replace the viscous coupling.
(Refer to pages J2-74, 89.)

J2

TRANSAXLE









TRANSAXLE

PREPARATION SST

<p>49 G017 5A0 Support, engine</p> 	<p>For support of engine</p>	<p>49 0118 850C Puller, ball joint</p> 	<p>For removal of tie-rod end</p>
<p>49 0107 680A Stand, engine</p> 	<p>For disassembly and assembly of transaxle</p>	<p>49 G019 0A0 Hanger, transaxle</p> 	<p>For disassembly and assembly of transaxle</p>
<p>49 G030 440 Holder, primary shaft</p> 	<p>For holding primary shaft</p>	<p>49 W032 2A0 Remover set, bearing</p> 	<p>For removal of bearing outer race</p>
<p>49 B001 795 Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>49 0636 145 Puller, fan pulley boss</p> 	<p>For removal of bearing inner race</p>
<p>49 G030 370 Plate, removing</p> 	<p>For removal of secondary 3rd gear and 2nd gear</p>	<p>49 G017 1A0 Remover set, bearing</p> 	<p>For removal of bearing</p>
<p>49 F401 366A Plate (Part of 49 G017 1A0)</p> 	<p>For removal of bearing inner race</p>	<p>49 B092 373 Attachment G (Part of 49 G017 1A0)</p> 	<p>For removal of bearing inner race</p>
<p>49 B092 374 Attachment H (Part of 49 G017 1A0)</p> 	<p>For removal of bearing inner race</p>	<p>49 0839 425C Puller set, bearing</p> 	<p>For removal of bearing inner race</p>
<p>49 F401 330B Installer set, bearing</p> 	<p>For installation of bearing</p>	<p>49 F401 331 Body (Part of 49 F401 330B)</p> 	<p>For installation of bearing inner race</p>

TRANSAXLE

J2


<p>49 F401 335A Attachment A (Part of 49 F401 330B)</p> 	<p>For installation of bearing inner race</p>	<p>49 F401 337A Attachment B (Part of 49 F401 330B)</p> 	<p>For installation of bearing inner race</p>
<p>49 G030 380C Selector set, shim</p> 	<p>For adjustment of bearing preload</p>	<p>49 G030 381 Selector for $\phi 68$ (Part of 49 G030 380C)</p> 	<p>For adjustment of bearing preload</p>
<p>49 G030 382A Selector $\phi 58$ (Part of 49 G030 380C)</p> 	<p>For adjustment of bearing preload</p>	<p>49 F401 382A Selector $\phi 52$ (Part of 49 G030 380C)</p> 	<p>For adjustment of bearing preload</p>
<p>49 F401 384 Collar (Part of 49 G030 380C)</p> 	<p>For adjustment of bearing preload</p>	<p>49 G019 021 Set, bolt (Part of 49 G030 380C)</p> 	<p>For adjustment of bearing preload</p>
<p>49 FT01 515A Adapter, preload (Part of 49 G030 380C)</p> 	<p>For adjustment of bearing preload</p>	<p>49 F401 385 Bar (Part of 49 G030 380C)</p> 	<p>For adjustment of bearing preload</p>
<p>49 B017 102 Adapter, preload</p> 	<p>For adjustment of bearing preload</p>	<p>49 G017 202 Adapter, preload</p> 	<p>For adjustment of bearing preload</p>
<p>49 B027 001 Holder, differential side gear</p> 	<p>For holding side gear</p>	<p>49 F027 009 Attachment 68 & 77</p> 	<p>For installation of bearing</p>
<p>49 G030 029 Chain</p> 	<p>For support of engine</p>	<p style="text-align: right;">96E0J2-032</p>	

J2

TRANSAXLE


REMOVAL

1. Disconnect the negative battery cable.
2. Raise the vehicle and support it with safety stands.
3. Drain the transaxle oil into a suitable container.
4. Remove in the order shown in the figure, referring to **Removal Note**.



- | | |
|-------------------------------|-------------------------------|
| 1. Negative battery cable | 20. Rear member |
| 2. Battery clamp | 21. Exhaust pipe |
| 3. Battery | 22. Tie-rod end |
| 4. Battery tray | Removal Note page J2-28 |
| 5. Main fuse block | 23. Stabilizer |
| 6. Relay | 24. Driveshaft |
| 7. Bracket | Removal Note page J2-28 |
| 8. Battery carrier | 25. Jointshaft |
| 9. Hose | 26. Bracket |
| 10. Air hose | 27. Starter |
| 11. Air cleaner | 28. Clutch release cylinder |
| 12. Bracket | Removal Note below |
| 13. Shift cable | 29. Engine mount No.2 |
| 14. Select cable | Removal Note below |
| 15. Speedometer cable | 30. Engine mount No.4 |
| 16. Connectors | Removal Note below |
| 17. Wheel and tire | 31. Frame |
| 18. Splash shield | Removal Note below |
| 19. Propeller shaft | 32. Transaxle |
| Removal Note page J2-28 | Removal Note page J2-29 |


96E0J2-034



96E0J2-035

Removal Note
Frame

1. Suspend the engine with the **SST** and remove the engine mounts.




03U0J1-013

Clutch release cylinder

Caution

- Do not damage the clutch pipe.


1. Remove the bolts shown.
2. Lay aside the clutch release cylinder and the clutch pipe when removing the transaxle.



96E0J2-036

Propeller shaft

1. Before removing the propeller shaft, mark the flanges for correct reassembly.




03U0J1-014

Tie-rod end

Caution

- Do not damage the dust boot.

1. Remove the cotter pin and loosen the nut.
2. Disconnect the tie-rod end with the **SST**.



96E0J2-037


Driveshaft

1. Remove the clinch bolt.

Caution

- Wrap a rag around the ball joint dust boot to protect it from damage.

2. Disconnect the lower arm from the knuckle with a pry bar.




03U0J1-017

Caution

- Do not shock the tripod joint when removing the driveshaft.

3. Separate the driveshaft from the transaxle by prying with a bar inserted between the outer ring and the transaxle.
4. Suspend the driveshaft with a rope.



03U0KX-161


Caution

- If the **SST** is not installed, the differential side gears may become misaligned.

4. Slide the **SST** into the differential side gear.

TRANSAXLE

J2



Transaxle

1. Loosen the **SST** (engine support) and lean the engine toward the transaxle.
2. Support the transaxle with a jack.
3. Remove the transaxle mounting bolts.
4. Remove the transaxle.



96E0J2-038

DISASSEMBLY


Precaution

1. Clean the transaxle exterior thoroughly with a steam cleaner or cleaning solvent before disassembly.
2. Clean the removed parts (except sealed bearings) and all sealing surfaces with cleaning solvent, and with compressed air. Clean out all holes and passages with compressed air, and check that there are no obstructions.
3. Wear eye protection when using compressed air to clean components.

5th/Reverse Gear and Housing Parts

1. Measure the thrust clearance between 5th gear and the transaxle case, referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
3. Inspect all parts and repair or replace as necessary.

96E04




- | | |
|---|--|
| 1. Clutch release bearing
Inspection..... page J2-44 | 26. Bolt, spring, and steel ball |
| 2. Clutch release fork | 27. Bolt |
| 3. Speedometer driven gear assembly | 28. Bolt |
| 4. Rear cover | 29. Neutral switch |
| 5. Locknut (Primary shaft)
Disassembly Note..... page J2-32 | 30. 5th/Reverse shift rod |
| 6. Spacer | 31. Roll pin
Disassembly Note..... page J2-32 |
| 7. Locknut (Secondary shaft)
Disassembly Note..... page J2-32 | 32. Primary shaft assembly
Disassembly Note..... page J2-38 |
| 8. Primary reverse synchronizer gear
Inspect for damage, wear, and cracks | 33. Secondary shaft assembly
Disassembly Note..... page J2-40 |
| 9. Synchronizer ring (Reverse)
Inspection..... page J2-43 | 34. Shift fork and shift rod assembly |
| 10. Secondary reverse synchronizer gear
Inspect for damage, wear, and cracks | 35. Front and center differential assembly
Disassembly Note..... page J2-74 |
| 11. 5th/Reverse shift fork
Inspection..... page J2-45 | 36. Idler gear assembly |
| 12. Clutch hub assembly (5th/Reverse)
Inspection..... page J2-45 | 37. Center differential lock shift fork assembly |
| 13. Synchronizer ring (5th)
Inspection..... page J2-43 | 38. Shift gate |
| 14. 5th gear
Inspection..... page J2-44 | 39. Control end |
| 15. Secondary 5th gear
Inspect for damage, wear, and cracks | 40. Dynamic damper assembly |
| 16. Gear sleeve
Inspection..... page J2-44 | 41. Transfer carrier assembly |
| 17. Back-up light switch | 42. Clutch housing assembly |
| 18. Lock bolt | 43. O-ring |
| 19. Interlock bolt | 44. Driven gear |
| 20. Transaxle case assembly | 45. Oil seal
Disassembly Note..... page J2-33 |
| 21. Reverse idler gear shaft assembly | 46. Gear case |
| 22. Reverse idler gear
Inspection..... page J2-43 | 47. Synchronizer key spring |
| 23. Reverse idler gear support | 48. Clutch hub sleeve |
| 24. Reverse idler gear shaft | 49. Synchronizer key |
| 25. Bolt, spring, and steel ball | 50. Clutch hub |
| | 51. 3rd/4th shift fork
Inspection..... page J2-45 |
| | 52. Interlock sleeve |
| | 53. 1st/2nd shift fork
Inspection..... page J2-45 |
| | 54. Control lever |
| | 55. Control rod |


96E0J2-041

J2


TRANSAXLE




96E0J2-042




03U0J1-023



03U0J2-023



96E0J2-043



96E0J2-044

Preinspection

5th gear thrust clearance

1. Measure the 5th gear thrust clearance with a dial indicator.

Clearance: 0.10—0.22mm (0.004—0.009 in)

Maximum: 0.27mm (0.011 in)

2. If the clearance exceeds the maximum, check the contact surfaces of 5th gear and the clutch hub. Replace worn or damaged parts.

Disassembly note

Locknut

1. Mount the transaxle on the **SST**.

2. Lock the primary shaft with the **SST**.

3. Shift to 1st or 2nd gear to lock the rotation of the primary shaft.

Caution

- Do not reuse the removed locknut.

4. Uncrimp the tabs of the locknuts.


5. Remove the locknuts from the primary and secondary shafts.

Roll pin

1. Remove the roll pin with a pin punch.


Primary shaft assembly, secondary shaft assembly, front and center differential assembly and idler gear assembly

1. Tilt the transaxle toward the transfer carrier side.




96EOJ2-045

2. Lift the center differential and idler gear a few centimeters (inches).




96EOJ2-046

3. Remove the primary shaft assembly, secondary shaft assembly, and shift fork and shift rod assembly together.




96EOJ2-047

4. Remove the shift gate.



96EOJ2-048

5. Remove the center differential assembly, center differential lock shift fork assembly, and idler gear together.



03U0J1-034

Oil seal (Speedometer gear case)

1. Remove the oil seal as shown in the figure.

J2


TRANSAXLE

Clutch Housing and Transaxle Case Components

Caution


- Do not remove an oil seal if not necessary.

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.



1. Plug	27. Lever set spring and steel ball
2. Oil passage	28. Reverse lever support
3. Bearing outer race	29. Bearing outer race
4. Diaphragm spring	30. Oil seal
5. Adjustment shim	31. Bearing outer race
6. Bearing outer race	Disassembly Note page J2-36
7. Diaphragm spring	32. Funnel
8. Adjustment shim	Disassembly Note page J2-36
9. Oil seal	33. Bearing outer race
Disassembly Note page J2-35	Disassembly Note page J2-35
10. Bearing outer race	34. Bearing outer race
Disassembly Note page J2-35	35. Oil seal
11. Adjustment shim	Replacement (On-vehicle) page J2-36
12. Bearing outer race	36. Crank lever shaft
Disassembly Note page J2-36	Disassembly Note page J2-36
13. Adjustment shim	37. Crank lever
14. Selection lever	38. Inner shift lever
15. Select lever	39. Select lever
16. Oil seal	40. Oil seal
17. Transaxle case	41. Base plate assembly
18. Dust cover	42. Spring
19. Ventilator cover	43. Pivot
20. Plug	44. Plug
21. Magnet	45. Oil seal
22. Baffle	Disassembly Note page J2-35
23. Bolt	46. Oil seal
24. Bleeder dust boot and bleeder	Disassembly Note page J2-36
25. Bleeder	47. Seal plate and seal rubber
26. Baffle	48. Clutch housing

96E0J2-050




96E0J2-051

Disassembly note
Oil seal (Front and center differential)

Caution

- Do not damage the clutch housing and transaxle case.

1. Remove the oil seal with a screwdriver.




96E0J2-052

Bearing outer race (Front and center differential)

Caution

- Do not damage the clutch housing and transaxle case.

1. Remove the bearing outer race with a screwdriver.




96EQJ2-053

Bearing outer race (Idler gear)

Caution

- Do not damage the clutch housing and transaxle case.


1. Remove the bearing outer race with the SST.



96EQJ2-054

Bearing outer race and funnel (Secondary shaft)


1. Remove the bearing outer race by lifting out the funnel and race together.



96EQJ2-055

Crank lever shaft

1. Remove the roll pin with side cutters.
2. Remove the crank lever shaft.




96EQJ2-056

Oil seal (Center differential lock shift rod)

Caution

- Do not damage the clutch housing.


1. Remove the oil seal with a screwdriver.




96EQJ2-057

Oil seal (Driveshaft and jointshaft) Replacement (On-vehicle)


1. Jack up the vehicle and support it with safety stands.
2. Drain the transaxle oil.
3. Replace the driveshaft oil seal.
 - (1) Remove the front wheel.
 - (2) Remove the splash shield.
 - (3) Separate the front stabilizer from the lower arm.




96EOJ2-058




03U0J1-036



03U0J2-031



03U0J1-037



03U0J2-032

Caution

- Do not damage the dust boots.

- (4) Remove the clinch bolt and pull the lower arm downward to separate the knuckle from the lower arm ball joint.
- (5) Loosen the nut and disconnect the tie-rod end with the **SST**.

Caution

- Do not subject the tripod joint to shock when removing the driveshaft.

- (6) Disconnect the driveshaft from the transaxle by prying with a bar inserted between the outer ring and the transaxle.
- (7) Suspend the driveshaft with a rope.

- (8) Remove the oil seal with a screwdriver.

Note


- Tap in until the oil seal installer contacts the case.
- Coat the oil seal lip with transaxle oil.

- (9) Tap the new oil seal into the transaxle case with the **SST**.

- (10) Replace the driveshaft end clip with a new one. Insert the driveshaft with the end-gap of the clip facing upward.


Primary Shaft Assembly

1. Measure the thrust clearances of all gears before disassembly, referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



96E0J2-059

- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Bearing inner race
Disassembly Note..... page J2-39 2. 4th gear
Disassembly Note..... page J2-39 3. Synchronizer ring (4th)
Inspection..... page J2-43 4. Retaining ring 5. Clutch hub assembly (3rd/4th)
Disassembly Note..... page J2-39
Inspection..... page J2-45 6. Synchronizer ring (3rd)
Disassembly Note..... page J2-39
Inspection..... page J2-43 | <ol style="list-style-type: none"> 7. 3rd gear
Disassembly Note..... page J2-39
Inspection..... page J2-44 8. Bearing inner race
Disassembly Note..... page J2-39 9. Primary shaft
Inspection..... page J2-43 10. Synchronizer spring 11. Clutch hub sleeve 12. Synchronizer key 13. Clutch hub |
|--|--|



96EQJ2-060

**Preinspection
3rd gear thrust clearance**

1. Measure the clearance between 3rd gear and 2nd gear.

Clearance: 0.05—0.20mm (0.002—0.008 in)
Maximum: 0.25mm (0.010 in)

2. If the clearance exceeds the maximum, check the contact surfaces of the 3rd gear, 2nd gear and clutch hub (3rd/4th). Replace worn or damaged parts.




96EQJ2-061

4th gear thrust clearance

1. Measure the clearance between 4th gear and the bearing inner race.

Clearance: 0.165—0.365mm (0.006—0.014 in)
Maximum: 0.415mm (0.016 in)

2. If the clearance exceeds the maximum, check the contact surfaces of the 4th gear, bearing inner race, and clutch hub (3rd/4th). Replace worn or damaged parts.




96EQJ2-062

**Disassembly note
Bearing inner race (4th gear)**

Caution

- Hold the shaft with one hand so that it does not fall.

1. Remove the bearing inner race with the SST.




96EQJ2-063

Clutch hub assembly (3rd/4th), synchronizer ring (3rd) and 3rd gear

Caution

- Hold the shaft with one hand so that it does not fall.

1. Remove the retaining ring.
2. Remove the clutch hub assembly (3rd/4th), synchronizer ring (3rd) and 3rd gear with the SST.




96EQJ2-064

Bearing inner race (1st gear)

1. Remove the bearing inner race with the SST.


Secondary Shaft Assembly

1. Measure the thrust clearance of 1st gear and 2nd gear before disassembly, referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



96E0J2-065

- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Bearing inner race
Disassembly Note page J2-41 2. 4th gear
Disassembly Note page J2-41 3. Retaining ring 4. 3rd gear
Disassembly Note page J2-41 5. 2nd gear
Disassembly Note page J2-41
Inspection page J2-45 6. Double cone assembly 7. Retaining ring 8. Clutch hub assembly (1st/2nd)
Disassembly Note page J2-41
Inspection page J2-45 9. Double cone assembly
Disassembly Note page J2-41 | <ol style="list-style-type: none"> 10. 1st gear
Inspection page J2-45 11. Bearing inner race
Inspect for wear, damage and rough rotation
Disassembly Note page J2-42 12. Secondary shaft
Inspection page J2-44 13. Synchronizer key spring 14. Clutch hub sleeve (1st/2nd) 15. Synchronizer key 16. Clutch hub (1st/2nd) 17. Synchronizer ring 18. Double cone 19. Inner cone |
|--|---|



03U0J1-045

Preinspection


1st gear thrust clearance

1. Measure the clearance between 1st gear and the differential drive gear.

Clearance: 0.05—0.28mm (0.002—0.011 in)

Maximum: 0.33mm (0.013 in)

2. If the clearance exceeds the maximum, check the contact surfaces of the 1st gear, differential drive gear of the secondary shaft gear, and clutch hub assembly (1st/2nd). Replace worn or damaged parts.



96E0J2-066


2nd gear thrust clearance

1. Measure the clearance between 2nd gear and 3rd gear.

Clearance: 0.18—0.46mm (0.007—0.018 in)

Maximum: 0.51mm (0.020 in)

2. If the clearance exceeds the maximum, check the contact surfaces of the 2nd gear, 3rd gear, and clutch hub assembly (1st/2nd). Replace worn or damaged parts.



96E0J2-067


Disassembly note

Bearing inner race and 4th gear

Caution

- Hold the shaft with one hand so that it does not fall.

1. Remove the bearing inner race and 4th gear with the **SST**.




96E0J2-068

3rd gear and 2nd gear

Caution

- Hold the shaft with one hand so that it does not fall.

1. Remove the retaining ring.
2. Remove the 3rd gear and 2nd gear with the **SST**.




96E0J2-069

Clutch hub assembly (1st/2nd), double cone assembly and 1st gear

Caution

- Hold the shaft with one hand so that it does not fall.

1. Remove the retaining ring.
2. Remove the clutch hub assembly (1st/2nd), double cone assembly and 1st gear with the **SST**.



Bearing inner race (Secondary shaft end)

Caution

- Hold the shaft with one hand so that it does not fall.

1. Remove the bearing inner race with the SST.

1. Measure the clearance between 2nd gear and 3rd gear.
 Clearance: 0.15-0.5mm (0.007-0.018 in)
 Maximum: 0.8mm (0.030 in)
 2. If the clearance exceeds the maximum, check the contact surfaces of the 2nd gear, 3rd gear, and clutch hub assembly (1st/2nd). Replace worn or damaged parts.

Disassembly note
 Bearing inner race and 4th gear

Caution
 • Hold the shaft with one hand so that it does not fall.


1. Remove the bearing inner race and 4th gear with the SST.

3rd gear and 2nd gear

Caution
 • Hold the shaft with one hand so that it does not fall.

1. Remove the retaining ring.
2. Remove the 3rd gear and 2nd gear with the SST.


1. Remove the retaining ring	11. Bearing inner race
2. Remove the 3rd gear and 2nd gear with the SST	12. Synchronizer key spring
3. Remove the 4th gear	13. Synchronizer key sleeve (1st/2nd)
4. Remove the 5th gear	14. Synchronizer key
5. Remove the 6th gear	15. Clutch hub (1st/2nd)
6. Remove the 7th gear	16. Clutch hub (2nd/1st)
7. Remove the 8th gear	17. Synchronizer ring
8. Remove the 9th gear	18. Clutch hub assembly (1st/2nd) double cone end
9. Remove the 10th gear	19. Clutch hub assembly (1st/2nd) double cone end



INSPECTION

Inspect all parts and repair or replace as necessary.


03U0J1-051



96EOJ2-070

Synchronizer Ring

1. Inspect the synchronizer ring teeth for damage, wear, and cracks.
2. Inspect the taper surface for wear and cracks.




96EOJ2-071

Note

- Set the synchronizer ring squarely in the gear; then measure around the circumference.

3. Measure the clearance between the synchronizer ring and flank surface of the gear.

Standard clearance: 1.02—1.98mm (0.040—0.078 in)
Minimum: 2.48mm (0.098 in)




96EOJ2-072

Reverse Idler Gear and Reverse Lever

1. Inspect the gear teeth for damage, wear, and cracks.
2. Measure the clearance between the reverse idler gear bushing and the reverse lever.

Standard clearance: 0.10—0.35mm (0.004—0.014 in)
Maximum: 0.85mm (0.033 in)



96EOJ2-073

Primary Shaft


Note

- If the shaft gear is replaced, adjust the bearing preload. (Refer to page J2-56.)



1. Inspect the shaft gear runout.

Maximum runout: 0.05mm (0.002 in)


2. Inspect the splines for damage and wear.
3. Inspect the gear teeth for damage, wear, and cracks.




96EQJ2-074



03U0J1-059



96EQJ2-075



96EQJ2-076

3rd Gear, 4th Gear, 5th Gear, and Gear Sleeve (5th Gear)

1. Measure the clearance between the shaft gear and the gear.

Oil Clearance

mm (in)

	Shaft (Outer dia.)	Gear (Inner dia.)	Sleeve (Outer dia.)	Oil clearance
3rd	35.945—35.970 (1.415—1.416)	36.000—36.025 (1.417—1.418)	—	0.03—0.08 (0.001—0.003)
4th	30.945—30.970 (1.218—1.219)	31.000—31.025 (1.220—1.221)	—	
5th	—	34.000—34.025 (1.339—1.400)	33.945—33.970 (1.336—1.337)	

2. Inspect the synchronizer cones for wear.
3. Inspect the gear teeth for damage, wear, and cracks.

Clutch Release Bearing

Caution

- The clutch release bearing is a sealed bearing and must not be washed in solvent.

1. Turn the bearing while applying force in the axial direction. If the bearing sticks or has excessive resistance, replace it.

Secondary Shaft


Note

- If the shaft gear is replaced, adjust the bearing preload adjustment. (Refer to page J2-56.)


1. Inspect the shaft gear runout.

Maximum runout: 0.015mm (0.001 in)


2. Inspect the gear teeth for damage, wear, and cracks.




96EQJ2-077



03U0J1-062



96EQJ2-078



96EQJ2-079

1st Gear and 2nd Gear

1. Measure the clearance between the shaft gear and the gear.

Oil Clearance

mm (in)

	Shaft (Outer dia.)	Gear (Inner dia.)	Oil clearance
1st	39.445—39.470 (1.553—1.554)	39.500—39.525 (1.555—1.556)	0.03—0.08 (0.001—0.003)
2nd	34.945—34.970 (1.376—1.377)	35.000—35.025 (1.378—1.379)	

2. Inspect the synchronizer cones for wear.
3. Inspect the gear teeth for damage, wear, and cracks.

Clutch Hub Assembly

1. Inspect the clutch hub sleeve and hub operation.
2. Inspect the gear teeth for damage, wear, and cracks.
3. Inspect the synchronizer keys for damage, wear, and cracks.

4. Measure the clearance between the hub sleeve and the shift fork.

Clearance

mm (in)


	Standard	Maximum
1st/2nd	0.10—0.40 (0.004—0.016)	0.9 (0.035)
3rd/4th	0.10—0.40 (0.004—0.016)	0.9 (0.035)
5th/Rev.	0.10—0.40 (0.004—0.016)	0.9 (0.035)

ASSEMBLY


Precaution

1. All O-rings and gaskets must be replaced with the new ones included in the overhaul kit.
2. Verify that all parts are completely clean before assembly.
3. Assemble parts within 10 minutes after applying sealant.
Allow all sealant to cure at least 30 minutes after assembly before filling the transaxle with transaxle oil.
4. The bearing outer race and bearing inner race must be replaced as a unit.


03U0J1-063




96E0J2-080



96E0J2-081



03U0J1-066



96E0J2-082

J2-46

Clutch hub assembly

Note

- Synchronizer ring diameters are as follows.

mm (in)

1st and 2nd	67.7 (2.665)
3rd and 4th	67.7 (2.665)
5th/Reverse	55.7 (2.193)

- Synchronizer key dimensions are as follows.

mm (in)


	①	②	③
1st/2nd	19.00 (0.748)	4.25 (0.167)	5.00 (0.197)
3rd/4th	17.00 (0.669)	4.25 (0.167)	5.00 (0.197)
5th/Reverse	17.00 (0.669)	4.25 (0.167)	5.00 (0.197)

1. Install the synchronizer key springs in the clutch hub with the hooks in the grooves to hold the three synchronizer keys in place.

2. Align the synchronizer ring grooves with the synchronizer keys during assembly.


Secondary Shaft Assembly

1. Assemble in the order shown in the figure, referring to **Assembly Note**.



96EQJ2-083

- | | |
|---|--|
| 1. Inner cone | 12. Clutch hub assembly (1st/2nd)
Assembly Note..... page J2-48 |
| 2. Double cone | 13. Retaining ring |
| 3. Synchronizer ring | 14. Double cone assembly
Assembly Note..... page J2-48 |
| 4. Clutch hub (1st/2nd) | 15. 2nd gear
Assembly Note..... page J2-48 |
| 5. Synchronizer key | 16. 3rd gear
Assembly Note..... page J2-48 |
| 6. Clutch hub sleeve (1st/2nd) | 17. Retaining ring |
| 7. Synchronizer key spring | 18. 4th gear
Assembly Note..... page J2-48 |
| 8. Secondary shaft | 19. Bearing inner race
Assembly Note..... page J2-48 |
| 9. Bearing inner race
Assembly Note..... page J2-48 | |
| 10. 1st gear | |
| 11. Double cone assembly
Assembly Note..... page J2-48 | |




Assembly note

Bearing inner race (Secondary shaft end)


1. Install the new bearing inner race with the SST.

Press to 19,620 N (2,000 kg, 4,400 lb)




1st gear, double cone assembly and clutch hub assembly (1st/2nd)

1. Press the 1st gear, double cone assembly and clutch hub assembly (1st/2nd) onto the secondary shaft gear with the SST.




Double cone assembly, 2nd gear, and secondary 3rd gear

1. Press the double cone assembly, 2nd gear, and 3rd gear to the secondary shaft gear with the SST.



4th gear and bearing inner race

1. Press the 4th gear and bearing inner race onto the secondary shaft gear with the SST.




2. Measure the clearance between the 2nd gear and 3rd gear.

Clearance: 0.175—0.455mm (0.0069—0.0179 in)
Maximum: 0.505mm (0.0199 in)

TRANSAXLE

J2




96E0J2-089

3. Measure the clearance between the 1st gear and differential drive gear.

Clearance: 0.05—0.28mm (0.002—0.011 in)
Maximum: 0.33mm (0.0130 in)

4. If not as specified, reassemble the secondary shaft assembly.




96E0J2-092

3rd gear, synchronizer ring (3rd), and clutch hub assembly (3rd/4th)

Apply transaxle oil to the bore of 3rd gear

1. Turn the primary shaft over and press on the synchronizer ring (3rd), and clutch hub assembly (3rd/4th).

Press to 19,620 N (2,000 kg, 4,400 lb)



96E0J2-093


Synchronizer ring (3rd) and bearing

1. Install the synchronizer ring (3rd) and bearing.


Press to 19,620 N (2,000 kg, 4,400 lb)

3. Measure the clearance between the 3rd gear and 3rd gear.

Clearance: 0.05—0.20mm (0.002—0.008 in)
Maximum: 0.25mm (0.010 in)



96E0J2-094



96E0J2-095

Clutch hub assembly (3rd/4th)


1. Assemble the clutch hub assembly (3rd/4th).

2. Measure the clearance between the 3rd gear and 3rd gear.

Clearance: 0.05—0.20mm (0.002—0.008 in)
Maximum: 0.25mm (0.010 in)


Primary Shaft Assembly

1. Assemble in the order shown in the figure, referring to **Assembly Note**.



96EOJ2-090

- | | |
|----------------------------------|-----------------------------------|
| 1. Clutch hub (3rd/4th) | 9. Clutch hub assembly (3rd/4th) |
| 2. Synchronizer key | Assembly Note..... page J2-51 |
| 3. Clutch hub sleeve (3rd/4th) | 10. Retaining ring |
| 4. Synchronizer key spring | 11. Synchronizer ring |
| 5. Primary shaft | Assembly Note..... page J2-51 |
| 6. Bearing inner race (1st gear) | 12. 4th gear |
| Assembly Note..... page J2-51 | Assembly Note..... page J2-51 |
| 7. 3rd gear | 13. Bearing inner race (4th gear) |
| Assembly Note..... page J2-51 | Assembly Note..... page J2-51 |
| 8. Synchronizer ring | |
| Assembly Note..... page J2-51 | |




96E0J2-091

Assembly note

Bearing inner race (1st gear)

1. Press on the new bearing inner race with the SST.

Press to 19,620 N (2,000 kg, 4,400 lb)



96E0J2-092


3rd gear, synchronizer ring (3rd), and clutch hub assembly (3rd/4th)

Caution

- Apply transaxle oil to the bore of 3rd gear.

1. Turn the primary shaft over and press on the 3rd gear, synchronizer ring (3rd), and clutch hub assembly (3rd/4th).

Press to 19,620 N (2,000 kg, 4,400 lb)




96E0J2-093

Synchronizer ring (4th), 4th gear, and bearing

1. Install the retaining ring.
2. Press on the synchronizer ring (4th), 4th gear, and ball bearing.


Press to 19,620 N (2,000 kg, 4,400 lb)



96E0J2-094

3. Measure the clearance between the 3rd gear and 2nd gear.

Clearance: 0.05—0.20mm (0.002—0.008 in)
Maximum: 0.25mm (0.010 in)



96E0J2-095


4. Measure the clearance between the 4th gear and bearing inner race.

Clearance: 0.17—0.37mm (0.007—0.015 in)
Maximum: 0.42mm (0.017 in)

5. If not as specified, reassemble the primary shaft assembly.


Clutch Housing and Transaxle Case Components

1. Select the adjustment shim(s), referring to **Bearing Preload Adjustment**.
2. Assemble in the order shown in the figure, referring to **Assembly Note**.
3. Verify that the bearing preload is as specified after assembly, referring to **Bearing Preload**.




- | | |
|-------------------------------------|-------------------------------|
| 1. Clutch housing | 26. Bolt |
| 2. Seal plate and seal rubber | 27. Baffle |
| 3. Oil seal | 28. Magnet |
| Assembly Note..... page J2-62 | 29. Plug |
| 4. Oil seal | 30. Ventilator cover |
| Assembly Note..... page J2-62 | 31. Dust cover |
| 5. Plug | 32. Transaxle case |
| 6. Pivot | 33. Oil seal |
| 7. Spring | 34. Select lever |
| 8. Base plate assembly | 35. Inner select lever |
| 9. Oil seal | 36. Adjustment shim |
| 10. Select lever | 37. Bearing outer race |
| 11. Inner shift lever | Assembly Note..... page J2-62 |
| 12. Crank lever | 38. Adjustment shim |
| 13. Crank lever shaft | 39. Bearing outer race |
| 14. Oil seal | Assembly Note..... page J2-62 |
| 15. Bearing outer race | 40. Oil seal |
| Assembly Note..... page J2-62 | Assembly Note..... page J2-62 |
| 16. Bearing outer race | 41. Adjustment shim |
| Assembly Note..... page J2-62 | 42. Diaphragm spring |
| 17. Funnel | Assembly Note..... page J2-62 |
| 18. Bearing outer race | 43. Bearing outer race |
| 19. Oil seal | 44. Adjustment shim |
| 20. Bearing outer race | 45. Diaphragm spring |
| 21. Reverse lever support | Assembly Note..... page J2-62 |
| 22. Lever set spring and steel ball | 46. Bearing outer race |
| 23. Baffle | 47. Oil passage |
| 24. Bleeder | 48. Plug |
| 25. Bleeder dust boot and bleeder | |


96EQJ2-097



03U0J3-129



03U0J3-130



03U0J3-131

Idler gear adjustment shim selection

Note

- Measure at three locations and average the reading.

1. Place a straightedge on the transaxle case.
2. Measure the depth on the bearing outer race bore.

3. Set the idler gear assembly into the clutch housing.
4. Turn the idler gear assembly to seat the bearing.
5. Install the bearing outer race to the idler gear assembly.

6. Measure from the top of the bearing outer race to the clutch housing.

Adjust shim thickness	mm (in)
0.10 (0.003)	0.20 (0.008)
0.25 (0.010)	0.30 (0.012)
0.35 (0.014)	0.40 (0.016)
0.45 (0.018)	0.50 (0.020)
0.55 (0.022)	0.60 (0.024)
0.65 (0.026)	0.70 (0.028)
0.75 (0.030)	0.80 (0.032)
0.85 (0.034)	0.90 (0.035)
0.95 (0.037)	1.00 (0.039)
1.05 (0.041)	1.10 (0.043)
1.15 (0.045)	1.20 (0.047)

03U0J3-132

Caution

- The number of shims used must not exceed two.

7. Select the shim as follows.
- Subtract the bearing height (Step 6) from the depth of the bearing bore (Step 2).
 - Add 0.17mm (0.0067 in) to (a).
 - Add 0.22mm (0.0087 in) to (a).
 - Select the shim in the range between (b) and (c) from the table.

Example:

Depth of bearing bore: 52.00mm (2.0472 in)

Bearing height: 51.50mm (2.0276 in)

(a) 52.00mm (2.0472 in) - 51.50mm (2.0276 in)
= 0.50mm (0.0196 in)

(b) 0.50mm (0.0196 in) + 0.17mm (0.0067 in)
= 0.67mm (0.0263 in)

(c) 0.50mm (0.0196 in) + 0.22mm (0.0087 in)
= 0.72mm (0.0283 in)

(d) Select the 0.70mm (0.0276 in) shim.


96E0J2-098

J2


TRANSAXLE


Bearing preload adjustment

Adjust the bearing preload of the primary shaft, secondary shaft, and front and center differential by selecting and installing the proper adjustment shim(s).




96E0J2-099







96EQJ2-100




96EQJ2-101



96EQJ2-102



96EQJ2-103



03U0J2-072

Primary and secondary shaft gear

1. Install the primary and secondary shaft bearing outer races into the transaxle case (shims and diaphragm spring removed).
2. Mount the clutch housing onto the transaxle hanger.

3. Set the outer races into the **SST**.

Note

- Turn the selector to eliminate the gap indicated by the arrow in the figure.


4. Set the **SST** (selector) in place.
5. Set the primary and secondary shaft gear assemblies onto the **SST** (selector).

6. Set the **SST** (collars) between the transaxle case and the clutch housing, and install the **SST** (bolts), and tighten to the specified torque.


Tightening torque:

37–52 N·m (3.8–5.3 m·kg, 27–38 ft·lb)

7. To seat the bearings, mount the **SST** (bars) on parts (A) and (B) of the selector, and turn the selector so the gaps are widened. Then turn the **SST** in the reverse direction until the gaps are eliminated.




96EQJ2-104



96EQJ2-105

Thickness	mm	(in)
0.20	0.008	
0.25	0.010	
0.30	0.012	
0.35	0.014	
0.40	0.016	
0.45	0.018	
0.50	0.020	
0.55	0.022	
0.60	0.024	
0.65	0.026	
0.70	0.028	

96EQJ2-106



96EQJ2-107

Note

- Make sure that each shaft turns smoothly.

8. Manually expand the **SST** (selector) for both shafts until the **SST** (selector) no longer turns.

Note

- Measure the gap around the entire circumference of the **SST** (selector).

9. Measure the gap of the **SST** (selector) for both gears.

10. Take the maximum reading and determine the shim to be used as follows:

Note

- Use a maximum of two shims.

< Primary shaft adjustment shim >

- Subtract the diaphragm spring thickness (0.70mm, 0.0276 in) from the gap determined in Step 9.
- Select the closest thinner shim from the table.

Example

$$1.22\text{mm (0.0480 in)} - 0.70\text{mm (0.0276 in)} \\ = 0.52\text{mm (0.0204 in)} \\ \text{Shim: } 0.50\text{mm (0.020 in)}$$


< Secondary shaft adjustment shim >

- Subtract the diaphragm spring thickness (0.70mm, 0.0276 in) from the gap determined in Step 9.
- Select the closest thicker shim from the table.


Example

$$1.22\text{mm (0.0480 in)} - 0.70\text{mm (0.0276 in)} \\ = 0.52\text{mm (0.0204 in)} \\ \text{Shim: } 0.55\text{mm (0.022 in)}$$


11. Remove the **SST** (bolts and collars) and then remove the transaxle case, shaft gears and **SST** (selector).
12. Remove the bearing outer races for both shafts from the transaxle case.




96EQJ2-108




96EQJ2-109



96EQJ2-110



96EQJ2-111



96EQJ2-112

Front and center differential

1. Install the bearing outer race with the **SST**.

1. Install the front and center differential and bearing outer race into the clutch housing.
2. Set the **SST** (selector) in place.

3. Set the **SST** (collars) between the transaxle case and the clutch housing, and install the **SST** (bolts), and tighten to the specified torque.


Tightening torque:
37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

4. To seat the bearings turn the **SST** (bar) so the gap is widened.

5. Insert the **SST** (preload adaptor).

6. Expand the **SST** (selector) until the specified preload is obtained.


Preload:
2.9—3.9 N·m (30—40 cm·kg, 26—35 in·lb)




96E0J2-113

Thickness	mm (in)
0.10 (0.004)	0.70 (0.028)
0.20 (0.008)	0.75 (0.030)
0.25 (0.010)	0.80 (0.031)
0.30 (0.012)	0.85 (0.033)
0.35 (0.014)	0.90 (0.035)
0.40 (0.016)	0.95 (0.037)
0.45 (0.018)	1.00 (0.039)
0.50 (0.020)	1.05 (0.041)
0.55 (0.022)	1.10 (0.043)
0.60 (0.024)	1.15 (0.045)
0.65 (0.026)	1.20 (0.047)


96E0J2-114



96E0J2-115



96E0J2-116



96E0J2-117

Note

- Measure the gap around the entire circumference of the selector.

7. Measure the gap in the **SST** (selector).

Note

- Use a maximum of two shims.

8. Select an appropriate adjustment shim to be used for the differential by referring to the table and selecting the closest thicker shim to the largest measured value of the gap in the **SST** (selector).

Example: 0.54mm (0.021 in)

The closest thicker shim to 0.54mm (0.021 in) is 0.6mm (0.014 in).

9. Remove the **SST** (bolts and collars) and then remove the transaxle case.

10. Remove the **SST** (selector), bearing outer race and front and center differential.

Bearing preload

Verify that the shaft gears and differential bearing preload is correct.

Note


- Verify that the correct adjustment shims were selected.
- If the bearing preload is not within specification, readjust.

1. Set the primary shaft gear and the differential into the clutch housing.

2. Install the selected shim and bearing outer race for the front and center differentials with the **SST**.

TRANSAXLE

J2




96EQJ2-118

3. Install the selected shim, diaphragm spring and bearing outer race for the primary shaft.
4. Install the transaxle case, and tighten to the specified torque.

Tightening torque:


37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)



96EQJ2-119

5. Install the **SST** through the driveshaft opening.
6. Hook a spring scale to the attachment and measure the preload.

Preload: 2.9—3.9 N·m (30—40 cm·kg, 26—35 in·lb)




96EQJ2-120

7. Remove the **SST**.
8. With the transaxle facing in the direction shown in the figure, install the **SST** to the primary shaft gear.
9. Measure the preload.

Preload:

0.1—0.25 N·m (1.0—2.5 cm·kg, 0.87—2.18 in·lb)



96EQJ2-121

10. Remove the **SST**, transaxle case, primary shaft gear and differential.
11. Install the secondary shaft gear and transaxle case, then tighten to the specified torque.

Tightening torque:

37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)



96EQJ2-122

12. Measure the secondary shaft preload with the **SST**.

Preload:

0.29—0.42 N·m (3.0—4.3 cm·kg, 2.6—3.7 in·lb)

TRANSAXLE




96EOJ2-123

Assembly note
Oil seal (Front and center differential)

Caution
• Apply transaxle oil to the outer circumference of the oil seal.

1. Install the new oil seal with the **SST**.




96EOJ2-124

Oil seal (Center differential lock shift rod)

Caution
• Apply transaxle oil to the oil seal lip.


1. Install the new oil seal with a suitable pipe.



96EOJ2-125

Bearing outer race (Idler gear)


1. Install the new oil seal with the **SST**.



96EOJ2-126

Bearing outer race (Front and center differential)

1. Install the new oil seal with **SST**.



96EOJ2-127


Diaphragm spring

1. Install the diaphragm spring as shown in the figure.

TRANSAXLE

J2

MEMO




J2

TRANSAXLE

5th/Reverse Gear and Housing Parts

1. Assemble in the order shown in the figure, referring to **Assembly Note**.




N·m (m·kg, ft·lb)

96EQJ2-128

- | | |
|--|---|
| 1. Control rod | 27. Neutral switch |
| 2. Control lever | 28. Bolt |
| 3. Shift fork (1st/2nd) | 29. Bolt |
| 4. Interlock sleeve | 30. Steel ball, spring, bolt |
| 5. Shift fork (3rd/4th) | 31. Steel ball, spring, bolt |
| 6. Clutch hub | 32. Reverse idler gear shaft |
| 7. Synchronizer key | 33. Reverse idler gear support |
| 8. Clutch hub sleeve | 34. Reverse idler gear |
| 9. Synchronizer key spring | 35. Reverse idler gear assembly |
| 10. Speedometer driven gear case | Assembly Note..... page J2-66 |
| 11. Oil seal | 36. Transaxle case assembly |
| Assembly Note..... page J2-66 | 37. Interlock bolt |
| 12. Speedometer driven gear | 38. Lock bolt |
| Assembly Note..... page J2-66 | 39. Back-up light switch |
| 13. O-ring | 40. Gear sleeve |
| 14. Clutch housing assembly | 41. Secondary 5th gear |
| 15. Transfer carrier assembly | 42. Primary 5th gear |
| 16. Dynamic damper assembly | 43. Synchronizer ring (5th) |
| 17. Control end | 44. Clutch hub assembly (5th/Reverse) |
| 18. Shift gate | 45. 5th/Reverse shift fork |
| 19. Center differential lock shift fork assembly | 46. Secondary reverse synchronizer gear |
| 20. Idler gear assembly | 47. Synchronizer ring (Reverse) |
| Assembly Note..... page J2-66 | 48. Primary reverse synchronizer gear |
| 21. Front and center differential assembly | 49. Locknut (Secondary shaft) |
| Assembly Note..... page J2-66 | Assembly Note..... page J2-67 |
| 22. Shift fork and shift rod assembly | 50. Spacer |
| 23. Secondary shaft assembly | 51. Locknut (Primary shaft) |
| Assembly Note..... page J2-66 | Assembly Note..... page J2-67 |
| 24. Primary shaft assembly | 52. Rear cover |
| Assembly Note..... page J2-66 | 53. Speedometer driven gear assembly |
| 25. Roll pin | 54. Clutch release fork |
| 26. 5th/Reverse shift rod | 55. Clutch release bearing |

96EQJ2-129




96E0J2-130

Assembly note

Oil seal (Speedometer driven gear assembly)

1. Install the new oil seal with a suitable pipe.


Pipe diameter: 16mm (0.630 in)



96E0J2-131

Speedometer driven gear


1. Install the speedometer driven gear.
2. Install the new roll pin as shown in the figure.



96E0J2-132


Primary shaft assembly, secondary shaft assembly, front and center differential assembly and idler gear assembly

1. Tilt the transaxle toward the transfer carrier side.
2. Install the front and center differential assembly, center differential lock shift fork and idler gear.
3. Lift the front and center differential and idler gear a few centimeters (inches).



96E0J2-133


4. Install the primary and secondary shaft assembly, and verify that the gears are meshed.




96E0J2-134

Reverse idler gear shaft

1. Set the reverse idler gear shaft in the direction shown.



03U0J2-097



96E0J2-135

Locknut

1. Shift to 1st gear.
2. Lock the primary shaft with the **SST**.
3. Tighten new locknuts on the primary and secondary shafts.

Tightening torque:

128—196 N·m (13.0—20.0 m·kg, 94—145 ft·lb)

4. Stake the locknuts.
5. Measure the 5th gear thrust clearance with a dial indicator.

Clearance: 0.10—0.22mm (0.004—0.009 in)

Maximum: 0.27mm (0.011 in)


6. If not as specified, reassemble the transaxle.

J2

TRANSAXLE


INSTALLATION

1. Raise the vehicle and support it with safety stands.
2. Install in the order shown in the figure, referring to **Installation Note**.
3. Add the specified amount of the specified transaxle oil. (Refer to page J2-22.)
4. Warm up the engine and transaxle, and inspect for oil leakage and transaxle operation.



- | | |
|---|----------------------------|
| 1. Transaxle
Installation Note below | 15. Splash shield |
| 2. Frame
Installation Note below | 16. Wheel and tire |
| 3. Engine mount No.4 | 17. Connectors |
| 4. Engine mount No.2 | 18. Speedometer cable |
| 5. Clutch release cylinder | 19. Select cable |
| 6. Starter | 20. Shift cable |
| 7. Bracket | 21. Bracket |
| 8. Jointshaft | 22. Air cleaner |
| 9. Driveshaft
Installation Note page J2-70 | 23. Air hose |
| 10. Stabilizer
Installation Note page J2-70 | 24. Hose |
| 11. Tie-rod end
Installation Note page J2-70 | 25. Battery carrier |
| 12. Exhaust pipe | 26. Bracket |
| 13. Rear member | 27. Relay |
| 14. Propeller shaft
Installation Note page J2-71 | 28. Main fuse block |
| | 29. Battery tray |
| | 30. Battery |
| | 31. Battery clamp |
| | 32. Negative battery cable |


96E0J2-137



96E0J2-138

Installation Note
Transaxle

1. Set the transaxle on a jack and lift it into place.
2. Install the transaxle.




96E0J2-139

Frame

1. Install the bolts and nuts as shown.

Tightening torque:

- Ⓐ 36—54 N·m (3.7—5.5 m·kg, 27—40 ft·lb)
- Ⓑ 83—117 N·m (8.5—11.9 m·kg, 61—86 ft·lb)
- Ⓒ 93—131 N·m (9.5—13.4 m·kg, 69—97 ft·lb)




03U0J1-128

2. Tighten engine mount No.4 nuts.

Tightening torque:
64—89 N·m (6.5—9.1 m·kg, 47—66 ft·lb)

3. Remove the **SST** (Engine support).



03U0J1-123

Driveshaft


Caution

- Verify that the oil seal is not damaged.
- Do not damage the oil seal

1. Insert the clip with the end-gap at the top of the groove.
2. Apply transaxle oil around the oil seal lip. Install the driveshaft.
3. Verify that the driveshaft is correctly seated by pulling on the shaft.

4. Connect the lower arm to the knuckle and tighten the clinch bolt.

Tightening torque:
43—59 N·m (4.4—6.0 m·kg, 32—43 ft·lb)




03U0J1-124

Stabilizer

1. Tighten the nut until the specified amount of thread is exposed at the end of the bolt.

Dimension A: 17—19mm (0.67—0.75 in)




96E0J2-140

Tie-rod end


1. Install the tie-rod end and tighten the locknut.

Tightening torque:
42—57 N·m (4.3—5.8 m·kg, 31—42 ft·lb)

2. Secure the locknut with a new cotter pin.




96E0J2-141



96E0J2-142

Propeller shaft


1. Align the marks, and install the front and rear propeller shaft.



96E0J2-143

Shift cable

1. Install the shift cables to the brackets, and secure them by the clips.
2. Connect the shift cables to the transaxle control lever, and install the washers and pins.




96E0J2-144

Ground

1. Install the ground to the transaxle.

Tightening torque:

7.8—11 N·m (80—110 cm·kg, 69—95 in·lb)



96E0J2-145

Speedometer cable


1. Connect the speedometer cable to the speedometer driven gear.

J2

TRANSFER UNIT








TRANSFER UNIT

PREPARATION SST

49 G026 103 Support block 	For disassembly of idler gear	49 0107 680A Stand, engine 	For disassembly and assembly of differential
49 M005 561 Hanger, differential carrier 	For disassembly and assembly of differential	49 S120 710 Holder, coupling flange 	For removal and installation of companion flange
49 0710 520 Puller, bearing 	For removal of bearing	49 G017 1A0 Remover set, bearing 	For removal of bearing
49 F401 366A Plate (Part of 49 G017 1A0) 	For removal of bearing	49 B027 003 Attachment M 	For removal of bearing
49 F401 330B Installer set, bearing 	For installation of bearing	49 F401 331 Body (Part of 49 F401 330B) 	For installation of bearing inner race
49 F401 337A Attachment C (Part of 49 F401 330B) 	For installation of bearing inner race	49 F027 0A1 Installer set, bearing 	For removal of bearing
49 H028 2A0 Rubber bush replacer 	For installation of bearing	49 H028 202 Block L (Part of 49 H028 2A0) 	For installation of bearing
49 F027 003 Handle (Part of 49 F027 0A1) 	For installation of bearing	49 F027 005 Attachment for $\phi 62$ bearing (Part of 49 F027 0A1) 	For installation of bearing

TRANSFER UNIT

J2

<p>49 8531 565 Model, pinion</p> 	<p>For adjustment of pinion height</p>	<p>49 8531 567 Collar A (Part of 49 8531 565)</p> 	<p>For adjustment of pinion height</p>
<p>49 F027 0A0 Gauge set, pinion height adjustment</p> 	<p>For adjustment of pinion height</p>	<p>49 0660 555 Block, gauge (Part of 49 F027 0A0)</p> 	<p>For adjustment of pinion height</p>
<p>49 0727 570 Gauge body, pinion height (Part of 49 F027 0A0)</p> 	<p>For adjustment of pinion height</p>	<p>49 F401 336B Attachment B (Part of 49 F401 330B)</p> 	<p>For installation of bearing inner race</p>
<p>49 0259 720 Wrench, differential side bearing adjusting nut</p> 	<p>For adjustment of drive pinion and ring gear backlash</p>	<p>49 W023 785 Installer, boot</p> 	<p>For installation of bearing</p>
<p>49 G030 338 Attachment E</p> 	<p>For installation of bearing</p>	<p>49 B027 001 Holder, diff. side gear</p> 	<p>For holding side gear</p>
<p>49 G028 2A0 Replacer, lower arm bushing</p> 	<p>For installation of thrust washer</p>	<p>49 G028 201 Block, support (Part of 49 G028 2A0)</p> 	<p>For installation of thrust washer</p>
<p>49 U027 003 Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>49 0839 425C Puller set, bearing</p> 	<p>For removal of companion flange</p>

96E0J2-146

DISASSEMBLY


Precaution

1. Clean the removed parts (except sealed bearings) and all sealing surfaces with cleaning solvent, and dry with compressed air. Clean out all holes and passages with compressed air, and check that there are no obstructions.
2. Wear eye protection when using compressed air to clean components.

96E0J2-147

Front and Center Differential Assembly


1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.
3. Inspect all bearings for damage and rough rotation and replace as necessary.



96E0J2-148

- | | |
|--|---|
| 1. Center differential lock shift fork | 15. Thrust washer |
| 2. Center differential lock shift rod | 16. Gear case needle bearing |
| 3. Bearing inner race
(Differential lock gear sleeve)
Removal Note below | 17. Sun gear
Inspect gear teeth for wear and cracks |
| 4. Differential lock gear sleeve | 18. Gear case needle bearing |
| 5. Differential lock hub
Inspect for damage and wear | 19. Planetary carrier
Inspect gear for wear, cracks and rough rotation |
| 6. Gear case needle bearing | 20. Gear case needle bearing |
| 7. Ring gear case
Inspect gear teeth for wear and cracks | 21. Differential gear case sleeve
Removal Note page J2-76 |
| 8. Gear case needle bearing | 22. Pinion shaft |
| 9. Differential lock thrust washer | 23. Washer |
| 10. Front differential gear case | 24. Pinion gear
Inspect gear for wear and cracks |
| 11. Gear case needle bearing | 25. Side gear
Inspect gear for wear and cracks |
| 12. Gear case needle bearing | 26. Washer |
| 13. Bearing inner race (Viscous coupling)
Removal Note below | |
| 14. Viscous coupling | |

96E0J2-149



96E0J2-150


Disassembly note

Bearing inner race (Differential lock gear sleeve side)

Caution

- Hold the front differential gear case with one hand so that it does not fall.

1. Remove the bearing inner race.




96E0J2-151

Bearing inner race (Viscous coupling)

Caution

- Hold the front differential gear case with one hand so that it does not fall.

1. Remove the bearing inner race.



96E0J2-152


Differential gear case sleeve

Caution

- Hold the front differential gear case with one hand so that it does not fall.


1. Remove the differential gear case sleeve.

96E0J2-148




Transfer Carrier Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts and repair or replace as necessary.



96E0J2-153

- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Bearing inner race (Joint sleeve)
Removal Note page J2-78 2. Joint sleeve 3. O-ring 4. Bearing inner race (Idler gear) 5. Idler gear shaft 6. Lock plate and bolt 7. Bolt 8. Bearing cap 9. Adjusting screw 10. Bearing outer race
Removal Note page J2-78 11. Differential gear
Inspect gear for wear and cracks 12. Bearing inner race
Inspect for damage and rough rotation
Removal Note page J2-79 13. Locknut
Removal Note page J2-79 | <ol style="list-style-type: none"> 14. Washer 15. Companion flange
Removal Note page J2-79
Inspect splines for damage and wear 16. Oil seal 17. Bearing inner race (Companion flange)
Inspect for damage and rough rotation 18. Collapsible spacer 19. Bearing inner race (Drive pinion)
Removal Note page J2-79
Inspect for damage and rough rotation 20. Spacer 21. Drive pinion
Removal Note page J2-79
Inspect gear for damage and cracks
Inspect splines for damage and wear 22. Bearing outer race (Drive pinion) 23. Bearing outer race (Companion flange) |
|---|---|




96E0J2-154

Disassembly note
Bearing inner race (Idler gear)

1. Clamp the idler gear in a vise.
2. Remove the bearing inner race.


Pipe diameter: 16mm (0.630 in)



96E0J2-155

Bearing inner race (Joint sleeve)


1. Remove the bearing inner race with the **SST**.



96E0J2-156

Transfer carrier


1. Assemble the **SST** and mount the transfer carrier.



96E0J2-157

Cap

1. Mark one bearing cap and the carrier for proper reassembly.
2. Remove the bolts, lock plates and bearing caps.




96E0J2-158

Bearing outer race (Side bearing)

Note

- For proper reassembly, identify the bearing outer races.


1. Remove the bearing outer races.



96E0J2-159

Locknut


1. Remove the locknut with the **SST**.



96E0J2-160

Companion flange


1. Remove the companion flange with the **SST**.



96E0J2-161

Drive pinion

1. Push the drive pinion out by attaching a miscellaneous locknut to the drive pinion, then tapping it with a brass hammer.




96E0J2-162

Bearing inner race (Drive pinion)

Caution

- Support the drive pinion by hand so that it does not fall.

1. Remove the bearing with the **SST**.
2. Remove the spacer.



96E0J2-163

Bearing inner race (Side bearing)

Note

- Do not disassemble the bearing inner race if not necessary.
- For proper reassembly, identify the bearing inner race.

1. Remove the bearing inner race with the **SST**.


J2

TRANSFER UNIT

INSPECTION

Inspect all parts and repair or replace as necessary.

96E0J2-164




96E0J2-165

Differential Lock Gear Sleeve

1. Measure the clearance between the gear sleeve and the shift fork.

Standard clearance: 0.15—0.50mm (0.006—0.020 in)
Maximum: 1.0mm (0.039 in)



96E0J2-166

2. Inspect for smooth gear sleeve and hub operation.


ASSEMBLY

Precaution

1. Verify that all parts are completely clean before assembly.
2. Before assembly, apply ATF to all rotating parts and sliding parts.
3. When replacing, a bearing outer race and bearing inner race must be replaced as a unit.


Transfer Carrier Assembly

1. Assemble in the order shown in the figure, referring to **Assembly Note**.




96E0J2-167


- | | |
|--|--|
| <ol style="list-style-type: none"> 1. Bearing outer race (Companion flange)
Assembly Note..... page J2-82 2. Bearing outer race (Drive pinion)
Assembly Note..... page J2-82 3. Spacer
Assembly Note..... page J2-82 4. Bearing inner race (Drive pinion)
Assembly Note..... page J2-83 5. Collapsible spacer 6. Drive pinion
Assembly Note..... page J2-84 7. Bearing inner race (Companion flange) 8. Oil seal 9. Companion flange 10. Washer 11. Locknut | <ol style="list-style-type: none"> 12. Bearing inner race (Differential gear)
Assembly Note..... page J2-82 13. Differential gear 14. Bearing outer race 15. Adjusting screw
Assembly Note..... page J2-85 16. Bearing cap
Assembly Note..... page J2-86 17. Bolt 18. Lock plate and bolt 19. Bearing inner race (Joint sleeve)
Assembly Note..... page J2-87 20. Joint sleeve 21. O-ring 22. Idler gear 23. Bearing inner race (Idler gear)
Assembly Note..... page J2-87 |
|--|--|




96EQJ2-168



96EQJ2-169



96EQJ2-170



96EQJ2-171

Assembly note

Bearing inner race (Differential gear)

1. Install the bearing inner race with the **SST**.

Bearing outer race (Companion flange and drive pinion)

1. Install the bearing outer race with a brass drift.

Adjustment of pinion height

1. Adjust the drive pinion height as follows with the **SST**.

Note


- Use the spacer that was removed.

2. Assemble the spacer and bearing inner race (drive pinion) onto the **SST**.
3. Install the drive pinion model into the transfer carrier.


Note

- Use the nut which was removed.


4. Install the bearing inner race (companion flange), **SST**, companion flange, washer, and nut.
5. Tighten the nut to the extent that the companion flange can still be turned by hand.



96EQJ2-172




96EQJ2-173



96EQJ2-174

Mark	Thickness	Mark	Thickness
08	3.08mm (0.1213 in)	29	3.29mm (0.1295 in)
11	3.11mm (0.1224 in)	32	3.32mm (0.1307 in)
14	3.14mm (0.1236 in)	35	3.35mm (0.1319 in)
17	3.17mm (0.1248 in)	38	3.38mm (0.1331 in)
20	3.20mm (0.1260 in)	41	3.41mm (0.1343 in)
23	3.23mm (0.1271 in)	44	3.44mm (0.1354 in)
26	3.26mm (0.1283 in)	47	3.47mm (0.1366 in)

96EQJ2-175



96EQJ2-176

6. Place the **SST** on the surface plate and set the dial indicator to "Zero".

7. Set the **SST** atop the gauge block.

8. Place the feeler of the dial indicator so that it contacts where the side bearing is installed in the carrier, and measure the lowest position on the left and right sides.

9. Add the two (left and right) values obtained by the measurements taken in Step 7, and then divide the total by 2.

Specification: 0mm (0 in)

Note

- The spacer thicknesses are available in increments of 0.03mm (0.001 in). Select the spacer thickness that is closest to that necessary.


10. If not within specification, adjust the pinion height by selection of a spacer.

Bearing inner race (Drive pinion)


Note

- Install the spacer selected for the pinion height adjustment, being careful the direction of installation is correct.


1. Install the spacer onto the drive pinion.




96EOJ2-177




96EOJ2-178



96EOJ2-179



96EOJ2-180



96EOJ2-181

Note

- Press on until the force suddenly increases.

2. Press the bearing inner race on with the SST.

Adjustment of drive pinion preload

1. Install a new collapsible spacer.
2. Install the drive pinion assembly

3. Apply a light coat of grease to the end face of the companion flange.

Caution

- Do not install the oil seal.

4. Install the bearing inner race, companion flange and washer, and tighten the locknut.


Tightening torque:

118—180 N·m (12—18 m·kg, 87—130 ft·lb)


5. Turn the companion flange by hand to seat the bearings.
6. Measure the drive pinion preload. Adjust the preload by tightening the locknut and record the tightening torque.

Preload:


1.0—1.6 N·m (10—16 cm·kg, 8.7—13.9 in·lb)




96EOJ2-182




96EOJ2-183



96EOJ2-184



96EOJ2-185



96EOJ2-186

7. Remove the nut, washer, and companion flange.
8. Tap a new oil seal into the differential carrier with the **SST**.
9. Install the washer and companion flange, and tighten the locknut to the tightening torque record in Step 6.

Adjustment of backlash

1. Mount the differential gear assembly in the carrier.
2. Install the differential bearing caps making sure that the mark on the cap corresponds with the one on the carrier.
3. Loosely tighten the bearing cap bolts.
4. Mark the ring gear at four points at approx. **90°** intervals. Mount a dial indicator to the carrier so that the feeler comes into contact at a right angle with one of the ring gear teeth.
5. Turn both bearing adjusting screws equally with the **SST** until the backlash is within specifications.

Standard backlash:

0.09—0.11mm (0.0035—0.0043 in)


Note

- When adjusting the differential bearing preload, care must be taken not to affect the backlash of the drive pinion gear and ring gear.

6. After adjusting the backlash, tighten the adjusting screws equally until the distance between the pilot sections on the bearing caps is as specified.

Specification:

142.137—142.200mm (5.596—5.599 in)



96E0J2-187

7. Tighten the bearing cap bolts to the specified torque.


Tightening torque:

37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

8. Install and tighten the lock plates onto the bearing caps.

Tightening torque:


18—26 N·m (1.8—2.6 m·kg, 13—19 ft·lb)



96E0J2-188


Inspection and adjustment of tooth contact

1. Coat both surfaces of 6—8 teeth of the ring gear with a uniformly thin coat of red lead.
2. While moving the ring gear back and forth by hand, rotate the drive pinion several times and check the tooth contact.



63G07C-181

3. If the tooth contact is correct, wipe off the red lead.




96E0J2-189

4. If it is not correct, adjust the pinion height, and then adjust the backlash.

(1) Toe and flank contact


Replace the spacer with a thinner one to move the drive pinion outward.



96E0J2-190


(2) Heel and face contact

Replace the spacer with a thicker one bring the drive pinion inward.




Bearing inner race (Joint sleeve)

1. Install the bearing inner race with the SST.



Bearing inner race (Idler gear)

1. Install the bearing inner race with the SST.




J2

TRANSFER UNIT

Front and Center Differential Assembly

1. Assemble in the order shown in the figure, referring to **Assembly Note**.




TRANSFER UNIT


J2

- | | |
|---|--|
| 1. Washer | 14. Bearing inner race (Viscous coupling)
Assembly Note..... page J2-91 |
| 2. Side gear
Assembly Note..... page J2-89 | 15. Gear case needle bearing
Assembly Note..... page J2-91 |
| 3. Pinion gear
Assembly Note..... page J2-89 | 16. Gear case needle bearing |
| 4. Washer | 17. Front differential gear case |
| 5. Pinion shaft | 18. Differential lock thrust washer
Assembly Note..... page J2-92 |
| 6. Differential gear case sleeve
Assembly Note..... page J2-90 | 19. Gear case needle bearing |
| 7. Gear case needle bearing | 20. Ring gear case |
| 8. Planetary carrier | 21. Gear case needle bearing |
| 9. Gear case needle bearing | 22. Differential lock hub |
| 10. Sun gear | 23. Differential lock gear sleeve |
| 11. Gear case needle bearing | 24. Bearing inner race
(Differential lock gear sleeve)
Assembly Note..... page J2-92 |
| 12. Washer
Assembly Note..... page J2-90 | 25. Center differential lock shift rod |
| 13. Viscous coupling | 26. Center differential lock shift fork |

96EQJ2-194



96EQJ2-195



63G07C-141

Assembly note
Side gear and pinion gear

1. Install the side gears and washers, and fix them with the SST.


Note

- Do not install the washer at this time.
2. Install a pinion gear and turn it 180°.


J2-89

J2


TRANSFER UNIT




63G07C-142




63G07C-143



96E0J2-196



96E0J2-197



96E0J2-198

3. Install the other pinion gear and washer.
4. Turn the pinion gear and washer 150°.
5. Install the washer on opposite pinion gear.

6. Align the pinion shaft holes of the pinion gears with the differential gear case.

Differential gear case sleeve

1. Insert the pinion shaft
2. Install the differential gear case sleeve.

Adjustment of sun gear thrust clearance

1. Install the thickest new thrust washer (4.3mm, 0.17 in) with the **SST**.

2. Measure the sun gear thrust clearance as shown.

Standard clearance:


0.1—0.3mm (0.004—0.012 in)

TRANSFER UNIT


J2

Measured clearance mm (in)	Thrust washer mm (in)
0.9—1.1 (0.035—0.043)	3.5 (0.138)
0.7—0.9 (0.028—0.035)	3.7 (0.146)
0.5—0.7 (0.020—0.028)	3.9 (0.154)
0.3—0.5 (0.012—0.020)	4.1 (0.161)
0.1—0.3 (0.004—0.012)	4.3 (0.169)


96E0J2-199




96E0J2-200



96E0J2-201



96E0J2-202



96E0J2-203

- If the clearance is not within specification, select the thrust washer from the table.

Bearing inner race (Viscous coupling)

- Install the bearing inner race with the SST.

Adjustment of front differential gear case radial clearance

- Install the front differential gear case into the ring gear case.

Note

- Available gear case needle bearing part numbers.


Small GODO 27 519

Medium GODO 27 518


Large GODO 27 517

- Verify that the medium size gear case needle bearing can be installed.
- If not, install the small size gear case needle bearing.


- If the medium size gear case needle bearing can be installed, measure the clearance between the ring gear case and the needle bearing.




96E0J2-204



96E0J2-205



96E0J2-206



96E0J2-207

5. If the clearance exceeds **0.06mm (0.002 in)**, install the large size gear case needle bearing.

Adjustment of ring gear case thrust clearance

1. Install the gear case needle bearings and differential lock thrust washer.
2. Install the differential lock gear sleeve, differential lock hub and gear case needle bearing.
3. Measure the clearance between the differential lock hub and the gear case needle bearing.
If not within specification, select the proper differential lock thrust washer.

Standard clearance: 0.15—0.30mm (0.006—0.011 in)

Available washer thickness:

- 1.20mm (0.047 in)
- 1.35mm (0.053 in)
- 1.50mm (0.059 in)
- 1.65mm (0.065 in)
- 1.80mm (0.071 in)


Bearing inner race (Differential lock gear sleeve)

1. Install the bearing inner race with a press and the SST.

SHIFT MECHANISM

OVERHAUL

1. Disassemble in the order shown in the figure.
2. Inspect all parts and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




N·m (m·kg, ft·lb)

96E0J2-208

- | | |
|--|---|
| <ol style="list-style-type: none"> 1. Upper plate 2. Rear console 3. Shift lever knob 4. Front console 5. Side cover 6. Spring pin 7. Flat washer 8. Clip 9. Front duct | <ol style="list-style-type: none"> 10. Engine control unit 11. Shift lever assembly
Installation Note page J2-94 12. Rubber seat 13. Retainer 14. Select cable
Installation Note page J2-94 15. Shift cable |
|--|---|

J2

SHIFT MECHANISM



96E0J2-209


Assembly Note

Shift lever assembly

1. Install the rubber seat
2. Install the shift lever assembly.

Tightening torque:


16–23 N·m (1.6–2.3 m·kg, 12–17 ft·lb)



96E0J2-210

Clip


1. Install the select and shift cables and secure them with the clips.



96E0J2-211

Adjustment of select and shift cables

1. Verify that the gear position of the transaxle is in neutral.
2. Verify that the pin of the shift lever and the cable are aligned.
3. If not, loosen nuts (A), and turn the adjusting nut to align.



96E0J2-212

Pin

1. Install the select and shift cables and flat washers, and secure them with the spring pins.