

FRONT AND REAR AXLES

INDEX M- 2

FEATURES


OUTLINE M- 3
OUTLINE OF CONSTRUCTION M- 3
SPECIFICATIONS M- 3
REAR AXLE AND DIFFERENTIAL M- 4
REAR AXLE M- 4
DRIVESHAFT M- 5
VISCOUS LIMITED SLIP DIFFERENTIAL (VISCOUS L.S.D.) M- 6

SERVICE

SUPPLEMENTAL SERVICE INFORMATION.. M-10
TROUBLESHOOTING GUIDE..... M-10
REAR AXLE M-10
VISCOUS LIMITED SLIP DIFFERENTIAL M-10
REAR AXLE M-11
PREPARATION M-11
DISC BRAKE TYPE M-12
DRIVESHAFT M-17
JOINT SHAFT M-18
DOUBLE-OFFSET JOINT M-22
VISCOUS LIMITED SLIP DIFFERENTIAL M-26
PREPARATION M-26
DIFFERENTIAL OIL M-28
OIL SEAL (OUTPUT SHAFT) M-28
OPERATION INSPECTION M-30
VISCOUS LIMITED SLIP DIFFERENTIAL M-31

96E0MX-001

INDEX



OIL SPECIFICATION
 ABOVE -18°C (0°F): GL-5, SAE90
 BELOW -18°C (0°F): GL-5, SAE80W

96E0MX-002

- | | |
|--|---|
| <p>1. Rear axle
 Removal / Inspection /
 Installation page M-12
 Disassembly / Inspection /
 Assembly page M-13</p> <p>2. Driveshaft
 Inspection / Removal /
 Installation page M-17
 Disassembly / Inspection /
 Assembly page M-18</p> | <p>3. Joint shaft
 Preinspection page M-18
 Removal / Installation page M-18
 Overhaul page M-20</p> <p>4. Viscous limited slip differential
 Differential oil page M-28
 Oil seal (Output shaft) page M-28
 Operation inspection page M-30
 Removal / Installation page M-31
 Overhaul page M-33</p> |
|--|---|

OUTLINE

**OUTLINE OF CONSTRUCTION
(4WD model)**

- Double-offset joints, which feature low rotational fluctuation noise and excellent vibration resistance, are used for the differential side of front and rear driveshafts.
- The viscous limited slip differential (L.S.D.) is used to improve handling and performance.
- Angular type ball bearings are employed for the rear wheel bearings for improved durability and serviceability.

(2WD model)

- The construction of front and rear axle is the same as the previous model.
- The construction of driveshaft is the same as the previous model.
- Dust seal for joint shaft is redesigned to improve reliability.

96E0MX-003

SPECIFICATIONS (4WD model)

Engine/Transaxle Model		F2	
Item		G5MX-R	
Rear axle			
Wheel bearing axial play	Maximum mm (in)	0.05 (0.002)	
Rear differential			
Reduction gear		Hypoid gear	
Differential gear		Straight bevel gear	
Reduction ratio		3.909	
Number of teeth	Ring gear	43	
	Drive pinion gear	11	
Differential oil	Grade	API: GL-5	
	Viscosity	Above -18°C (0°F)	SAE 90
		Below -18°C (0°F)	SAE 80W
	Amount	liter (US qt, Imp qt)	0.65 (0.69, 0.57)
Driveshaft			
Joint type	Inside	Double-offset joint	
	Outside	Bell joint	
Length of shaft	Right mm (in)	691 (27.20)	
	Left mm (in)	661 (26.02)	
Shaft diameter	mm (in)	22 (0.86)	


96E0MX-004

M

REAR AXLE AND DIFFERENTIAL

REAR AXLE AND DIFFERENTIAL



REAR AXLE Wheel Bearings



96EOMX-005

The use of angular type wheel bearings allows setting of bearing preload by simply tightening the driveshaft nut to the specified torque, thus improving bearing durability and serviceability.

DRIVESHAFT




96E0MX-006

To transmit the power from the rear differential to the wheels, driveshafts, similar in design to the front driveshafts, are employed. As with the front driveshafts, bell joint is used at the wheel side and double-offset joint is used at the differential side.

M VISCOUS LIMITED SLIP DIFFERENTIAL (VISCOUS L.S.D.)

VISCOUS LIMITED SLIP DIFFERENTIAL (VISCOUS L.S.D.)



96E0MX-007



The newly designed viscous limited slip differential is made available for the 4WD model to improve handling, performance and serviceability, and to achieve reductions of vibration and noise. The viscous limited slip differential is a viscous coupling that takes advantage of resistance of a fluid to control operation of the differential.

The viscous limited slip differential is composed of the self-contained viscous coupling unit and the differential mechanism (side gears and pinion gears), common to other differentials.

VISCOUS LIMITED SLIP DIFFERENTIAL (VISCOUS L.S.D.)

M

CROSS-SECTIONAL VIEW




M


VISCOUS LIMITED SLIP DIFFERENTIAL (VISCOUS L.S.D.)

POWER FLOW

Right wheel speed higher (left turn or split-traction road)




97U0MX-513




VISCOUS LIMITED SLIP DIFFERENTIAL (VISCIOUS L.S.D.)

M

Left wheel speed higher (right turn or split-traction road)



97U0MX-514



M SUPPLEMENTAL SERVICE INFORMATION, TROUBLESHOOTING GUIDE

SUPPLEMENTAL SERVICE INFORMATION

- The following points in this section are changed in comparison with Workshop Manual (1163-10-87G).

Troubleshooting guide

- Rear axle
- Viscous limited slip differential

Rear axle

- Removal / Inspection / Installation
- Disassembly / Assembly

Driveshaft

- Inspection / Removal / Installation
- Disassembly / Inspection / Assembly

Viscous limited slip differential

- Removal / Installation
- Overhaul

Differential oil

- Inspection
- Replacement

96E0MX-008

TROUBLESHOOTING GUIDE

REAR AXLE

Problem	Possible Cause	Action	Page
Abnormal noise	Bent bearing housing	Replace	—
	Bent driveshaft	Replace	M-22
	Worn or damaged wheel bearing	Replace	M-13
	Worn driveshaft spline	Replace	M-23

96E0MX-009

VISCOUS LIMITED SLIP DIFFERENTIAL

Problem	Possible Cause	Action	Page
Abnormal noise	Insufficient differential oil	Add oil	M-28
	Incorrect differential oil	Replace	M-28
	Improperly adjusted ring gear backlash	Adjust	M-40
	Worn or damaged viscous L.S.D.	Replace	M-28, 33
	Worn or damaged ring gear	Replace	M-33
	Worn or damaged drive pinion bearing	Replace	M-33
Heat buildup	Insufficient differential oil	Add oil	M-28
	Excessive bearing preload	Adjust	M-38
Oil leakage	Excessive differential oil	Remove oil	M-28
	Loose differential carrier	Tighten or repair	M-41
	Worn or damaged oil seal	Replace	M-28, 33
No differential operation	Misassembled	Repair	M-33













96E0MX-013

REAR AXLE

M

REAR AXLE


PREPARATION SST

<p>49 F026 103 Puller, wheel hub</p> 	<p>For removal of wheel hub and wheel bearing</p>	<p>49 G033 105 Attachment A (Part of 49 G033 1A1)</p> 	<p>For removal of wheel hub</p>
<p>49 G033 106 Attachment B (Part of 49 G033 1A1)</p> 	<p>For removal of wheel bearing</p>	<p>49 G033 102 Handle (Part of 49 B026 1A0)</p> 	<p>For removal of wheel hub</p>
<p>49 G033 107 Installer, dust cover</p> 	<p>For installation of dust cover</p>	<p>49 H026 103 Block, support</p> 	<p>For installation of dust cover, wheel bearing hub flange</p>
<p>49 B001 797 Handle (Part of 49 S231 505)</p> 	<p>For installation of wheel bearing</p>	<p>49 F027 004 Attachment for bearing $\phi 80$</p> 	<p>For installation of wheel bearing</p>
<p>49 V001 795 Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>49 B026 1A0 Puller, wheel hub</p> 	<p>For removal of wheel hub</p>
<p>49 F027 0A1 Installer set, bearing</p> 	<p>For installation of wheel bearing</p>	<p>49 H027 002 Remover, bearing</p> 	<p>For removal of wheel bearing</p>

96E0MX-011

M

REAR AXLE



03U0MX-810

DISC BRAKE TYPE

Preinspection


Wheel bearing play

1. Remove the wheel and tire.
2. Remove the brake caliper assembly.
3. Position a dial indicator against the wheel hub. Push and pull the wheel hub by hand in the axial direction and measure the wheel bearing play.
4. If the bearing play exceeds specification, check and adjust the wheel hub nut torque or replace the wheel bearing if necessary.

Maximum wheel bearing play: 0.05mm (0.002 in)

Removal / Inspection / Installation


1. Remove in the order shown in the figure, referring to **Removal Note**.
2. Inspect all parts, and repair or replace as necessary.
3. Install in the reverse order of removal, referring to **Installation Note**.



N·m (m·kg, ft·lb)

96E0MX-012

- | | |
|---|---|
| <ol style="list-style-type: none"> 1. Wheel and tire 2. Locknut
Installation Note page M-13 3. Brake caliper assembly
Service Section P 4. Disc plate | <ol style="list-style-type: none"> 5. Trailing link 6. Lateral link 7. Shock absorber 8. Wheel hub, knuckle
Disassembly / Inspection /
Assembly page M-13 |
|---|---|



03U0MX-812

Installation Note
Wheel hub nut


1. Install a new nut, and stake it as shown.

Tightening torque:

177—235 Nm (18—24 m·kg, 130—174 ft·lb)

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts, and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




96E0MX-013


- | | |
|---|---|
| <p>1. Oil seal
Disassembly Note..... page M-14
Assembly Note page M-16</p> <p>2. Wheel hub
Disassembly Note..... page M-14
Inspect for cracks and other damage
Assembly Note page M-16</p> <p>3. Retaining ring
Disassembly Note..... page M-14
Assembly Note page M-15</p> | <p>5. Dust cover
Disassembly Note..... page M-15
Inspect for damage and distortion
Assembly Note page M-15</p> <p>6. Knuckle
Inspect for cracks and other damage</p> <p>7. Wheel stud
Disassembly Note..... page M-15
Assembly Note page M-15</p> |
|---|---|

M


REAR AXLE




03U0MX-814




03U0MX-815



03U0MX-816



03U0MX-817



03U0MX-818

Disassembly Note

Oil seal

1. Remove the oil seal with a screwdriver.

Wheel hub

1. Remove the wheel hub from the knuckle with the **SST** and a press.

Caution

- Support the wheel hub by hand to prevent it from falling.

2. Move the inner bearing race away from the axle with a hammer and chisel.

3. Set the **SST** between the wheel hub and bearing inner race, and remove the bearing inner race.

Wheel bearing


Caution

- Do not reuse the removed wheel bearing.

1. Remove the wheel bearing from the knuckle with the **SST** and a press.

REAR AXLE

M




03U0MX-819

Dust cover

Caution

- Do not remove the dust cover if not necessary.
- Do not reuse the removed dust cover.

1. Mark the dust cover and knuckle for proper reassembly.
2. Remove the dust cover with a chisel.




96E0MX-014

Wheel studs

Caution

- Do not remove the wheel studs if not necessary.
- Do not reuse the removed wheel.

1. Remove the wheel studs with a hammer.




03U0MX-821

Assembly Note

Wheel stud


1. Install the new wheel studs with a press.



96E0MX-015

Dust cover

1. Mark the new dust cover the same as the one removed.
2. Align the marks of the new dust cover and the knuckle.
3. Press on the new dust cover with the SST.




96E0MX-016

Wheel bearing


1. Press in the new wheel bearing with the SST.

M

REAR AXLE



96E0MX-017



03U0MX-014

Wheel hub

1. Press in the wheel hub with the **SST**.

Oil seal

Caution

- Use a new oil seal, and apply grease to the lip of the seal.
- Install the oil seal flush with the knuckle.









1. Install the new oil seal with the **SST**.

DRIVESHAFT

M

DRIVESHAFT


PREPARATION SST

<p>49 H034 2A0 Lower arm bushing puller & installer</p> 	<p>For support of bracket</p>	<p>49 H034 201 Support block (Part of 49 H034 2A0)</p> 	<p>For support of bracket</p>
<p>49 F026 102 Installer, bearing</p> 	<p>For removal of bearing and rear oil seal</p>	<p>49 G030 795 Installer, oil seal</p> 	<p>For installation of front oil seal and bearing</p>
<p>49 M005 795 Installer set, oil seal</p> 	<p>For installation of rear oil seal</p>	<p>49 M005 796 Body (Part of 49 M005 795)</p> 	<p>For installation of rear oil seal</p>
<p>49 0118 850C Puller, ball joint</p> 	<p>For removal of tie-rod end</p>	<p>49 G030 455 Holder, diff. side gear</p> 	<p>For support of side gears</p>

96EOMX-018

M

DRIVESHAFT




96EOMX-019

JOINT SHAFT Preinspection Joint shaft

1. Verify that the joint shaft is not twisted or cracked. Replace it if necessary.
2. Turn the joint shaft by hand and verify that the bearing rotates smoothly and freely. Replace it if necessary.

Removal / Installation

1. Drain the transaxle oil before removal.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.




N-m (m-kg, ft-lb)

96EOMX-020

- | | |
|-----------------------------------|-----------------------------------|
| 1. Wheel and tire | 5. Lower arm ball joint |
| 2. Splash shield | 6. Driveshaft |
| 3. Stabilizer | 7. Joint shaft |
| Installation Note page M-19 | Removal Note page M-19 |
| 4. Ball joint | Installation Note page M-19 |
| Removal Note page M-19 | Overhaul page M-20 |

DRIVESHAFT

M




96E0MX-021

Removal Note Ball joint

Caution

- Do not damage the dust boot.
- Do not reuse the cotter pin.


1. Remove the cotter pin and loosen the nut until it is flush with the end of ball stud.
2. Disconnect the ball joint from knuckle arm with the **SST**.



96E0MX-022


Joint shaft

1. Separate the joint shaft and driveshaft with pry bar.



96E0MX-023

2. Remove the two bolts and two reamer bolts, and disconnect the joint shaft from the cylinder block.



96E0MX-024


Installation Note

Joint shaft

1. Connect the joint shaft mount to the cylinder block with the two bolts and two reamer bolts.

Tightening torque

- Ⓐ : 42—62 N·m (4.3—6.3 m·kg, 31—46 ft·lb)
- Ⓑ : 6.9—48 N·m (0.7—4.9 m·kg, 5.1—35 ft·lb)



86U09X-073

Stabilizer


Lock the nut with **20.1mm (0.79 in)** of the threads exposed.

Tightening torque:

- 16—23 N·m (1.6—2.3 m·kg, 12—17 ft·lb)**

M

DRIVESHAFT




96E0MX-019

JOINT SHAFT Preinspection Joint shaft

1. Verify that the joint shaft is not twisted or cracked. Replace it if necessary.
2. Turn the joint shaft by hand and verify that the bearing rotates smoothly and freely. Replace it if necessary.

Removal / Installation

1. Drain the transaxle oil before removal.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.




1. Wheel and tire
2. Splash shield
3. Stabilizer
Installation Note page M-19
4. Ball joint
Removal Note page M-19

5. Lower arm ball joint
6. Driveshaft
Removal Note page M-19
Installation Note page M-19
7. Joint shaft
Overhaul page M-20

DRIVESHAFT

M




96E0MX-021

Removal Note Ball joint

Caution

- Do not damage the dust boot.
- Do not reuse the cotter pin.


1. Remove the cotter pin and loosen the nut until it is flush with the end of ball stud.
2. Disconnect the ball joint from knuckle arm with the **SST**.



96E0MX-022


Joint shaft

1. Separate the joint shaft and driveshaft with pry bar.



96E0MX-023

2. Remove the two bolts and two reamer bolts, and disconnect the joint shaft from the cylinder block.



96E0MX-024


Installation Note

Joint shaft

1. Connect the joint shaft mount to the cylinder block with the two bolts and two reamer bolts.

Tightening torque

- (A) : 42—62 N·m (4.3—6.3 m·kg, 31—46 ft·lb)
- (B) : 6.9—48 N·m (0.7—4.9 m·kg, 5.1—35 ft·lb)



86U09X-073

Stabilizer

Lock the nut with **20.1mm (0.79 in)** of the threads exposed.

Tightening torque:


- 16—23 N·m (1.6—2.3 m·kg, 12—17 ft·lb)

M

DRIVESHAFT


Overhaul

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts, and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.



96E0MX-025

- | | |
|-------------------------------------|---|
| 1. Clip | 5. Ball bearing |
| 2. Joint shaft | Assembly note page M-21 |
| Disassembly note page M-20 | 3. Dust seal (Differential-side) |
| Assembly note page M-21 | Inspect splines for damage and wear |
| Inspect splines for damage and wear | Assembly note page M-21 |
| 3. Dust seal (Differential-side) | Inspect for damage, wear and rough rotation |
| Assembly note page M-21 | 6. Joint shaft mounting bracket |
| | |
| | 4. Dust seal (Wheel-side) |
| | Assembly note page M-21 |



96E0MX-026


M-20

Disassembly Note

- #### Joint shaft
1. Support the joint shaft bracket with the **SST**.
 2. Remove the joint shaft with a press and a suitable pipe.

DRIVESHAFT


M



96E0MX-027

Ball bearing

1. Remove the ball bearing from joint shaft bracket with the SST.




96E0MX-028

Assembly Note

Ball bearing


1. Install the ball bearing with the SST.



96E0MX-029

Dust seal (Differential-side)


1. Install the new dust seal with the SST.



96E0MX-030

Dust seal (Wheel-side)

1. Install the new dust seal with the SST.



96E0MX-031

Joint shaft

1. Support the joint shaft bracket with the SST.
2. Install the joint shaft with a press.


M

DRIVESHAFT

DOUBLE-OFFSET JOINT

Inspection / Removal / Installation

1. Inspect the rear driveshaft, referring to **Inspection**.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.




1. Wheel nut
2. Wheel and tire
3. Wheel hub nut
4. Nut (Driveshaft)

Removal Note..... page M-23

5. Bolt (Trailing link)
6. Bolt (Lateral link)
7. Driveshaft

Inspection..... below




M-22

96E0MX-033

Inspection Driveshaft

1. Turn the driveshaft by hand and verify that the splines and joints are not excessively loose.
2. Verify that the driveshaft is not twisted or cracked.
3. Replace the driveshaft if necessary.



03U0MX-828

**Removal Note
Nuts (Driveshaft)**


1. Before removing the driveshaft, mark the driveshaft and output shaft for proper reassembly.

Disassembly / Inspection / Assembly

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts, and repair or replace as necessary.
3. Assemble in the reverse order of removal, referring to **Assembly Note**.

Caution

- Secure the driveshaft in a vise with protective material (such as copper plates) on the vise jaws.
- Be careful that dust or other foreign material does not enter the ball joint while the work is being performed.
- Do not disassemble the wheel-side ball joint.
- Do not wash the ball joint unless it is being disassembled.




96E0MX-034


- | | |
|---------------------------------|--|
| 1. Boot band (Large) | 8. Inner ring |
| 2. Boot band (Small) | Disassembly Note..... page M-24 |
| 3. Clip | 9. Boot |
| Disassembly Note..... page M-24 | Disassembly Note..... page M-24 |
| 4. Outer ring | Assembly Note..... page M-25 |
| 5. Ball | 10. Boot band (Small) |
| 6. Snap ring | 11. Boot band (Large) |
| Disassembly Note..... page M-24 | 12. Boot |
| 7. Cage | Disassembly Note..... page M-24 |
| Disassembly Note..... page M-24 | Assembly Note..... page M-25 |
| Assembly Note..... page M-25 | 13. Driveshaft |
| | Inspect for bending, twisting and other damage |

M


DRIVESHAFT




03U0MX-830




96E0MX-035



03U0MX-832



96E0MX-036



03U0MX-834

Disassembly Note Clip

Caution

- Mark with paint, do not use a punch.

1. Mark the outer ring and the cage for proper reassembly.
2. Remove the clip with a screwdriver.

Snap ring

Caution

- Mark with paint, do not use a punch.

1. Mark the driveshaft, the cage and the inner ring for proper reassembly.
2. Remove the snap ring with snap-ring pliers.

Cage

1. Turn the cage approximately 30°, then pull it away from the inner ring.

Inner ring

1. Drive the inner ring off the driveshaft with a brass bar and a hammer.

Boot


Caution

- Do not remove the boot (wheel-side) if not necessary.

1. Wrap the splines of the driveshaft with tape to prevent damaging the boot.
2. Remove the boot.

DRIVESHAFT

M




Assembly Note Boot

Caution


- The wheel-side and differential-side boots are different.

A: 79.2mm (3.13 in)

B: 80.2mm (3.15 in)



1. Wrap the wheel-side splines of the shaft with tape and install the boot and a new boot band.



Caution


- Do not use other than the specified grease.

2. Apply molybdenum disulfide grease to the joint.

Quantity:

Differential side: 55 ± 10 g (1.94 ± 0.35 oz)

Wheel side : 55 ± 10 g (1.94 ± 0.35 oz)




3. Measure the length of the driveshaft.

Standard length:

Right side: 691mm (27.20 in)

Left side : 661mm (26.02 in)



Cage

















1. Install the cage at approximately 30° from the mark, then align the marks.

M

VISCOUS LIMITED SLIP DIFFERENTIAL









VISCOUS LIMITED SLIP DIFFERENTIAL

PREPARATION SST

<p>49 0107 680A Engine stand</p> 	<p>For disassembly and assembly of differential</p>	<p>49 M005 561 Hanger, differential carrier</p> 	<p>For disassembly and assembly of differential</p>
<p>49 0636 145 Puller, fan pulley boss</p> 	<p>For removal of bearing inner race (side bearing)</p>	<p>49 N034 213 Installer, rubber bushing</p> 	<p>For installation of differential mounting rubber</p>
<p>49 G030 795 Installer, oil seal</p> 	<p>For installation of oil seal</p>	<p>49 G030 797 Handle (Part of 49 G030 795)</p> 	<p>For installation of bearing outer race</p>
<p>49 B001 795 Installer, oil seal</p> 	<p>For installation of oil seal (output shaft)</p>	<p>49 H033 101 Remover, bearing</p> 	<p>For installation of bearing outer race (front bearing)</p>
<p>49 F027 0A1 Installer set, bearing</p> 	<p>For installation of bearing</p>	<p>49 F027 005 Attachment $\phi 62$ (Part of 49 F027 0A1)</p> 	<p>For installation of bearing outer race (rear bearing)</p>
<p>49 F027 0A0 Gauge set, pinion height adjustment</p> 	<p>For adjustment of pinion height</p>	<p>49 0727 570 Gauge body, pinion height (Part of 49 F027 0A0)</p> 	<p>For adjustment of pinion height</p>
<p>49 8531 565 Model, pinion</p> 	<p>For adjustment of pinion height</p>	<p>49 8531 567 Collar A (Part of 49 8531 565)</p> 	<p>For adjustment of pinion height</p>
<p>49 H027 001 Collar</p> 	<p>For adjustment of pinion height</p>	<p>49 N027 001 Gauge block</p> 	<p>For adjustment of pinion height</p>

VISCOUS LIMITED SLIP DIFFERENTIAL


M

<p>49 D017 2A1 Installer set, bearing</p> 	<p>For installation of bearing</p>	<p>49 F401 336B Attachment B (Part of 49 D017 2A1)</p> 	<p>For installation of bearing inner race (rear bearing)</p>
<p>49 F401 331 Body (Part of 49 D017 2A1)</p> 	<p>For installation of bearing inner race (rear bearing)</p>	<p>49 F401 337A Attachment C (Part of 49 D017 2A1)</p> 	<p>For installation of bearing inner race (side bearing)</p>
<p>49 S120 710 Holder, coupling flange</p> 	<p>For removal and installation of companion flange</p>	<p>49 0839 425C Puller set, bearing</p> 	<p>For removal and installation of companion flange</p>
<p>49 U027 003 Installer, oil seal</p> 	<p>For installation of oil seal (companion flange)</p>	<p>49 0259 720 Wrench, differential side bearing adjusting nut</p> 	<p>For adjustment of drive pinion and ring gear backlash</p>


96E0MX-041

M


VISCOUS LIMITED SLIP DIFFERENTIAL




9MU0MX-033




96E0MX-042



05U0MX-055



05U0MX-056



96E0MX-043

DIFFERENTIAL OIL

Inspection

1. Remove the filler plug.
2. Verify that the oil is at the bottom of the filler plug hole. If it is low, add the specified oil.
3. Install the filler plug.

Tightening torque:

39—54 N·m (4.0—5.5 m·kg, 29—40 ft·lb)

Replacement

1. Remove the filler and drain plugs.
2. Drain the differential oil into a suitable container.
3. Wipe the plugs clean.
4. Install the drain plug and new washer.

Tightening torque:

39—54 N·m (4.0—5.5 m·kg, 29—40 ft·lb)

5. Add the specified oil from the filler plug until the level reaches the bottom of the plug hole.

Specified oil

Type:

Above -18°C (0°F): API GL-5, SAE 90

Below -18°C (0°F): API GL-5, SAE 80W

Capacity: 0.65 liter (0.69 US qt, 0.57 Imp qt)

6. Install the filler plug.

Tightening torque:

39—54 N·m (4.0—5.5 m·kg, 29—40 ft·lb)

OIL SEAL (OUTPUT SHAFT)

Replacement

1. Jack up the vehicle and support it with safety stands.
2. Drain the differential gear oil.


Note

- Mark the driveshaft and output shaft flanges for proper reassembly.


3. Remove the lateral link.
4. Remove the trailing link.
5. Pull the wheel hub out to separate the driveshaft from the output shaft.

VISCOUS LIMITED SLIP DIFFERENTIAL


M




96E0MX-044




96E0MX-045



96E0MX-046



03U0MX-848



96E0MX-047

6. Suspend the driveshaft.

Note

- Use caution during the removal operation, because the shaft may suddenly drop.

7. Remove the output shaft with two pry bars as shown in the figure, then remove the clips.

8. Remove the oil seal.

9. Apply lithium-based grease to the new oil seal lip and install it with the SST.

10. Install a new clip at the end of the output shaft.

Caution

- The right output shaft is longer than the left shaft.

11. Install the output shaft into the side gear by lightly tapping with a plastic hammer.

12. Verify that the output shaft is hooked into the side gear by pulling it by hand.

13. Install the lateral link.

Tightening torque:

63—75 N·m (6.4—7.6 m·kg, 46—55 ft·lb)

14. Install the trailing link.

Tightening torque:

49—59 N·m (5.0—6.0 m·kg, 36—43 ft·lb)


15. Align the marks and install the driveshaft.

Tightening torque:

54—64 N·m (5.5—6.5 m·kg, 40—47 ft·lb)

M

VISCOUS LIMITED SLIP DIFFERENTIAL



03U0MX-850

16. Add the specified oil through the filler plug hole until it reaches the bottom of the hole.

Specified oil

Type:

Above -18°C (0°F): GL-5, SAE 90


Below -18°C (0°F): GL-5, SAE 80W

Capacity: 0.65 liter (0.6 US qt, 0.5 Imp qt)

17. Install the filler plug and a new gasket.

Tightening torque:

39—54 N·m (4.0—5.5 m·kg, 29—40 ft·lb)



96E0MX-048

OPERATION INSPECTION

1. Turn off the engine and shift the transmission into reverse.
2. Block the front wheels with wheel chocks.
3. Jack up the rear wheels and support the vehicle with safety stands.
4. Release the parking brake.
5. Using a torque wrench on a wheel lug nut, measure the time it takes to turn the wheel 90° while applying the specified torque.

Specified torque: 15 N·m (1.5 m·kg, 11 ft·lb)


Specified time: 4.0 sec. min.

6. If not as specified, replace the viscous limited slip differential and fill the differential with new specified oil. (Refer to pages M-28, 33.)

VISCOUS LIMITED SLIP DIFFERENTIAL

Removal / Installation

1. Drain the differential oil.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.
4. Add the specified oil to the specified level.




N·m (m·kg, ft·lb)

96EOMX-049

1. Propeller shaft
Service..... Section L
2. Wheel and tire
3. Lateral link
4. Trailing link

5. Driveshaft
Removal Note below
Installation Note page M-32
6. Viscous L.S.D.
Removal Note page M-32
Installation Note page M-32
Overhaul page M-33



03UOMX-852


Removal Note

Driveshaft

1. Before removing the driveshaft, mark the driveshaft and output shaft for proper reassembly.


M

VISCOUS LIMITED SLIP DIFFERENTIAL



03U0MX-853


2. Pull the wheel hub out to separate the driveshaft from the output shaft.



96E0MX-050

Viscous L.S.D.

1. Support the differential with a jack while removing it.



96E0MX-051

Installation Note


Viscous L.S.D.

1. Support the differential with a jack while installing it.

Tightening torque:

Front 45—68 N·m (4.6—6.9 m·kg, 33—50 ft·lb)

Rear 93—116 N·m (9.5—11.9 m·kg, 68—86 ft·lb)



03U0MX-856

Driveshaft

1. Align the marks and reinstall the driveshaft.

Tightening torque:

53—63 N·m (5.5—6.5 m·kg, 39—47 ft·lb)

VISCOUS LIMITED SLIP DIFFERENTIAL


M

Overhaul

Caution

- Install the differential carrier within 10 minutes after applying sealant. Allow the sealant to set at least 30 minutes after installation before filling the differential with the specified oil.

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.
2. Inspect all parts, and repair or replace as necessary.
3. Assemble in the reverse order of disassembly, referring to **Assembly Note**.




M


VISCOUS LIMITED SLIP DIFFERENTIAL

1. Differential gear assembly
Disassembly Note..... page M-34
2. Output shaft
Disassembly Note..... page M-34
Assembly Note page M-41
3. Differential case
Assembly Note page M-41
4. Lock plate
5. Bearing cap
Disassembly Note..... page M-35
6. Adjusting screw
Disassembly Note..... page M-39
7. Bearing outer race (Side bearing)
8. Nut (Companion flange)
Disassembly Note..... page M-35
Assembly Note page M-39
9. Washer
10. Companion flange
Disassembly Note..... page M-35
Inspect splines for cracks and other damage
Assembly Note page M-39
11. Oil seal (Companion flange)
Assembly Note page M-39
12. Drive pinion
Assembly Note page M-36
Inspect splines for cracks and other damage
13. Spacer
14. Bearing inner race (Front bearing)
Inspect for rough rotation
15. Collapsible spacer
16. Bearing inner race (Rear bearing)
Disassembly Note..... page M-36
Inspect for rough rotation
17. Bearing outer race (Rear bearing)
Disassembly Note..... page M-36
Assembly Note page M-37
18. Bearing outer race (Front bearing)
Disassembly Note..... page M-36
Assembly Note page M-37
19. Differential carrier
20. Ring gear
Inspect for cracks and other damage
21. Bearing inner race (Side bearing)
Disassembly Note..... page M-36
22. Gear case
23. Viscous L.S.D.
24. Oil seal (Output shaft)
Assembly Note page M-41

96EOMX-053



03UOMX-859




M-34

Disassembly Note Differential gear assembly

1. Mount the differential carrier on the **SST**.

Output shaft

1. Remove the output shaft with a pry bar as shown in the figure.




03U0MX-861

Bearing cap

1. Mark one bearing cap and the carrier.

Adjusting screw


1. Mark one adjusting screw and the carrier.



03U0MX-862

Nut (Companion flange)


1. Hold the companion flange with the SST and remove the nut.



03U0MX-863

Companion flange


1. Remove the companion flange with the SST.



03U0MX-864

Drive pinion

1. Push out the drive pinion by attaching a miscellaneous nut to the drive pinion and tapping it with a copper hammer.



03U0MX-865

Bearing outer race (Front), (Rear)


Note

- Identify the bearing outer races for proper reassembly.

1. Remove the bearing outer races by alternately tapping the races at the two grooves in the carrier.

M

VISCOUS LIMITED SLIP DIFFERENTIAL




96E0MX-054

Bearing inner race (Rear bearing)

Note

- Support the drive pinion with one hand so that it does not fall.

1. Remove the rear bearing with the SST.




96E0MX-055

Bearing inner race (Side bearing)

Note

- Do not remove the bearing inner races if not necessary.
- Replace the bearing inner races with new bearings if removed.

1. Remove the side bearings from the gear case with the SST.




96E0MX-056

Assembly Note

Bearing outer race (Front), (Rear)

1. Install the front and rear bearing outer races with a brass drift and a hammer.




03U0MX-869

Adjustment of pinion height


1. Adjust the drive pinion height as follows with the SST.

VISCOUS LIMITED SLIP DIFFERENTIAL


M




96EOMX-057



97UOMX-082



96EOMX-058



97UOMX-084

Note

- Use the spacer that was removed.
- Do not install the collapsible spacer.

- Install the bearing inner race (rear), spacer, O-ring and **SST**.
- Install the bearing inner race (front), companion flange, washer, and nut.
- Tighten the nut just enough so that the **SST** can still be turned by hand.

- Place the **SST** on a surface plate and set the dial indicator to "Zero".

- Place the **SST** atop the drive pinion model. Set the gauge body atop the gauge block.
- Place the feeler of the dial indicator so that it contacts where the bearing inner race (side bearing) sets in the carrier. Measure the lowest position on the left and right sides of the carrier.

- Add the two (left and right) values obtained in Step f, and divide the total by 2.


Specification: 0mm (0 in)

M


VISCOUS LIMITED SLIP DIFFERENTIAL

Mark	Thickness	Mark	Thickness
08	3.08mm (0.1213 in)	29	3.29mm (0.1295 in)
11	3.11mm (0.1224 in)	32	3.32mm (0.1307 in)
14	3.14mm (0.1236 in)	35	3.35mm (0.1319 in)
17	3.17mm (0.1248 in)	38	3.38mm (0.1331 in)
20	3.20mm (0.1260 in)	41	3.41mm (0.1343 in)
23	3.23mm (0.1271 in)	44	3.44mm (0.1354 in)
26	3.26mm (0.1283 in)	47	3.47mm (0.1366 in)


96EOMX-059




03UOMX-872



03UOMX-873



96EOMX-060



03UOMX-875

h) If not within specification, adjust the pinion height by selection of a spacer.

Note

- Spacers are available in increments of 0.03mm (0.0012 in). Select the spacer thickness that is closest to that necessary.

Adjustment of drive pinion preload

1. Install the spacer.

Note

- Press the bearing on until the force required suddenly increases.
- Install the spacer selected from the pinion height adjustment above, being careful that the installation direction is correct.

2. Press the bearing inner race (rear bearing) on with the SST.

Caution

- Do not install the oil seal.

3. Install the collapsible spacer.

4. Install the drive pinion assembly.

5. Install the companion flange, and tighten the flange nut.

Tightening torque: 117 N·m (12 m·kg, 86 ft·lb)

6. Turn the companion flange by hand to seat the bearing.

7. Measure the drive pinion preload.

Adjust the preload by tightening the flange nut.

Preload:

0.29—0.68 N·m (3—7 cm·kg, 2.6—6.0 in·lb)

Tightening torque:

117—176 N·m (12—18 m·kg, 86—130 ft·lb)

If the specified preload cannot be obtained, replace the collapsible spacer with a new one and recheck.


8. Remove the nut, washer, and companion flange.

Oil seal (Companion flange)

Caution

- Apply differential oil to the oil seal lip.


1. Tap a new oil seal into the differential carrier with the SST.



03U0MX-876

Companion flange

1. Apply a light coat of grease to the end face of the companion flange.



49 S120 710

Nut (Companion flange)

1. Adjust the preload by tightening the flange nut.


Preload:

0.29—0.68 N·m (3—7 cm·kg, 2.6—6.0 in·lb)

Tightening torque:

117—176 N·m (12—18 cm·kg, 86—130 in·lb)

03U0MX-877




96E0MX-061

Adjustment of drive pinion and ring gear backlash

Note

- Apply approx. 0.04 cc (0.0024 cu in) of compound at each point.

1. Apply thread-locking compound to points A and B around the back face of the ring gear.




96E0MX-062

2. Mount the ring gear onto the gear case.

Tightening torque:

69—83 N·m (7.0—8.5 m·kg, 51—61 ft·lb)




96E0MX-068


3. Press the new bearing inner race (side gear) on with the SST.
4. Install the differential gear assembly in the carrier.
5. Note the identification mark on the adjusting screw, and install the screws to their respective sides.
6. Install the differential bearing caps, making sure that the identification mark on the cap corresponds with the one on the carrier.

M


VISCOUS LIMITED SLIP DIFFERENTIAL




96E0MX-064




97U0MX-104



03U0MX-882



03U0MX-883



63G09X-385

7. Mark the ring gear at four points at approx. **90°** intervals. Mount a dial indicator onto the carrier so that the feeler comes into contact at a right angle with one of the ring gear teeth.

8. Turn both bearing adjusting screws, equally with the **SST** until the backlash is as specified.

Backlash: 0.09—0.11mm (0.0035—0.0043 in)

9. Check the backlash at the three other marked points, and make sure the minimum backlash is above **0.05mm (0.0020 in)** and the difference between the maximum and minimum is less than **0.07mm (0.0028 in)**.

10. Tighten the adjusting screws equally until the distance between the pilot sections on the bearing caps is as specified.

Specified distance:

150.13—150.20mm (5.910—5.913 in)

Note

- When adjusting the differential bearing preload, be careful not to affect the backlash of the drive pinion and ring gear.

Inspection and adjustment of teeth contact


1. Coat both surfaces of 6—8 teeth of the ring gear with a uniformly thin coat of red lead.
2. While moving the ring gear back and forth by hand, rotate the drive pinion several times and check the tooth contact.
3. If the tooth contact is good, wipe off the red lead.
4. If it is not good, readjust the pinion height, and then readjust the backlash.

(1) Toe and flank contact

Replace the spacer with a thinner one to move the drive pinion outward.


VISCOUS LIMITED SLIP DIFFERENTIAL

M



9MU0MX-068

- (2) Heel and face contact
Replace the spacer with a thicker one to bring the drive pinion inward.




96E0MX-065

Differential case

1. Apply sealant to the case mounting surface.
2. Tighten the bolts.

Tightening torque:

23—26 N·m (2.3—2.7 m·kg, 10—20 ft·lb)




96E0MX-066

Oil seal (Output shaft)

Caution

- Apply lithium-base grease to the oil seal lip.

1. Install the new oil seal with the SST.



96E0MX-067

Output shaft

1. Install new clips.

Caution

- The right output shaft is longer than the left shaft.

2. Install the output shaft into the side gears by lightly tapping with a plastic hammer.
3. Verify that the output shaft is secured in the side gears by pulling them by hand.