


# MANUAL TRANSAXLE (G5M-R)

<b>INDEX</b> .....	J1- 2
<b>OUTLINE</b> .....	J1- 3
SPECIFICATIONS.....	J1- 3
STRUCTURAL VIEW .....	J1- 4
POWER FLOW .....	J1- 5
<b>TROUBLESHOOTING GUIDE</b> .....	J1- 6
<b>TRANSAXLE OIL</b> .....	J1- 7
INSPECTION.....	J1- 7
REPLACEMENT.....	J1- 7
<b>TRANSAXLE</b> .....	J1- 8
PREPARATION .....	J1- 8
REMOVAL .....	J1-10
DISASSEMBLY .....	J1-12
INSPECTION.....	J1-23
ASSEMBLY .....	J1-26
INSTALLATION.....	J1-43
<b>SHIFT MECHANISM</b> .....	J1-48
REMOVAL / INSTALLATION.....	J1-48
INSPECTION.....	J1-49

16U0J1-027

## INDEX



06U0J1-002

### 1. Transaxle

Removal ..... page J1-10  
Disassembly ... page J1-12  
Inspection ..... page J1-23  
Assembly ..... page J1-28  
Installation..... page J1-43

### 2. Differential

Disassembly ... page J1-22  
Inspection ..... page J1-23  
Adjustment ..... page J1-27  
Assembly ..... page J1-26

### 3. Shift mechanism

Removal /  
Installation..... page J1-48  
Inspection ..... page J1-49

### 4. Transaxle oil

Inspection ..... page J1- 7  
Replacement .. page J1- 7

OUTLINE


SPECIFICATIONS

Item	Engine	F2 Non-turbo
Transaxle model		G5M-R
Transaxle control		Floor shift
Synchromesh system		Forward.....synchromesh, Reverse.....selective sliding and synchromesh
Gear ratio	1st	3.307
	2nd	1.833
	3rd	1.233
	4th	0.914
	5th	0.717
	Reverse	3.166
Final gear ratio		4.105
Oil	Type	All season SAE 75W-90 ATF: DEXRON-II Above -18°C (0°F) API: GL-4 or GL-5 SAE 80W-90 or SAE 90
	Capacity	3.35 liters (3.5 US qt, 2.9 Imp qt)

J1

16U0J1-001

### STRUCTURAL VIEW









06U0J1-004

- 1. Primary 1st gear
- 2. Primary 2nd gear
- 3. Primary 3rd gear
- 4. Primary 4th gear
- 5. Primary 5th gear

- 6. Primary reverse gear
- 7. Secondary 1st gear
- 8. Secondary 2nd gear
- 9. Secondary 3rd gear
- 10. Secondary 4th gear

- 11. Secondary 5th gear
- 12. Secondary reverse gear
- 13. Reverse idler gear
- 14. Differential

POWER FLOW




J1


### TROUBLESHOOTING GUIDE

Problem	Possible cause	Remedy	Page
<b>Change lever won't shift smoothly, or is hard to shift</b>	Seized change lever ball	Replace	J1-48
	Seized change control rod joint	Replace	J1-48
	Bent change control rod	Replace	J1-48
<b>Too much play in change lever</b>	Worn change control rod bushing	Replace	J1-48
	Weak ball spring or change lever	Replace	J1-48
	Worn ball bushing or change lever	Replace	J1-48
<b>Difficult to shift</b>	Bent change rod	Replace	J1-48
	No grease in transmission control	Lubricate with grease	J1-48
	Insufficient oil	Add oil	J1- 7
	Deterioration of oil quality	Replace with oil of specified quality	J1- 7
	Wear or play of shift fork or shift rod	Replace	J1-12
	Worn synchronizer ring	Replace	J1-23
	Worn synchronizer gear cone	Replace	J1-23
	Bad contact of synchronizer ring and gear cone	Replace	J1-23
	Excessive longitudinal play of gears	Replace	J1-19
	Worn bearing	Adjust or replace	J1-19
	Worn synchronizer key spring	Replace	J1-19
	Excessive primary shaft gear bearing preload	Adjust	J1-34
	Improperly adjusted change guide plate	Adjust	J1-15
	<b>Won't stay in gear</b>	Bent change control rod	Replace
Worn change control rod bushing		Replace	J1-48
Weak change lever ball spring		Replace	J1-48
Improperly installed extension bar		Tighten	J1-48
Worn shift fork		Replace	J1-19
Worn clutch hub		Replace	J1-23
Worn clutch hub sleeve		Replace	J1-23
Worn gear sliding part of both shaft gears		Replace	J1-24
Worn gear sliding part of each gear		Replace	J1-24
Worn steel sliding groove of control end		Replace	J1-12
Weak spring pressing against steel ball		Replace	J1-12
Excessive thrust clearance		Replace	J1-30,32
Worn bearing		Replace	J1-19
Improperly installed engine mount		Tighten	J1-43
<b>Abnormal noise</b>	Insufficient oil	Add oil	J1- 7
	Deterioration of oil quality	Replace	J1- 7
	Worn bearing	Adjust or replace	J1-19
	Worn gear sliding surface of both shaft gears	Replace	J1-19
	Worn sliding surfaces of gears	Replace	J1-19
	Excessive gear backlash	Replace	J1-19
	Damaged gear teeth	Replace with oil of specified quality	J1-23,24
	Foreign material in gears	Replace	J1-19
	Damaged differential gear, or excessive backlash	Adjust or replace	J1-27


16U0J1-028




06U0J1-006




06U0J1-007



06U0J1-008



16U0J1-002



06U0J1-010

## TRANSAXLE OIL

### INSPECTION

1. Park the vehicle on level ground.
2. Slide up the speedometer cable dust cover, and disconnect the cable from the speedometer driven gear.
3. After removing the bolt, pull the gear case to remove it from the housing. (Insert a flat-tipped screwdriver between the speedometer gear case and the clutch housing, and use it to pry the gear case loose if necessary.)
4. Check that the oil level is between the "F" and "L".
5. If not, add the necessary amount of the specified oil through the gear case hole.
6. Install the speedometer driven gear.

J1

### REPLACEMENT

1. Park the vehicle on level ground.
2. Remove the speedometer driven gear. (See "INSPECTION" section above.)
3. Remove the drain plug, and drain the oil.

4. Replace the drain plug, and add the necessary amount of the specified oil through the speedometer gear case hole.

#### Specified oil

##### Type

















- All-season
- SAE 75W-90
- ATF: DEXRON-II
- Above -18°C (0°F):
- API: GL-4 or GL-5
- SAE 80W-90 or SAE 90

**Capacity: 3.35 liters (3.5 US qt, 2.9 Imp qt)**

















5. Check that the oil level is between the "F" and "L".
6. If not, add the necessary amount of the specified oil through the gear case hole.
7. Install the speedometer driven gear.

### TRANSAXLE

#### PREPARATION SST

<p>49 0118 850C Puller, ball joint</p> 	<p>For removal of ball joint</p>	<p>49 G030 455 Holder, diff. side gear</p> 	<p>For support of differential side gears</p>
<p>49 G017 5A0 Support, engine</p> 	<p>For support of engine</p>	<p>49 G017 501 Bar (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>
<p>49 G017 502 Support (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>	<p>49 G017 503 Hook (Part of 49 G017 5A0)</p> 	<p>For support of engine</p>
<p>49 G019 0A0 Hanger, transaxle</p> 	<p>For disassembly and assembly of transaxle</p>	<p>49 0107 680A Engine stand</p> 	<p>For disassembly and assembly of transaxle</p>
<p>49 G030 440 Holder, primary shaft</p> 	<p>For hold of primary shaft</p>	<p>49 FT01 361 Remover, bearing</p> 	<p>For removal of bearing outer race</p>
<p>49 0636 145 Puller, fan pulley boss</p> 	<p>For removal and installation of bearing inner race</p>	<p>49 G030 370 Removing plate</p> 	<p>For removal of secondary 3rd gear and 2nd gear</p>
<p>49 F401 366A Plate</p> 	<p>For removal of bearing inner race</p>	<p>49 B092 374 Attachment H</p> 	<p>For removal of bearing inner race</p>
<p>49 B092 373 Attachment G</p> 	<p>For removal of bearing inner race</p>	<p>49 0839 425C Puller set, bearing</p> 	<p>For removal of bearing inner race</p>




<p>49 B092 375 Attachment J</p> 	<p>For removal of bearing inner race</p>	<p>49 G030 338 Attachment E</p> 	<p>For installation of bearing inner race</p>
<p>49 F401 331 Body</p> 	<p>For installation of bearing inner race</p>	<p>49 F401 335A Attachment A</p> 	<p>For installation of bearing inner race</p>
<p>49 F401 336B Attachment B</p> 	<p>For installation of bearing inner race</p>	<p>49 G030 380C Shim selector set</p> 	<p>For adjustment of bearing preload</p>
<p>49 G030 381 Selector for <math>\phi 68</math> (Part of 49 G030 380C)</p> 	<p>For adjustment of bearing preload</p>	<p>49 G030 382A Selector <math>\phi 58</math> (Part of 49 G030 380C)</p> 	<p>For adjustment of bearing preload</p>
<p>49 F401 382A Selector <math>\phi 52</math> (Part of 49 G030 380C)</p> 	<p>For adjustment of bearing preload</p>	<p>49 F401 384 Collar (Part of 49 G030 380C)</p> 	<p>For adjustment of bearing preload</p>
<p>49 F401 385 Bar (Part of 49 G030 380C)</p> 	<p>For adjustment of bearing preload</p>	<p>49 G019 021 Bolt set (Part of 49 G030 380C)</p> 	<p>For adjustment of bearing preload</p>
<p>49 FT01 515A Adaptor, preload (Part of 49 G030 380C)</p> 	<p>For adjustment of bearing preload</p>	<p>49 B001 795 Installer, oil seal</p> 	<p>For installation of oil seal</p>
<p>49 G017 202 Adaptor, preload</p> 	<p>For adjustment of preload</p>	<p>49 B017 102 Adaptor, preload</p> 	<p>For adjustment of bearing preload</p>

J1


### REMOVAL

1. Disconnect the negative battery cable.
2. Raise the vehicle and support it with safety stands.
3. Drain the transaxle oil into a suitable container.
4. Remove in the order shown in the figure, referring to **Removal Note**.



06U0J1-012

- |                             |                          |                             |
|-----------------------------|--------------------------|-----------------------------|
| 1. Battery                  | 12. Tie-rod end          | 21. Starter                 |
| 2. Main fuse block          | Removal ..... page J1-11 | 22. Engine mount No.4       |
| 3. Distributor lead         | 13. Nuts (stabilizer)    | Removal ..... page J1-11    |
| 4. Airflow meter connector  | 14. Lower arm ball-joint | 23. Engine mount No.2       |
| 5. Air cleaner assembly     | 15. Driveshaft           | 24. Hanger rubber           |
| 6. Resonance chamber        | Removal ..... page J1-11 | 25. Crossmember             |
| 7. Speedometer cable        | 16. Gusset plate(s)      | 26. Transaxle               |
| 8. Ground(s)                | 17. Under cover          | Removal ..... page J1-11    |
| 9. Wheel(s)                 | 18. Extension bar        | Disassembly ... page J1-12  |
| 10. Splash shield(s)        | 19. Control rod          | Inspection ..... page J1-23 |
| 11. Clutch release cylinder | 20. Surge tank bracket   | Assembly ..... page J1-28   |




06U0J1-013

### Removal note

#### Tie-rod end

Separate the tie-rod end from the knuckle with the **SST**.




06U0J1-014

### Driveshaft

1. Separate the left driveshaft from the transaxle by prying with a bar inserted between the shaft and the case.

### Caution

- Do not damage the oil seal.
- Do not separate the driveshaft by pulling the disc plate.




06U0J1-015

2. Install the **SST** to the differential side gear.

### Note


- Failure to install the **SST** may cause the differential side gears to become mispositioned.



06U0J1-016

### Engine mount No.4

Suspend the engine with the **SST**.



06U0J1-017

### Transaxle

1. Lean the engine toward the transaxle.
2. Support the transaxle with a jack.
3. Remove the remaining transaxle mounting bolts.
4. Remove the transaxle.


### DISASSEMBLY

#### Precaution

1. Clean the transaxle exterior thoroughly with steam or cleaning solvents before disassembly.
2. Clean the removed parts with cleaning solvent, and dry with compressed air. (Except sealed bearings.)  
Clean out all holes and passages with a compressed air, and check that there are no obstructions.
3. Wear eye protection when using compressed air to clean components.


#### Step 1

1. Measure the thrust clearance between 5th gear and transaxle case referring to **Preinspection**.
2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.



- |   |   |   |
|---|---|---|
| 1. Rear cover   | 15. Lock bolt, and ball and spring  | 30. Primary shaft gear assembly<br>Disassembly ... page J1-19   |
| 2. Locknut<br>Removal ..... page J1-13                                | 16. Transaxle case assembly<br>Removal ..... page J1-14<br>Disassembly ... page J1-15           | 31. Secondary shaft gear assembly<br>Disassembly ... page J1-19 |
| 3. Locknut  | 17. Magnet  | 32. Differential assembly<br>Disassembly ... page J1-22         |
| 4. Primary reverse synchronizer gear<br>Inspection ..... page J1-23   | 18. Reverse idler shaft   | 33. Clutch housing<br>Disassembly ... page J1-15                |
| 5. Secondary reverse synchronizer gear<br>Inspection ..... page J1-23 | 19. Reverse idler gear<br>Inspection ..... page J1-24   | 34. Synchronizer key spring<br>Inspection ..... page J1-24      |
| 6. Roll pin   | 20. Lock bolt   | 35. Clutch hub sleeve<br>Inspection ..... page J1-24            |
| 7. Shift fork   | 21. Shift rod (5th/Rev.) and clip   | 36. Synchronizer key<br>Inspection ..... page J1-24             |
| 8. Clutch hub assembly  | 22. Shift rod end (5th/Rev.)  | 37. Clutch hub<br>Inspection ..... page J1-23                   |
| 9. Synchronizer ring<br>Inspection ..... page J1-23                   | 23. Pin   |   |
| 10. Primary 5th gear<br>Inspection ..... page J1-23                   | 24. Crank lever shaft   |   |
| 11. Gear sleeve   | 25. O-ring  |   |
| 12. Secondary 5th gear<br>Inspection ..... page J1-23                 | 26. Crank lever assembly  |   |
| 13. Lock bolt   | 27. Shift fork and shift rod assembly<br>Removal ..... page J1-14<br>Disassembly ... page J1-19 |   |
| 14. Guide bolt  | 28. Steel ball  |   |
|   | 29. Spring  |   |

16U0J1-004




16U0J1-005

**Preinspection  
5th gear thrust clearance**

1. Measure the 5th gear thrust clearance with a dial indicator.

**Clearance: 0.10—0.22mm (0.0039—0.0087 in)  
Maximum : 0.27mm (0.0106 in)**


2. If the clearance exceeds the the maximum, check the contact surfaces of 5th gear and the clutch hub. Replace worn or damaged parts.



06U0J1-020


**Disassembly Note  
Locknut**

1. Mount the transaxle on the **SST**.



06U0J1-021


2. Lock the primary shaft with the **SST**.
3. Shift to 1st or 2nd gear.
4. Remove the locknut.



96U07A-007

### Transaxle case assembly


1. Remove the lock bolt ①, the guide bolt ②.
2. Remove the lock bolt, spring and ball ③.
3. Remove the transaxle case installation bolts, and remove the transaxle case.



86U07A-039

### Shift fork and shift rod assembly

1. Align the ends of the interlock sleeve and of the control lever, then turn the shift rod counter clockwise.
2. While holding the 1st-2nd shift fork with one hand and the 3rd-4th shift fork with the other, raise them both at the same time and shift each of the clutch hub sleeves.




76U07A-227

3. Lift the control end and remove the steel ball, and, at the same time, remove the shift rod from the clutch housing.
4. Separate the shift rod and shift fork assembly from each of the clutch hub sleeves.


Step 2

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.




16U0J1-006


- |                          |                                      |                                |
|--------------------------|--------------------------------------|--------------------------------|
| 1. Bolt, nut             | 19. Bolt                             | 31. Reverse lever shaft        |
| 2. Joint                 | 20. Bleeder cover                    | 32. Reverse lever              |
| 3. Bearing outer race    | 21. Bleeder                          | 33. Drain plug and washer      |
| Removal ..... page J1-16 | 22. Bolt                             | 34. Neutral switch             |
| 4. Oil seal              | 23. Speedometer driven gear assembly | 35. Bearing outer race         |
| 5. Bearing outer race    | 24. O-ring                           | Removal ..... page J1-16       |
| 6. Funnel                | 25. Roll pin                         | 36. Diaphragm spring           |
| 7. Bolts                 | 26. Driven gear                      | 37. Adjust shim                |
| 8. Guide plate           | 27. Gear case                        | 38. Bearing outer race(s)      |
| 9. Pipe                  | 28. Oil seal                         | Removal ..... page J1-16       |
| 10. Bolt                 | Do not remove if not necessary       | 39. Adjust shim(s)             |
| 11. Change arm           | Replace                              | 40. Oil seal                   |
| 12. Roll pin             | (On-vehicle) .. page J1-16           | Do not remove if not necessary |
| 13. Change rod           | 29. Bearing outer race               | Replace                        |
| 14. Boot                 | Removal ..... page J1-16             | (On-vehicle) .. page J1-16     |
| 15. Spring               | 30. Roll pin                         | 41. Back-up light switch       |
| 16. Reverse gate         | Removal ..... page J1-16             | 42. Oil passage                |
| 17. Selector             |                                      |                                |
| 18. Oil seal             |                                      |                                |




06U0J1-085




06U0J1-086



76G07A-020



86U07A-044



06U0J1-023

### Disassembly Note Bearing outer race (clutch housing)

#### Note

- If it is difficult to remove the bearing outer race, remove it with the SST.

Remove the bearing outer race with the SST.

### Bearing outer races (transaxle case)

#### Note

- If it is difficult to remove the bearing outer races, remove it with the SST.

Remove the bearing outer races with the SST.

### Roll pin

Align the groove for removal of the clutch housing pin with the position of the roll pin, then tap the pin out using a pin punch.

### Bearing outer race (differential)

Remove the bearing outer race with the SST.


### On-vehicle replacement

#### Oil seals

Jack up the vehicle, support it on safety stands, and then drain the transaxle oil. Next, use the following procedure to replace the driveshaft oil seals:

1. Remove the front wheel(s).
2. Remove the splash shield(s).
3. Separate the front stabilizer from the lower arm.






86U07A-009

- Remove the clinch bolt and pull the lower arm downward. Separate the knuckle from the lower arm ball-joint.

**Note**

- **Be careful not to damage the ball-joint dust boot.**

- Remove the cotter pin then disconnect the tie-rod end with the **SST**.




06U0J1-024

**Caution**


- **Do not damage the oil seal.**
- **Do not separate the driveshaft by pulling the disc plate.**

- Separate the left driveshaft from the transaxle by prying with a bar inserted between the shaft and the case.



86U07A-011

- Remove the oil seal with a flat-tipped screwdriver.




86U07A-012

- Tap the new oil seal into the transaxle case with the **SST**.


**Note**

- **Tap in until the oil seal installer contacts the case.**
- **Coat the oil seal lip with transaxle oil.**




86U07A-013


- Replace the driveshaft end clip with a new one. Insert the clip with the gap at the top of the groove.




86U07A-014



86U07A-015



06U0J1-090



16U0J1-029

10. Install the driveshaft as follows:
  - (1) Pull the front hub outward, then fit the driveshaft into the transaxle.
  - (2) Insert the driveshaft into the transaxle by pushing on the wheel hub assembly.

**Note**

- Be careful not to damage the oil seal.
- After installation is finished, pull the front hub slowly outward to check that the driveshaft is held securely by the clip.

11. Install the lower arm ball-joint to the knuckle, and tighten the clinch bolt.

**Tightening torque:**

43—54 N·m (4.4—5.5 m·kg, 32—40 ft·lb)

12. Install the tie-rod end and new cotter pin.

**Tightening torque:**

29—44 N·m (3.0—4.5 m·kg, 22—33 ft·lb)

13. Adjust and tighten the stabilizer.

**Tightening torque:**

16—23 N·m (1.6—2.3 m·kg, 12—17 ft·lb)

**Dimension:** 20.1 ± 2mm (0.79 ± 0.08 in)

14. Install the drain plug.

**Tightening torque:**

39—59 N·m (4.0—6.0 m·kg, 29—43 ft·lb)

15. Install the wheel.

**Tightening torque:**

88—118 N·m (9.0—12.0 m·kg, 65—87 ft·lb)

16. Add the correct quantity of the specified oil.

**Type:**

All-season ATF: DEXRON-II

Above -18°C (0°F):


API: GL-4 or GL-5

SAE 80W-90 or SAE 90

**Capacity:** 3.35 liters (3.5 US qt, 2.9 Imp qt)


Step 3

1. Disassemble in the order shown in the figure, referring to **Disassembly Note**.




- |   |  |   |
|---|--|---|
| 1. Shift fork (3rd/4th)   | 17. Synchronizer key spring<br>Inspection ..... page J1-24             | 27. Synchronizer ring<br>Inspection ..... page J1-23                              |
| 2. Interlock sleeve   | 18. Synchronizer key<br>Inspection ..... page J1-24                    | 28. Retaining ring  |
| 3. Roll pin   | 19. Clutch hub<br>Inspection ..... page J1-23                          | 29. Clutch hub assembly<br>(3rd/4th)<br>Removal ..... page J1-21                  |
| 4. Control end  | 20. Clutch hub sleeve (reverse<br>gear)<br>Inspection ..... page J1-24 | 30. Synchronizer key spring<br>Inspection ..... page J1-24                        |
| 5. Shift fork (1st/2nd)   | 21. Synchronizer ring<br>Inspection ..... page J1-23                   | 31. Synchronizer key<br>Inspection ..... page J1-24                               |
| 6. Roll pin   | 22. Secondary 1st gear<br>Removal ..... page J1-21                     | 32. Clutch hub<br>Inspection ..... page J1-23                                     |
| 7. Control lever  | Inspection ..... page J1-23  | 33. Clutch hub sleeve<br>Inspection ..... page J1-24                              |
| 8. Control rod  | 23. Bearing inner race<br>Removal ..... page J1-21                     | 34. Synchronizer ring<br>Inspection ..... page J1-23                              |
| 9. Bearing inner race<br>Removal ..... page J1-20<br>Inspection ..... page J1-25  | 24. Secondary shaft<br>Inspection ..... page J1-23                     | 35. Primary 3rd gear<br>Inspection ..... page J1-23                               |
| 10. Secondary 4th gear<br>Inspection ..... page J1-23                             | 25. Bearing inner race<br>Removal ..... page J1-21                     | 36. Bearing inner race<br>Removal ..... page J1-21<br>Inspection ..... page J1-25 |
| 11. Retaining ring  | 26. Primary 4th gear<br>Inspection ..... page J1-23                    | 37. Primary shaft<br>Inspection ..... page J1-23                                  |
| 12. Secondary 3rd gear<br>Removal ..... page J1-20<br>Inspection ..... page J1-23 |  |   |
| 13. Secondary 2nd gear<br>Removal ..... page J1-20<br>Inspection ..... page J1-23 |  |   |
| 14. Synchronizer ring<br>Inspection ..... page J1-23                              |  |   |
| 15. Retaining ring  |  |   |
| 16. Clutch hub assembly<br>Removal ..... page J1-21                               |  |   |

16U0J1-007



06U0J1-028



86U07A-047

### Disassembly note

#### Bearing inner race (secondary 4th gear end)

Remove the bearing inner race and secondary 4th gear with the **SST**.

#### Caution


- Hold the shaft with one hand so that it does not fall.

#### Secondary 3rd gear and 2nd gear

1. Remove the retaining ring.
2. Shift the gears to 1st gear.
3. Remove the secondary 3rd gear and 2nd gear with the **SST**.

#### Caution

- Hold the shaft with one hand so that it does not fall.




16U0J1-008

**Clutch hub assembly and Secondary 1st gear**

1. Remove the retaining ring.
2. Remove the clutch hub assembly (reverse gear) and 1st gear as shown in the figure.

**Caution**

- Hold the shaft with one hand so that it does not fall.




86U07A-049

**Bearing inner race (secondary shaft end)**

Remove the bearing inner race with the SST.

**Caution**

- Hold the shaft with one hand so that it does not fall.




06U0J1-030

**Bearing inner race (primary 4th gear end)**

Remove the bearing inner race with the SST.

**Caution**

- Hold the shaft with one hand so that it does not fall.




86U07A-051

**Clutch hub assembly (3rd/4th)**

1. Remove the retaining ring.
2. Remove the clutch hub assembly with the SST.

**Caution**

- Hold the shaft with one hand so that it does not fall.



86U07A-052

**Bearing inner race (primary shaft end)**

Remove the bearing inner race with the SST.

**Caution**

- Hold the shaft with one hand so that it does not fall.


### Step 4 (Differential)

1. Inspect side gears and pinion gears for backlash. (Refer to page J1-27.)

#### Caution

- Do not remove inner races if not necessary.

2. Disassemble in the order shown in the figure, referring to **Disassembly Note**.




16U0J1-009

1. Roll pin
2. Pinion shaft
3. Pinion gear
4. Thrust washer
5. Side gear

6. Thrust washer
7. Side bearing inner race  
Removal ..... page J1-22
8. Speedometer drive gear  
Inspection ..... page J1-25

9. Side bearing inner race  
Removal ..... page J1-22
10. Gear case




06U0J1-032

#### Disassembly note

**Side bearing inner race (side opposite ring gear)**  
Remove the race from the gear case with the **SST**.

#### Caution


- Hold the gear case with one hand so that it does not fall.



86U07A-055

#### Side bearing inner race (ring gear side)

Remove the race with a combination of parts from the **SST**.




06U0J1-033

**INSPECTION**

Check the following parts, and replace if necessary.

**1st, 2nd, 3rd, 4th, and 5th gears**

1. Worn or damaged synchronizer cone.
2. Worn or damaged hub sleeve coupling.
3. Worn or damaged teeth.
4. Worn or damaged inner surface or end surface of gears.



16U0J1-010


**Synchronizer Ring**

1. Engagement with gear.
2. Worn or damaged teeth.
3. Worn or damaged tapered surface.
4. Clearance from side of gear.

**Clearance: 1.5mm (0.059 in)**  
**Minimum : 0.8mm (0.032 in)**

**Note**


- Press the synchronizer ring uniformly against the gear and measure around the circumference.
- If the clearance is less than specified, replace the synchronizer ring or gear.



63U07A-070

**Clutch Hub**

1. Worn or damaged splines.
2. Worn or damaged synchronizer key groove.
3. Worn end surface.
4. Operation of the hub sleeve when it is installed.




96U07A-050

**Primary Shaft Gear and Secondary Shaft Gear**

1. Worn or damaged gear contact surface.
2. Worn or damaged splines.
3. Worn teeth.
4. Clogged oil passage.
5. Shaft gears' run-out.

**Primary shaft gear runout: 0.05mm (0.002 in) max.**




96U07A-051



**Secondary shaft gear runout:  
 0.015mm (0.0006 in) max.**

**Note**


- If the shaft gear is replaced, adjust the bearing preload. (Refer to page J1-33.)




16U0J1-011



16U0J1-012



63U07A-072



96U07A-012

### 6. Oil clearance between shaft gears and gears.

#### Oil Clearance

mm (in)

	Shaft (A) (outer diameter)	Gear (B) (inner diameter)	Sleeve (C) (outer diameter)	Oil (D) Clearance
3rd Gear	35.970 (1.416) —35.945 (1.415)	36.025 (1.418) —36.000 (1.417)	—	(D) = (B) — (A) 0.03 (0.001) — 0.08 (0.003)
4th Gear	30.970 (1.219) —30.945 (1.218)	31.025 (1.222) —31.000 (1.221)	—	(D) = (B) — (A) 0.03 (0.001) — 0.08 (0.003)
5th Gear	—	34.025 (1.340) —34.000 (1.339)	33.970 (1.337) —33.945 (1.336)	(D) = (B) — (C) 0.03 (0.001) — 0.08 (0.003)
1st Gear	39.470 (1.554) —39.445 (1.553)	39.525 (1.556) —39.500 (1.555)	—	(D) = (B) — (A) 0.03 (0.001) — 0.08 (0.003)
2nd Gear	34.970 (1.377) —34.945 (1.376)	35.025 (1.379) —35.000 (1.378)	—	(D) = (B) — (A) 0.03 (0.001) — 0.08 (0.003)

#### Clutch Hub Sleeve

1. Worn or damaged hub splines.
2. Worn or damaged sleeve fork groove.
3. Clearance between sleeve and shift fork.

#### Clearance

mm (in)

	Standard	Limit
1st—2nd	0.08 (0.003) — 0.228 (0.009)	0.728 (0.029)
3rd—4th	0.1 (0.004) — 0.5 (0.020)	1.000 (0.039)
5th	0.15 (0.059) — 0.458 (0.018)	0.958 (0.038)

#### Synchronizer Key and Spring


1. Worn key.
2. Bent spring.

#### Reverse Idle Gear

1. Worn or damaged bushing.
2. Worn or damaged teeth.
3. Worn or damaged reverse shift lever coupling groove.
4. Clearance between sleeve and reverse shift lever.

**Standard : 0.095—0.318mm (0.004—0.013 in)**  
**Maximum: 0.5mm (0.020 in)**






63U07A-075

**Bearing**

1. Roughness or noise while turning
2. Worn or damaged outer race or rollers

**Caution**

- **Replace the bearing, the outer race, and the inner race as a unit.**
- **If the bearing is replaced, adjust the preload.**



06U0J1-034

**Speedometer Driven Gear Assembly**

Worn or damaged teeth.

**Speedometer Drive Gear**

Worn or damaged teeth.


### ASSEMBLY

#### Precaution

1. All O-rings and gasket must be replaced with the new ones included in the overhaul kit.
2. Before assembly, make sure all parts are completely clean.
3. Assemble the parts within 10 minutes after applying sealant. Allow all sealant to cure at least 30 minutes after assembly before filling the transaxle with transaxle oil.
4. If the clutch housing or transaxle case is replaced, adjust the bearing preload of the shaft gears and the preload of the differential side bearings.
5. If the bearing inner races are replaced, assemble new bearing outer races.


#### Step 1 (Differential)

1. Assemble in the order shown in the figure, referring to **Assembly Note**.



16U0J1-013

- |                              |                              |                              |
|------------------------------|------------------------------|------------------------------|
| 1. Gear case                 | 5. Thrust washer             | 8. Roll pin                  |
| 2. Speedometer drive gear    | 6. Pinion gear               | Installation..... page J1-27 |
| Installation..... page J1-26 | Installation..... page J1-27 | 9. Thrust washer             |
| 3. Side bearing inner race   | 7. Pinion shaft              | 10. Side gear                |
| Installation..... page J1-26 | Installation..... page J1-27 | Installation..... page J1-27 |
| 4. Side bearing inner race   |                              |                              |
| Installation..... page J1-27 |                              |                              |




06U0J1-036

#### Assembly note

**Speedometer drive gear and Side bearing inner race**  
Install the speedometer drive gear and the new bearing inner race with the SST.

#### Note

- Press to 19,620 N (2,000 kg, 4,400 lb).




06U0J1-037

**Side bearing inner race**

Install the new bearing inner race with the **SST**.

**Note**


- Press to 19,620 N (2,000 kg, 4,400 lb).



06U0J1-038

**Pinion gears and pinion shaft**


1. Install the thrust washers and pinion gears.
2. Install the pinion shaft.



16U0J1-014

**Roll pin and side gears**

1. Install the roll pin, then crimp it so that it cannot come out of the gear case.
2. Install the thrust washers and the side gears.



06U0J1-040

**Backlash of side gear and pinion gear**

1. Install the left and right driveshafts in the differential assembly.
2. Support the driveshafts on V-blocks as shown in the figure.
3. Measure the backlash of both pinion gears.
4. If not, reassemble the differential assembly.


**Backlash: 0—0.1mm (0—0.004 in)**

### Step 2

1. Assemble in the order shown in the figure, referring to **Assembly Note**.




APPLY SPECIFIED OIL TO INDIVIDUAL PARTS



- |   |   |  |
|---|---|--|
| 1. Clutch hub<br>Installation..... page J1-29         | 13. Bearing inner race<br>Installation..... page J1-30  | 25. Secondary 2nd gear<br>Installation..... page J1-31 |
| 2. Synchronizer key                                   | 14. Clutch hub<br>Installation..... page J1-29          | 26. Secondary 3rd gear<br>Installation..... page J1-31 |
| 3. Clutch hub sleeve                                  | 15. Synchronizer key                                    | 27. Retaining ring                                     |
| 4. Synchronizer spring                                | 16. Clutch hub sleeve                                   | 28. Secondary 4th gear<br>Installation..... page J1-32 |
| 5. Primary shaft                                      | 17. Synchronizer spring                                 | 29. Bearing inner race<br>Installation..... page J1-32 |
| 6. Bearing inner race<br>Installation..... page J1-30 | 18. Secondary shaft                                     | 30. Control rod  |
| 7. Primary 3rd gear<br>Installation..... page J1-30   | 19. Bearing inner race<br>Installation..... page J1-31  | 31. Control lever                                      |
| 8. Synchronizer ring<br>Installation..... page J1-30  | 20. Secondary 1st gear<br>Installation..... page J1-31  | 32. Roll pin   |
| 9. Clutch hub assembly (3rd<br>and 4th gear)          | 21. Synchronizer ring<br>Installation..... page J1-31   | 33. Shift fork (1st and 2nd gears)                     |
| 10. Retaining ring                                    | 22. Clutch hub assembly<br>Installation..... page J1-31 | 34. Control end  |
| 11. Synchronizer ring<br>Installation..... page J1-30 | 23. Retaining ring                                      | 35. Roll pin   |
| 12. Primary 4th gear<br>Installation..... page J1-30  | 24. Synchronizer ring<br>Installation..... page J1-31   | 36. Interlock sleeve<br>Installation..... page J1-32   |
|   |   | 37. Shift fork (3rd and 4th gears)                     |

06U0J1-042




06U0J1-043

**Assembly note**  
**Clutch hub**

Install the synchronizer key spring in the clutch hub with the hook in the groove. This holds the three synchronizer keys in place.

**Note**

- The sizes of the synchronizer keys are different.




06U0J1-044

**Specification:**

mm (in)

	①	②	③
1st/2nd	19 (0.75)	14.2 (0.56)	4.25 (0.17)
3rd/4th 5th/Rev.	17 (0.67)	12.2 (0.48)	4.25 (0.17)




06U0J1-045

**Primary Shaft Gear  
Bearing inner race**

Install the new bearing inner race with the **SST**.

**Note**

- Press to 19,620 N (2,000 kg, 4,400 lb).




06U0J1-046

**Primary 3rd gear, synchronizer ring and clutch hub assembly**

Install the primary 3rd gear, synchronizer ring, and clutch hub assembly with the **SST**.

**Note**

- Press to 19,620 N (2,000 kg, 4,400 lb).
- Align the synchronizer ring groove and clutch housing hub key when installing.




06U0J1-047

**Synchronizer ring, primary 4th gear and bearing inner race**

1. Install the synchronizer ring, primary 4th gear, and bearing inner race with the **SST**.

**Note**


- Press to 19,620 N (2,000 kg, 4,400 lb).



06U0J1-048

2. Measure the clearance between the primary 3rd gear and primary 2nd gear.


**Clearance: 0.05—0.20mm (0.0020—0.0079 in)**  
**Maximum: 0.25mm (0.0098 in)**



16U0J1-015

3. Measure the clearance between the primary 4th gear and bearing inner race.

**Clearance: 0.165—0.365mm (0.0065—0.0144 in)**  
**Maximum: 0.415mm (0.0163 in)**




06U0J1-050

**Bearing inner race**

Install the new bearing inner race with the **SST**.

**Note**


- Press to 19,620 N (2,000 kg, 4,400 lb).



76F07A-048

**Note**

- The size of the 1st, 2nd, and 3rd/4th synchronizer rings is the same. Be careful when installing them. The 2nd ring has the larger cut-out as shown in the illustration.



06U0J1-051


**Secondary Shaft Gear**

**Secondary 1st gear, synchronizer ring and clutch hub assembly**

1. Assemble the secondary 1st gear, synchronizer ring, and clutch hub assembly (reverse gear), as shown in the figure.

**Note**

- Align the synchronizer ring, groove and clutch housing hub key when installing.




06U0J1-052

2. Press on the clutch hub assembly (reverse gear) with the **SST**.

**Note**

- Press to 19,620 N (2,000 kg, 4,400 lb).



06U0J1-053

**Synchronizer ring, secondary 2nd gear and secondary 3rd gear**


1. Install the synchronizer ring and secondary 2nd gear.
2. Install the secondary 3rd gear with the **SST**.

**Note**

- Press to 19,620 N (2,000 kg, 4,400 lb).

**Secondary 4th gear and bearing inner race**


1. Install the secondary 4th gear and bearing inner race.



2. Measure the clearance between the secondary 1st gear and differential drive gear.

**Clearance: 0.050—0.280mm (0.0020—0.0110 in)**


**Maximum: 0.33mm (0.0130 in)**



3. Measure the clearance between the secondary 2nd gear and secondary 3rd gear.


**Clearance: 0.175—0.455mm (0.0069—0.0179 in)**

**Maximum: 0.505mm (0.0199 in)**



**Interlock sleeve**


Install both shift forks and the interlock sleeve, as in the figure.





**Step 3**

1. Select the adjust shim(s), referring to Adjustment of Bearing Preload.
2. Assemble in the order shown in the figure, referring to **Assembly Note**.




- |                              |                              |                              |
|------------------------------|------------------------------|------------------------------|
| 1. Gear case                 | 14. Bearing outer race       | 26. Spring                   |
| 2. Speedometer driven gear   | Installation..... page J1-37 | Installation..... page J1-37 |
| 3. O-ring                    | 15. Oil seal                 | 27. Boot                     |
| 4. Roll pin                  | Installation..... page J1-37 | Installation..... page J1-37 |
| 5. Oil passage               | 16. Funnel                   | 28. Change rod               |
| 6. Neutral switch            | 17. Bearing outer race       | Installation..... page J1-37 |
| 7. Drain plug and washer     | 18. Oil seal                 | 29. Roll pin                 |
| 8. Back-up light switch      | 19. Bearing outer race       | 30. Change arm               |
| 9. Oil seal                  | 20. Bearing outer race       | 31. Pipe                     |
| Installation..... page J1-37 | 21. Bleeder                  | 32. Guide plate              |
| 10. Adjust shim(s)           | 22. Bleeder cover            | 33. Reverse lever            |
| 11. Bearing outer race(s)    | 23. Oil seal                 | 34. Reverse lever shaft      |
| 12. Adjust shim              | 24. Selector                 | 35. Roll pin                 |
| Installation..... page J1-37 | Installation..... page J1-37 | 36. Speedometer driven gear  |
| 13. Diaphragm spring         | 25. Reverse gate             | assembly                     |
| Installation..... page J1-37 | Installation..... page J1-37 | 37. Joint                    |
|                              |                              | 38. Bolt, nut                |


16U0J1-016

### Bearing Preload Adjustment


Adjust the bearing preload by selecting adjust shim(s).




06U0J1-059




83U07A-033




86U07A-251




86U07A-252



86U07A-253



86U07A-254



86U07A-255

1. Install the primary and secondary shaft bearing outer races into the transaxle case (diaphragm springs and shims removed).
2. After mounting the clutch housing onto the transaxle hanger, and set the differential bearing outer race into the clutch housing.  
Next, position a piece of pipe against the outer race and tap in with a hammer until it contacts the clutch housing.
3. Assemble the outer races into the **SST** (selector) as shown in the figure.

**Note**

- Turn the selector to eliminate the gap indicated by the arrow in the figure.

4. Set the differential assembly onto the clutch housing, then mount the bearing outer race and the selector on the differential.  
Set the assembled selectors for the primary and secondary shaft in the clutch housing.  
Mount the shaft gear assemblies as shown in the figure.


5. Set the **SST** (collars) in the positions shown in the figure.

Install the transaxle case then tighten the **SST** (bolts) to the specified torque.

**Tightening torque:**

**37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)**

6. To seat the bearings, mount the **SST** (bars) on parts (A) and (B) of the selector, and then turn the selector so the gap is widened.  
Then turn it in the reverse direction until the gap is eliminated.



86U07A-256

- Manually expand the selector until the selector no longer turns by hand.


**Note**

- Check that each shaft turns smoothly.

- Use a feeler gauge and measure the gap in the selector.

**Note**

- Measure the gap around the entire circumference of the selector.



16U0J1-017

- Take the maximum reading and determine the shim to be used as follows:

**< Primary shaft adjust shim >**

- Subtract the diaphragm spring thickness (0.70mm [0.0276 in]) from the gap determined in Step 8.
- Select the closest thicker shim from the table.

**Example**

$$1.22\text{mm (0.0480 in)} - 0.70\text{mm (0.0276 in)} = 0.52\text{mm (0.0205 in)}$$

**Shim: 0.50mm (0.020 in)**

**< Secondary shaft adjust shim >**

- Subtract the diaphragm spring thickness (0.70mm [0.0276 in]) from the gap determined in Step 10.
- Select the closest thicker shim from the table.

**Example**

$$1.22\text{mm (0.0480 in)} - 0.70\text{mm (0.0276 in)} = 0.52\text{mm (0.0205 in)}$$

**Shim: 0.55mm (0.022 in)**


**Note**

- Use a maximum of two shims.

Thickness (Shaft gears)	mm (in)
0.20 (0.008)	0.50 (0.020)
0.25 (0.010)	0.55 (0.022)
0.30 (0.012)	0.60 (0.024)
0.35 (0.014)	0.65 (0.026)
0.40 (0.016)	0.70 (0.028)
0.45 (0.018)	

16U0J1-018


- Install the **SST**.




76G07A-609

- Adjust the selector with the **SST** until the specified preload is obtained.

**Preload: 0.5 N-m (5 cm-kg, 4.3 in-lb)**




76G07A-610




76G07A-611

Thickness		mm (in)	
0.10 (0.004)		0.70 (0.028)	
0.20 (0.008)		0.75 (0.030)	
0.25 (0.010)		0.80 (0.031)	
0.30 (0.012)		0.85 (0.033)	
0.35 (0.014)		0.90 (0.035)	
0.40 (0.016)		0.95 (0.037)	
0.45 (0.018)		1.00 (0.039)	
0.50 (0.020)		1.05 (0.041)	
0.55 (0.022)		1.10 (0.043)	
0.60 (0.024)		1.15 (0.045)	
0.65 (0.026)		1.20 (0.047)	


96U07A-016



06U0J1-060



16U0J1-019



06U0J1-062

12. Use a feeler gauge to measure the gap in the selector for the differential.

**Note**

- Measure the gap around the entire circumference of the selector

13. Add **0.15mm (0.0059 in)** to the measured clearance and select the combination of shims closest in value to that measurement.

See the table below for available shim sizes.

**Example: 0.32mm (0.013 in)**

**0.32mm (0.013 in) + 0.15mm (0.006 in) = 0.47mm (0.019 in).**

**So the nearest shim (on the thick side) to 0.47mm (0.019 in) is 0.50mm (0.020 in).**

**Note**

- Use a maximum of two shims.

14. Remove the **SST** and transaxle case.

15. Remove the selectors, the primary shaft assembly and the differential.

16. Remove the bearing outer races.

**Assembly note**

**Oil seals**

Install the new oil seals with the **SST**.

**Adjust shims, diaphragm spring, and bearing outer races**

Install the adjust shims, diaphragm spring, and bearing outer races.


**Note**

- Install the diaphragm spring as shown in the figure.

**Change rod, boot, spring, reverse gate, and selector**


**Note**

- Install the boot with the air bleed downward as shown in the figure.



06U0J1-063

Install the change rod ①, the boot ②, the spring ③, the reverse gate ④, and selector ⑤, as shown.



06U0J1-087


### Rechecking of bearing preload

Check the shaft gears and the differential bearing preload.

#### Note

- Check that the correct adjust shims were selected.
- If the bearing preload is not within specification, adjust again.

1. Set the primary shaft gear and the differential into the clutch housing.
2. Install the transaxle case, and tighten to the specified torque.



16U0J1-020


#### Tightening torque:

**37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)**

3. Connect the **SST** and install it through the driveshaft hole.
4. Hook a spring scale to the attachment and measure the preload.

#### Preload:

**1.4—2.0 N·m (14—20 cm·kg, 12.2—17.4 in·lb)**



96U07A-018


5. Remove the **SST**.
6. With the transaxle facing in the direction shown in the figure, install the **SST** to the primary shaft gear.
7. Measure the preload.

#### Preload:

**0.1—0.25 N·m (1.0—2.5 cm·kg, 0.87—2.17 in·lb)**

#### Note

- Extend the handle fully and hook the pull scale to the end of the handle.



16U0J1-021

8. Remove the **SST**, transaxle case, primary shaft gear and differential.
9. Install the secondary shaft gear and transaxle case then tighten to the specified torque.

#### Tightening torque:

**37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)**


10. Check the secondary shaft preload with the **SST**.

#### Preload:

**0.2—0.4 N·m (2.0—4.0 cm·kg, 1.7—3.5 in·lb)**


**Step 4**

1. Assemble in the order shown in the figure, referring to **Assembly Note**.



- |  |   |   |
|--|---|---|
| 1. Clutch hub  | 13. Crank lever shaft<br>Installation..... page J1-41             | 23. Gear sleeve   |
| 2. Synchronizer key  | 14. Pin   | 24. Primary 5th gear                                    |
| 3. Clutch hub sleeve   | 15. Shift rod end (5th/Rev.)<br>Installation..... page J1-41      | 25. Synchronizer ring                                   |
| 4. Synchronizer spring   | 16. Shift rod (5th/Rev.) and clip<br>Installation..... page J1-41 | 26. Clutch hub assembly<br>Installation..... page J1-42 |
| 5. Ring gear and differential<br>assembly                                | 17. Reverse idler gear<br>Installation..... page J1-41            | 27. Shift fork<br>Installation..... page J1-42          |
| 6. Secondary shaft gear<br>assembly<br>Installation..... page J1-40      | 18. Reverse idler shaft<br>Installation..... page J1-41           | 28. Roll pin  |
| 7. Primary shaft gear assembly<br>Installation..... page J1-40           | 19. Magnet  | 29. Secondary reverse<br>synchronizer gear              |
| 8. Spring  | 20. Clutch housing<br>Installation..... page J1-41                | 30. Primary reverse synchronizer<br>gear                |
| 9. Steel ball  | 21. Transaxle case assembly<br>Installation..... page J1-41       | 31. Locknut<br>Installation..... page J1-42             |
| 10. Shift fork and shift rod<br>assembly<br>Installation..... page J1-40 | 22. Secondary 5th gear<br>Installation..... page J1-42            | 32. Locknut<br>Installation..... page J1-42             |
| 11. Crank lever assembly<br>Installation..... page J1-41                 |   | 33. Rear cover  |
| 12. O-ring   |   |   |

16U0J1-022




06U0J1-066

### Assembly note

#### Primary shaft gear assembly and Secondary shaft gear assembly


Install the primary shaft gear assembly and the secondary shaft gear assembly together.



06U0J1-067

### Shift fork and Shift rod assembly


1. Shift to 2nd gear and position the shift fork and shift rod assembly as shown.



06U0J1-068


2. Insert the spring seat and spring into the reverse lever shaft, install the steel ball, and place a scraper knife so that it contacts the steel ball.
3. With the edge of the control end against the knife, when the control end is pushed in the direction of the arrow in the figure so that the ball goes into the shaft, the rod will at the same time line up with the shift rod coupling hole in the clutch housing.





06U0J1-069

4. Set each clutch hub sleeve to the neutral position, and tap the shift rod from above so that the steel ball goes into the center groove (of the 3 grooves in the control end).
5. Pull the ball part of the control end forward so that the steel ball goes into the detent in the groove.




06U0J1-070

**Crank lever assembly and Crank lever shaft**

1. Fit the crank lever in between the change arm and the control end, and connect the crank lever shaft to the crank lever.
2. Align the pin holes of the crank lever shaft and the clutch housing, and insert the pin.

**Note**

- Use a new O-ring for the crank lever shaft.




06U0J1-071

**Shift rod end and Shift rod**

Install the shift rod end (1) and the shift rod (2), and tighten the shift rod end mounting bolt.

**Note**


- The mark (indicated by the arrow in the figure) and the shift rod end mounting bolt hole must be in the same direction.



06U0J1-072

**Reverse idle gear and Reverse idle shaft**


1. Install the reverse idle gear and the reverse idle shaft.
2. Connect the magnet to the clutch housing.
3. Align the end of the interlock sleeve with the control lever indicated by the arrow, and, at the same time, face the reverse idle shaft screw hole in the direction shown in the figure.



06U0J1-073

**Clutch housing and Transaxle case**


1. Apply a thin coat of sealant to the contact surfaces of the clutch housing and transaxle case, tighten the transaxle case installation bolts to the specified torque.
2. Insert the **SST** to driveshaft coupling hole.



06U0J1-074

### Secondary 5th gear


Install the secondary 5th gear as shown.



06U0J1-075

### Clutch hub assembly and Shift fork

Install the clutch hub assembly and the shift fork together.



06U0J1-076

### Locknut


1. Shift to 1st gear.
2. Lock the primary shaft with the **SST**.
3. Tighten new locknuts.

### Tightening torque:


**128—196 N·m (13.0—20.0 m·kg, 94—145 ft·lb)**

4. Stake the locknuts.







06U0J1-078




96U07A-040



76F07A-062



06U0J1-079



86U07A-214

### Installation note

1. Attach rope at 2 places on the transaxle and place a board on the jack and position the transaxle on it.

### Caution

- The transaxle is not well balanced; be careful when positioning on the jack.

2. Move the transaxle into the place and attach the rope (attached to the transaxle in step 1) to the SST.

3. Install the transaxle onto the engine.

### Note

- Lift the transaxle using the jack to pull the rope.

### Tightening torque:

89—117 N·m (9.1—11.9 m·kg, 66—86 ft·lb)

4. Install engine mount No.4.

### Tightening torque

Ⓐ : 64—89 N·m (6.5—9.1 m·kg, 47—66 ft·lb)

Ⓑ : 67—93 N·m (6.8—9.5 m·kg, 49—69 ft·lb)

5. Install engine mount No.2.

### Tightening torque

Ⓐ : 37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)

Ⓑ : 67—93 N·m (6.8—9.5 m·kg, 49—69 ft·lb)


6. Install the crossmember and the left side lower arm as an assembly.

### Tightening torque:

Bolts, 36—54 N·m (3.7—5.5 m·kg, 27—40 ft·lb)

Nut, 75—93 N·m (7.6—9.5 kg, 55—69 ft·lb)

7. Remove the jack and take off the rope.
8. Remove the SST.



16U0J1-023

9. Install the starter and harnesses.


**Tightening torque**

- Ⓐ : 37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)
- Ⓑ : 9.8—12 N·m (100—120 cm·kg, 87—104 in·lb)

10. Install the surge tank bracket and the gusset plate.

**Tightening torque**

- Ⓒ : 37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)
- Ⓓ : 37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)



86U07A-216

11. Install the end plate.


**Tightening torque:**

- 8—11 N·m (80—110 cm·kg, 69—95 in·lb)

12. Install the clutch release cylinder.

**Tightening torque:**

- 19—26 N·m (1.9—2.6 m·kg, 14—19 ft·lb)




86U07A-217

13. Install the gusset plates.

**Tightening torque:**

- 37—52 N·m (3.8—5.3 m·kg, 27—38 ft·lb)



16U0J1-024

14. Replace the clips at the end of the driveshafts and joint shaft with new ones.

15. Install the joint shaft and right driveshaft as follows:

- (1) Install and tighten the reamer bolts Ⓐ; then install and tighten the standard bolts Ⓑ.


**Tightening torque**

- Ⓐ : 6.9—48 N·m (0.7—4.9 m·kg, 5.1—35 ft·lb)
- Ⓑ : 42—62 N·m (4.3—6.3 m·kg, 31—46 ft·lb)

(2) Remove the **SST** (holder) and insert the shaft into the transaxle.

(3) Pull the front hub outward and connect the driveshaft to the joint shaft.


(4) Push the joint at the differential side to securely connect the driveshaft to the joint shaft.



96U07A-048

**Note**

- After installation, pull the front hub outward to confirm that the driveshaft doesn't come out.
- Do not damage the oil seal.



86U07A-220

16. Install the left driveshaft as follows:
  - (1) Pull the front hub outward and insert the driveshaft into the transaxle.
  - (2) Push the joint at the differential side to connect the driveshaft to the differential side gear.

**Note**

- Do not damage the oil seal.
- After installation, pull the front hub outward to confirm that the driveshaft doesn't come out.

17. Install the lower arm ball joints to the knuckles and tighten the bolts and nuts.

**Tightening torque:**

**36—54 N·m (3.7—5.5 m·kg, 27—40 ft·lb)**


18. Install the under cover.

**Note**

- Before installation, fill the notches with silicon as shown in the figure.

**Tightening torque:**

**8—11 N·m (80—110 cm·kg, 69—95 in·lb)**




06U0J1-092

19. Install the stabilizer bar control links as follows.

- (1) Install the stabilizer bar control link.
- (2) Adjust protrusion to **20.1 ± 2mm (0.79 ± 0.08 in)**.
- (3) Tighten bolt to specified torque.

**Tightening torque:**

**16—23 N·m (1.6—2.3 m·kg, 12—17 ft·lb)**



06U0J1-093

20. Install the tie-rod ends and new cotter pin.

**Tightening torque:**

**42—57 N·m (4.3—5.8 m·kg, 31—42 ft·lb)**

21. Install the splash shields.


**Tightening torque:**

**8—11 N·m (80—110 cm·kg, 69—95 in·lb)**

22. Install the front wheels.

**Tightening torque:**

**88—118 N·m (9.0—12.0 m·kg, 65—87 ft·lb)**




06U0J1-094


23. Install the grounds to the transaxle case.

**Tightening torque:**

**8—11 N·m (80—115 cm·kg, 69—100 in·lb)**




76G07A-652



86U07A-225

24. Connect the speedometer cable.



16U0J1-030

25. Install the air cleaner assembly and connect the air flow meter connector.

**Tightening torque:**


**16—27 N·m (1.6—2.8 m·kg, 12—20 ft·lb)**

26. Connect the distributor lead.

27. Connect the main fuse block.

**Tightening torque:**

**8—11 N·m (80—110 cm·kg, 69—95 in·lb)**



16U0J1-025

28. Install the battery carrier and battery.

29. Add the correct quantity of the specified transaxle oil.

**Specified oil**

**Type**

All-season

SAE 75W-90

ATF: DEXRON-II

Above -18°C (0°F):

API: GL-4 or GL-5

SAE 80W-90 or SAE 90


**Capacity: 3.35 liters (3.4 US qt, 2.9 Imp qt)**

### SHIFT MECHANISM

#### REMOVAL / INSTALLATION

1. Jack up the vehicle and support it with safety stands.
2. Remove in the order shown in the figure, referring to **Removal Note**.
3. Install in the reverse order of removal, referring to **Installation Note**.

06U0J1-081




N-m (m-kg, ft-lb)

06U0J1-082

- |                              |  |                              |
|------------------------------|--|------------------------------|
| 1. Change lever knob         | 8. Extension bar bracket assembly and gasket | 14. Bushings                 |
| 2. Assist boot               | Installation..... page J1-50                 | 15. Boot                     |
| 3. Mounting rubber boot      |  | Installation..... page J1-49 |
| 4. Bolts and nuts            | 9. Bushing                                   | 16. Holder                   |
| 5. Change control rod        | 10. Pipe                                     | Installation..... page J1-49 |
| Installation..... page J1-50 | 11. Change lever                             | 17. Ball seat (lower)        |
| 6. Bracket installation nuts | 12. Spring                                   | Installation..... page J1-49 |
| Installation..... page J1-49 | Removal ..... page J1-49                     | 18. Extension bar            |
| 7. Nut and washer            | Installation..... page J1-50                 | Installation..... page J1-49 |
|                              | 13. Ball seat (upper)                        |                              |
|                              | Installation..... page J1-49                 |                              |






06U0J1-083

### Removal note

#### Spring

Remove the spring by prying on the hooked part of the spring with a screwdriver.




61G07X-192

### INSPECTION

Check the following, and replace if necessary:

1. Bent control rod.
2. Wear, damage, or malfunction of any joint.
3. Damaged gear shift lever ball.
4. Weak spring.
5. Wear or damage of bushing.



06U0J1-084


### Installation note

#### Extension Bar

First, install the extension bar to the floor, and then install it onto the transaxle.

#### Tightening torque:

**31—46 N·m (3.2—4.7 m·kg, 23—34 ft·lb)**




16U0J1-026

### Bracket Installation Nuts

Tighten the bracket installation nuts to the specified torque.

#### Tightening torque:

**16—23 N·m (1.6—2.3 m·kg, 12—17 ft·lb)**




61G07X-193

### Gear Shift Lever Ball

Apply grease to the ball seat surface, and install the upper and lower ball seat, holder, and boot.

#### Note


- Apply grease to all joints.



63U07A-156

### Spring


Make sure that the hooked part of the spring is properly seated in the bracket groove, as shown in the figure.



63U07A-157

### Bracket Cavity

Put grease in the bracket cavity.



96U07X-044

### Change Control Rod

Install the change control rod so that its relationship with the shift lever is as shown in the figure.

### Tightening torque:

**16—23 N·m (1.6—2.3 m·kg, 12—17 ft·lb)**