


BODY

INDEX	S- 2	REMOVAL.....	S- 60
HOOD	S- 5	INSTALLATION.....	S- 60
STRUCTURAL VIEW.....	S- 5	REAR WINDOW GLASS	S- 64
REMOVAL.....	S- 6	PREPARATION.....	S- 64
INSTALLATION.....	S- 6	STRUCTURAL VIEW.....	S- 64
ADJUSTMENT.....	S- 7	REMOVAL.....	S- 66
FRONT DOORS	S- 8	INSTALLATION.....	S- 67
STRUCTURAL VIEW.....	S- 8	QUARTER WINDOW GLASS	S- 69
FRONT DOOR GLASS AND REGULATOR.....	S- 10	PREPARATION.....	S- 69
OUTER HANDLE AND KEY CYLINDER.....	S- 11	STRUCTURAL VIEW.....	S- 69
DOOR LOCK ASSEMBLY.....	S- 12	REMOVAL.....	S- 71
GLASS GUIDE AND GLASS CLAMP NUT.....	S- 12	INSTALLATION.....	S- 71
POWER WINDOW.....	S- 14	HEADLIGHT CLEANER	S- 73
DOOR LOCK STRIKER.....	S- 15	TROUBLESHOOTING.....	S- 73
DOOR HINGE.....	S- 15	REMOVAL / INSTALLATION.....	S- 74
REAR DOORS	S- 16	HEADLIGHT CLEANER SWITCH.....	S- 75
STRUCTURAL VIEW.....	S- 16	WASHER MOTOR.....	S- 75
REAR DOOR GLASS AND REGULATOR.....	S- 17	SLIDING SUNROOF	S- 76
GLASS GUIDE AND GLASS CLAMP NUT.....	S- 18	STRUCTURAL VIEW.....	S- 76
DOOR LOCK AND OUTER HANDLE.....	S- 20	TROUBLESHOOTING.....	S- 77
DOOR LOCK STRIKER.....	S- 20	INSPECTION.....	S- 79
TIGHTENING TORQUE.....	S- 20	REMOVAL.....	S- 81
TRUNK LID	S- 21	INSTALLATION.....	S- 84
STRUCTURAL VIEW.....	S- 21	INSTRUMENT PANEL	S- 89
REMOVAL.....	S- 22	STRUCTURAL VIEW.....	S- 89
INSTALLATION.....	S- 23	INSTALLATION VIEW.....	S- 90
ADJUSTMENT.....	S- 23	REMOVAL.....	S- 91
POWER DOOR LOCK	S- 25	INSTALLATION.....	S- 95
STRUCTURAL VIEW.....	S- 25	SEAT	S- 96
TROUBLESHOOTING.....	S- 26	STRUCTURAL VIEW.....	S- 96
POWER DOOR LOCK SWITCH.....	S- 28	FRONT SEAT.....	S- 97
POWER DOOR LOCK MOTOR.....	S- 28	REAR SEAT.....	S- 97
POWER DOOR LOCK RELAY.....	S- 28	PASSIVE SHOULDER BELT	S- 98
POWER WINDOW	S- 29	STRUCTURAL VIEW.....	S- 98
STRUCTURAL VIEW.....	S- 29	TROUBLESHOOTING.....	S- 99
TROUBLESHOOTING.....	S- 30	INSPECTION.....	S-101
INSPECTION.....	S- 34	REMOVAL.....	S-104
TRUNK LID LOCK REMOTE RELEASE	S- 36	INSTALLATION.....	S-104
REMOVAL / INSTALLATION.....	S- 36	SEAT BELTS	S-105
FUEL FILLER LID REMOTE RELEASE	S- 37	STRUCTURAL VIEW.....	S-105
REMOVAL / INSTALLATION.....	S- 37	INSPECTION.....	S-106
FRONT BUMPER	S- 38	HEAD LINER	S-107
STRUCTURAL VIEW.....	S- 38	STRUCTURAL VIEW.....	S-107
REMOVAL.....	S- 39	REMOVAL.....	S-109
INSTALLATION.....	S- 39	INSTALLATION.....	S-111
REAR BUMPER	S- 40	UNDERBODY PROJECTED DIMENSIONS	S-112
STRUCTURAL VIEW.....	S- 40		
REMOVAL.....	S- 41		
INSTALLATION.....	S- 41		
MOLDING AND GARNISH	S- 42		
STRUCTURAL VIEW.....	S- 42		
REMOVAL / INSTALLATION.....	S- 43		
SIDE PROTECTOR MOLDING.....	S- 46		
RADIATOR GRILLE	S- 47		
REMOVAL / INSTALLATION.....	S- 47		
DOOR MIRROR	S- 48		
TROUBLESHOOTING.....	S- 48		
REMOTE CONTROL MIRROR SWITCH.....	S- 49		
DOOR MIRROR.....	S- 50		
WINDSHIELD WIPER AND WASHER	S- 51		
STRUCTURAL VIEW.....	S- 51		
TROUBLESHOOTING.....	S- 52		
WIPER MOTOR.....	S- 56		
WASHER MOTOR.....	S- 56		
REMOVAL.....	S- 57		
INSTALLATION.....	S- 57		
ADJUSTMENT.....	S- 58		
WINDSHIELD GLASS	S- 59		
PREPARATION.....	S- 59		
STRUCTURAL VIEW.....	S- 59		


INDEX




06U0SX-002

- | | | |
|------------------------------|---------|-----|
| 1. Hood | | |
| Structural view | page S- | 5 |
| Removal | page S- | 6 |
| Installation | page S- | 6 |
| Adjustment | page S- | 7 |
| 2. Front door | | |
| Structural view | page S- | 8 |
| Removal | page S- | 10 |
| Installation | page S- | 11 |
| Adjustment | page S- | 15 |
| 3. Front bumper | | |
| Structural view | page S- | 38 |
| Removal | page S- | 39 |
| Installation | page S- | 39 |
| 4. Molding and garnish | | |
| Structural view | page S- | 42 |
| Removal / Installation | page S- | 42 |
| 5. Radiator grille | | |
| Removal / Installation | page S- | 47 |
| 6. Door mirror | | |
| Troubleshooting | page S- | 48 |
| Inspection | page S- | 49 |
| Disassembly | page S- | 50 |
| Assembly | page S- | 50 |
| 7. Windshield wiper | | |
| Structural view | page S- | 51 |
| Troubleshooting | page S- | 52 |
| Inspection | page S- | 56 |
| Removal | page S- | 57 |
| Installation | page S- | 57 |
| Adjustment | page S- | 58 |
| 8. Windshield glass | | |
| Structural view | page S- | 59 |
| Removal | page S- | 60 |
| Installation | page S- | 60 |
| 9. Headlight cleaner | | |
| Troubleshooting | page S- | 73 |
| Removal / Installation | page S- | 74 |
| Inspection | page S- | 75 |
| 10. Sliding sunroof | | |
| Structural view | page S- | 76 |
| Troubleshooting | page S- | 77 |
| Inspection | page S- | 79 |
| Removal | page S- | 81 |
| Installation | page S- | 84 |
| 11. Headliner | | |
| Structural view | page S- | 107 |
| Removal | page S- | 109 |
| Installation | page S- | 111 |

MX-6



SEDAN




06U0SX-003

S

- 1. Rear door
 - Structural view page S-16
 - Removal..... page S-17
 - Installation page S-18
 - Adjustment..... page S-20
- 2. Trunk lid
 - Structural view page S-21
 - Removal..... page S-22
 - Installation page S-23
 - Adjustment..... page S-23
- 3. Rear bumper
 - Structural view page S-40
 - Removal..... page S-41
 - Installation page S-41
- 4. Molding and garnish
 - Structural view page S-42
 - Removal / Installation page S-43
- 5. Rear window glass
 - Structural view page S-64
 - Removal..... page S-66
 - Installation page S-67

- 6. Quarter window glass
 - Structural view page S-69
 - Removal..... page S-71
 - Installation page S-71




16U05X-003

- | | | | |
|-----------------------------------|------|-------|--|
| 1. Power door lock | | | |
| Structural view | page | S-25 | |
| Troubleshooting | page | S-26 | |
| Inspection | page | S-28 | |
| 2. Power window | | | |
| Structural view | page | S-29 | |
| Troubleshooting | page | S-30 | |
| Inspection | page | S-34 | |
| 3. Trunk lid lock remote release | | | |
| Removal / Installation | page | S-36 | |
| 4. Fuel filler lid remote release | | | |
| Removal / Installation | page | S-37 | |
| 5. Instrument panel | | | |
| Structural view | page | S-89 | |
| Removal | page | S-91 | |
| Installation | page | S-95 | |
| 6. Seat | | | |
| Inspection | page | S-97 | |
| Removal | page | S-97 | |
| Installation | page | S-97 | |
| 7. Passive shoulder belt | | | |
| Structural view | page | S-98 | |
| Troubleshooting | page | S-99 | |
| Inspection | page | S-101 | |
| Removal | page | S-104 | |
| Installation | page | S-104 | |
| 8. Seat belt | | | |
| Structural view | page | S-105 | |
| Inspection | page | S-106 | |

HOOD

STRUCTURAL VIEW




- 1. Hood
- 2. Hinge
- 3. Cowl seal rubber


- 4. Hood stay
- 5. Hood lock
- 6. Hood insulator

- 7. Front seal rubber
- 8. Windshield washer hose


86U14X-002




86U14X-003




86U14X-004



86U14X-005



86U14X-006



86U14X-007

REMOVAL

1. Disconnect the windshield washer hose at the joint shown in the figure.

2. Remove hood insulator fasteners, then remove the insulator.

3. Remove the front seal rubber fasteners, then remove the seal rubber.

4. Remove the hood hinge installation bolts, then remove the hood.

INSTALLATION


Install in the reverse order of removal.

1. Hood hinge installation bolts.


Tightening torque:

19—25 N·m (1.9—2.6 m·kg, 14—19 ft·lb)


2. Push the fasteners into the hood.



86U14X-008



86U14X-009



86U14X-010

ADJUSTMENT

Hood

Adjust the hood laterally and vertically by loosening the hood to hinge mounting bolts and repositioning the hood.

Hood Lock


Adjust the hood lock after the hood has been aligned. The lock can be moved vertically and horizontally. Align it with the striker on the hood after loosening the mounting bolts.

Tightening torque:

7.8—11 N·m (0.8—1.1 m·kg, 5.8—8.0 ft·lb)

FRONT DOORS


STRUCTURAL VIEW



N-m (m-kg, ft-lb)

06U0SX-005


- | | | |
|---|---|--|
| 1. Power window switch
Inspection..... page S-34 | 9. Key cylinder
Removal..... page S-11
Installation..... page S-12 | 18. Door mirror
Disassembly..... page S-50
Assembly..... page S-50 |
| 2. Regulator handle | 10. Glass
Removal..... page S-10
Installation..... page S-11 | 19. Beltline molding |
| 3. Inner handle cover | 11. Glass guide | 20. Weatherstrip |
| 4. Door trim | 12. Run channel | 21. Sail inner garnish |
| 5. Door screen | 13. Weatherstrip | 22. Glass guide
Removal..... page S-12
Installation..... page S-13 |
| 6. Weatherstrip | 14. Glass guide | 23. Glass clamp nut
Removal..... page S-12
Installation..... page S-13 |
| 7. Regulator (power type)
Removal..... page S-10
Installation..... page S-11 | 15. Door checker | |
| 8. Regulator (manual type)
Removal..... page S-10
Installation..... page S-11 | 16. Door | |
| | 17. Outer handle
Removal..... page S-11
Installation..... page S-12 | |



N-m (m-kg, ft-lb)

06U0SX-006

- | | | |
|------------------------------|------------------------------|------------------------------|
| 1. Regulator handle | 10. Glass guide | 19. Outer handle |
| 2. Arm rest | 11. Glass | Removal page S-11 |
| 3. Power window switch | Removal page S-10 | Installation page S-12 |
| Inspection page S-34 | Installation page S-11 | 20. Key cylinder |
| 4. Inner handle cover | 12. Run channel | Removal page S-11 |
| 5. Door trim | 13. Weatherstrip | Installation page S-12 |
| 6. Door screen | 14. Door | 21. Sail inner garnish |
| 7. Weatherstrip | 15. Door checker | 22. Glass guide |
| 8. Regulator (power type) | 16. Beltline molding | Removal page S-12 |
| Removal page S-10 | 17. Weatherstrip | Installation page S-13 |
| Installation page S-11 | 18. Door mirror | 23. Glass clamp nut |
| 9. Regulator (manual type) | Disassembly page S-50 | Removal page S-12 |
| Removal page S-10 | Assembly page S-50 | Installation page S-13 |
| Installation page S-11 | | |




06U0SX-007

FRONT DOOR GLASS AND REGULATOR Removal

Note

- Raise the door glass 100mm (3.94 in) from the fully open position.

1. Remove the clip and regulator handle.
(Manual type)




86U14X-037

2. Remove the inner handle cover, the screws (arrows), and the door trim.

Note

- For vehicles with power windows, disconnect the connectors.




86U14X-038

3. Remove the door screen.


Caution

- Remove the screen carefully so that it may be reused.




86U14X-039

4. Position the door glass so that the mounting bolts can be removed from the service holes.
5. Remove the mounting bolts.




06U0SX-008

6. Remove the beltline molding. (Refer to page S-54.)
7. Remove the door glass by lifting upward.



86U14X-040

8. Remove the mounting bolts, and remove the regulator through the service hole.




16U0SX-004

9. Remove the window motor mounting bolt, and remove the motor from the regulator (power window).

Installation

Install in the reverse order of removal.




06U0SX-010

OUTER HANDLE AND KEY CYLINDER


Removal

1. Disconnect the rod from the outer handle.



86U14X-042

2. Remove the key cylinder spring.
3. Remove the key cylinder.




16U0SX-005

4. Remove the mounting nuts and remove the outer handle.

Installation

Install in the reverse order of removal.




16U0SX-006

DOOR LOCK ASSEMBLY**Removal**

1. Remove the mounting screws.
2. Remove the door lock assembly.

Installation

Install in the reverse order of removal.






06U0SX-013


GLASS GUIDE AND GLASS CLAMP NUT**Removal**

1. Removal of door glass. (Refer to page S-10.)
2. Removal of glass guide and glass clamp nut.
 - (1) Remove glass clamp nut and remove the glass guide.


Note

- Apply heat (lighter) to the glass clamp nut if removal is difficult.







06U0SX-014




06U0SX-015



06U0SX-016



06U0SX-017



Installation

1. Installation of glass guide and glass clamp nut.

- (1) Clean and degrease the glass clamp nut and glass guide thread.
- (2) Apply the locking agent (8530 77 743) or equivalent to the threads of the glass clamp nut.

Note

- Apply the locking agent or equivalent freely.


- (3) Center the glass guide and washer on the glass and fill with repair seal (B001 77 739) or equivalent the gap between the glass and glass guide.

- (4) Loosely tighten the glass clamp nut into the glass guide.

Note

- Install the glass clamp nut (A) (GJ21 58 518E) with the torx wrench (T10).
- Install the glass clamp nut (B) (GJ23 58 518) with the torx wrench (T15).

FRONT DOORS



- (5) Adjust the glass guide to be parallel with the edge of the glass and tighten the glass clamp nut.

Tightening torque:

2.0—2.7 N·m (20—28 cm·kg, 17.4—24.3 in·lb)

- (6) Remove the excess repair seal or equivalent with kerosene.

Caution

- Keep the door glass open until the repair seal hardens.

Hardening time of repair seal

Temperature	Surface hardening time	Time required until car can be put in service
5°C (41°F)	Approx. 1.5 hrs	12 hrs
20°C (68°F)	Approx. 1 hr	4 hrs
35°C (95°F)	Approx. 10 min	2 hrs

2. Check for water leaks.


- (1) Check for water leaks. If a leak is found, remove the glass clamp nut and glass guide, and perform installation from the beginning.

3. Installation of door glass. (Refer to page S-11.)


Note

- Check the door glass movement after installation. If the door glass does not move smoothly, remove the glass clamp nut and glass guide, and perform installation from the beginning.

06U0SX-019

**POWER WINDOW**


Before installing the motor, connect the leads to a battery and run the regulator down to the position shown.



06U0SX-021

DOOR LOCK STRIKER**Adjustment**

1. Check that the door can be closed easily and whether there is any looseness. If there is a problem, loosen the striker mounting screws and adjust by moving the striker down, or laterally.
2. Check the rear offset of the door to the body. If there is a problem, adjust by moving the door lock striker laterally.



06U0SX-022

DOOR HINGE**Adjustment**


1. If looseness is found when the door is opened, tighten the door hinge mounting bolts (arrows).
2. Align the door and body by loosening and adjusting the door hinge mounting bolts.

Note

- If noise is heard from the checker when the door is opened, apply grease to the checker cam.


REAR DOORS

STRUCTURAL VIEW



06U0SX-023


- | | | |
|--|--|--|
| 1. Regulator handle
(manual type) | 9. Outer handle
Installation page S-20 | 15. Weatherstrip |
| 2. Arm rest | 10. Regulator (power type)
Removal page S-17
Installation page S-18 | 16. Door checker |
| 3. Power window switch
Inspection page S-34 | 11. Regulator (manual type)
Removal page S-17
Installation page S-18 | 17. Door |
| 4. Inner handle cover | 12. Glass guide | 18. Weatherstrip |
| 5. Door trim | 13. Glass
Removal page S-17
Installation page S-18 | 19. Sail inner garnish |
| 6. Beltline molding | 14. Weatherstrip | 20. Sail outer garnish |
| 7. Door screen | | 21. Glass guide
Removal page S-18
Installation page S-18 |
| 8. Door lock
Installation page S-20 | | 22. Glass clamp nut
Removal page S-18
Installation page S-18 |



06U0SX-024

**REAR DOOR GLASS AND REGULATOR
Removal**

1. Lower the door glass the way.
2. Remove the clip. (Manual type)
3. Remove the regulator handle. (Manual type)




86U14X-048

4. Remove the inner handle cover.
5. Remove the door trim.

Note

- For vehicles with power windows, disconnect the connectors.




86U14X-049

6. Remove the door screen.


Caution

- Remove the screen carefully so that it may be reused.




86U14X-050

7. Position the door glass so that the mounting bolts can be removed from the service hole.
8. Remove the mounting bolts.



86U14X-051

9. Remove the door glass upward.




16U0SX-007

10. Remove the mounting bolts, and remove the window regulator through the service hole.
11. Remove the window motor mounting bolts, then remove the motor from the regulator (power window).

Installation

Install in the reverse order of removal.






06U0SX-026

GLASS GUIDE AND GLASS CLAMP NUT**Removal**

1. Removal of door glass. (Refer to page S-17.)
2. Removal of glass guide and glass clamp nut
 - (1) Remove glass clamp nut and remove the glass guide.

Note

- Apply heat (lighter) to the glass clamp nut if removal is difficult.




06U0SX-027

Installation


1. Installation of glass guide and glass clamp nut
 - (1) Clean and degrease the glass clamp nut and glass guide thread.
 - (2) Apply the locking agent (8530 77 743) or equivalent to the threads of the glass clamp nut.

Note


- Apply the locking agent or equivalent freely.




16U0SX-008



06U0SX-029



06U0SX-030



06U0SX-031

- (3) Center the glass guide and washer on the glass and fill the gap between the glass and glass guide with repair seal (B001 77 739) or equivalent.

- (4) Loosely tighten the glass clamp nut into the glass guide.

Note

- Install the glass clamp nut (A) (GJ21 58 518E) with the torx wrench (T10).
- Install the glass clamp nut (B) (GJ23 58 518) with the torx wrench (T15).

- (5) Adjust the glass guide to be parallel with the edge of the glass and tighten the glass clamp nut.

Tightening torque:

2.0—2.7 N·m (20—28 cm·kg, 17.4—24.3 in·lb)

- (6) Remove the excess repair seal or equivalent with kerosene.

Caution

- Keep the door glass open until the repair seal hardens.

Hardening time of repair seal


Temperature	Surface hardening time	Time required until car can be put in service
5°C (41°F)	Approx. 1.5 hrs	12 hrs
20°C (68°F)	Approx. 1 hr	4 hrs
35°C (95°F)	Approx. 10 min	2 hrs

2. Check for water leaks.
 - (1) Check for water leaks. If a leak is found, remove the glass clamp nut and glass guide, and perform installation from the beginning.
3. Installation of door glass. (Refer to page S-18.)

Note

- Check the door glass movement after installation. If the door glass does not move smoothly, remove the glass clamp nut and glass guide, and perform installation from the beginning.


06U0SX-032



06U0SX-033

DOOR LOCK AND OUTER HANDLE**Installation**


1. Before installing the door lock, apply grease to the places shown in the figure.
2. After installation, check that the door opens smoothly, and that the operation of the lock is correct when using the key and the door lock knob.



06U0SX-034

DOOR LOCK STRIKER**Adjustment**

1. Check that the door can be closed easily and whether there is any looseness. If there is a problem, loosen the striker mounting screws and adjust by moving the striker vertically, or laterally.
2. Check the rear offset of the door to the body. If there is a problem, adjust by moving the door lock striker laterally.



06U0SX-035


TIGHTENING TORQUE

Torque		N·m (m·kg, ft·lb)
Door lock assembly		4.22–6.18 (0.43–0.63, 3.10–4.54)
Outer handle		8.8–13 (0.9–1.3, 6.5–9.4)
Glass guide		7.8–11 (0.8–1.1, 5.8–8.0)
Regulator	Nut	8.8–13 (0.9–1.3, 6.5–9.4)
	Bolt	7.8–11 (0.8–1.1, 5.8–8.0)
Door lock striker		18–26 (1.8–2.7, 13–20)

Before installing the motor, connect the leads to a battery and run regulator down.

TRUNK LID


STRUCTURAL VIEW (SEDAN AND MX-6)



N-m (m-kg, ft-lb)

86U14X-011


- | | | |
|-------------------------------|---------------------------|----------------------------|
| 1. Trunk lid lock | 4. Retainer | 7. Trunk lid hinge bracket |
| 2. Trunk lid opener protector | 5. Trunk lid key cylinder | 8. Trunk lid hinge |
| 3. Opening rod | 6. Balance spring | 9. Trunk lid |



86U14X-012


REMOVAL Trunk Lid Opener

1. Remove the nut and the protector.



86U14X-013


2. Remove the opening rod.
3. Remove the bolts and the trunk lid opener.



86U14X-014

Trunk Lid Key Cylinder


Remove the retainer and the trunk lid key cylinder.



06U0SX-036


Trunk Lid

1. Remove the trunk lid installation bolts, then remove the trunk lid.
2. Remove the balance spring.
3. Remove the rear seat. (Refer to page S-97.)



86U14X-016

4. Remove the fasteners and remove the rear package tray.




16U0SX-009

5. Remove the bolts and remove the trunk lid hinge bracket.

INSTALLATION

Install in the reverse order of removal.




86U14X-019

ADJUSTMENT


Trunk Lid

1. Adjust the trunk lid by loosening the lid to hinge mounting bolts and repositioning it.



86U14X-020

2. Align the trunk lid evenly as shown in the figure.




86U14X-021

Trunk Lid Striker


1. Loosen the striker mounting bolts.
2. Tighten the bolts after adjusting.

Tightening torque:

7.8—11 N·m (0.8—1.1 m·kg, 5.8—8.0 ft·lb)



96U14X-002



Balance Spring

1. Lift the balance spring with protected screwdriver A.
2. Slide the balance spring to the alternate position as described below with protected screwdriver B.

Tension	Hinge	Set position	
		a	b
Standard	Left side	○	
	Right side		○
Increase	Left side		○
	Right side		○
Decrease	Left side	○	
	Right side	○	


○ : Indicates position

Warning

- Use care when moving the balance spring.

POWER DOOR LOCK

STRUCTURAL VIEW



16U05X-010


1. Power door lock switch
Inspection page S-28

2. Power door lock motor
Inspection page S-28


3. Power door lock relay
Inspection page S-28

POWER DOOR LOCKS


K-3



<p>K-13 POWER DOOR LOCK RELAY (R)</p> <table border="1"> <tr> <td>G</td> <td>R</td> <td>W/G</td> </tr> <tr> <td>G/B</td> <td>*</td> <td>B</td> </tr> </table>	G	R	W/G	G/B	*	B	<p>K-14 POWER DOOR LOCK MOTOR REAR LH (DR3)</p> <table border="1"> <tr> <td>R</td> </tr> <tr> <td>G</td> </tr> </table>	R	G	<p>K-15 POWER DOOR LOCK MOTOR REAR RH (DR4)</p> <table border="1"> <tr> <td>R</td> </tr> <tr> <td>G</td> </tr> </table>	R	G	<p>K-16 POWER DOOR LOCK MOTOR FRONT RH (DR2) 2 DOOR 4 DOOR</p> <table border="1"> <tr> <td>R</td> </tr> <tr> <td>G</td> <td>*</td> </tr> <tr> <td>R</td> </tr> <tr> <td>G</td> </tr> </table>	R	G	*	R	G	<p>K-17 POWER DOOR LOCK SWITCH (DR1)</p> <table border="1"> <tr> <td>G/B</td> </tr> <tr> <td>B</td> <td>W/G</td> </tr> </table>	G/B	B	W/G	
G	R	W/G																					
G/B	*	B																					
R																							
G																							
R																							
G																							
R																							
G	*																						
R																							
G																							
G/B																							
B	W/G																						



06U0SX-040



06U0SX-041

POWER DOOR LOCK SWITCH


Inspection

1. Check continuity of the switch with an ohmmeter.

	a	b	c
Lock	○	○	
Unlock	○		○

○—○: Indicates continuity

2. If continuity is not as specified, replace the switch.



06U0SX-042


POWER DOOR LOCK MOTOR

Inspection

1. Check operation of the door lock actuator when battery voltage is applied to the terminal.

Connecting to		Door lock motor
12V	ground	
b	a	LOCK (Pull)
a	b	UNLOCK (Release)

2. If not as specified, replace the door lock motor.



16U0SX-011

POWER DOOR LOCK RELAY

Inspection

1. Check continuity between terminals of the door lock relay.

Terminal		Continuity	Terminal		Continuity
+	-		+	-	
a	b	X	b	e	○
a	c	X	b	f	X
a	e	X	c	e	○
a	f	X	c	f	X
b	c	○	e	f	X

○ : Indicates continuity

X: No continuity


Note

- Set the tester to x1,000Ω range.

2. If not as specified, replace the relay.

POWER DOOR LOCK

STRUCTURAL VIEW




06U0SX-043

- 1. Power window main switch
Inspection page S-34
- 2. Power window switch
Inspection page S-35



- 3. Power window motor
Inspection page S-35


POWER WINDOWS

K-2




<p>K-05 POWER WINDOW MAIN SWITCH (DR1)</p> <table border="1" data-bbox="304 1106 556 1214"> <tr> <td>G/W</td> <td>R/W</td> <td></td> <td>R/L</td> <td>G/L</td> </tr> <tr> <td>G/Y</td> <td>W/R</td> <td>B/R</td> <td>Y/W</td> <td>L/W</td> </tr> <tr> <td>*</td> <td>*</td> <td>B/L</td> <td>B</td> <td>B</td> </tr> </table>	G/W	R/W		R/L	G/L	G/Y	W/R	B/R	Y/W	L/W	*	*	B/L	B	B	<p>K-06 POWER WINDOW SWITCH FRONT RH (DR2)</p> <table border="1" data-bbox="724 1073 861 1139"> <tr> <td>G</td> <td>R/W</td> </tr> <tr> <td>G/W</td> <td>R B/L</td> </tr> </table>	G	R/W	G/W	R B/L	<p>K-07 POWER WINDOW SWITCH REAR LH (DR3)</p> <table border="1" data-bbox="966 1073 1102 1139"> <tr> <td>L</td> <td>Y/W</td> </tr> <tr> <td>L/W</td> <td>R B/L</td> </tr> </table>	L	Y/W	L/W	R B/L	<p>K-08 POWER WINDOW SWITCH REAR RH (DR4)</p> <table border="1" data-bbox="1207 1073 1344 1139"> <tr> <td>L</td> <td>Y/W</td> </tr> <tr> <td>L/W</td> <td>R B/L</td> </tr> </table>	L	Y/W	L/W	R B/L	<p>K-09 POWER WINDOW MOTOR FRONT LH (DR1)</p> <table border="1" data-bbox="1491 1073 1564 1139"> <tr> <td>G/L</td> </tr> <tr> <td>R/L</td> </tr> </table>	G/L	R/L	<p>K-10 POWER WINDOW MOTOR FRONT RH (DR2)</p> <table border="1" data-bbox="1743 1073 1816 1139"> <tr> <td>R</td> </tr> <tr> <td>G</td> </tr> </table>	R	G
G/W	R/W		R/L	G/L																																
G/Y	W/R	B/R	Y/W	L/W																																
*	*	B/L	B	B																																
G	R/W																																			
G/W	R B/L																																			
L	Y/W																																			
L/W	R B/L																																			
L	Y/W																																			
L/W	R B/L																																			
G/L																																				
R/L																																				
R																																				
G																																				
	<p>K-11 POWER WINDOW MOTOR REAR LH (DR3)</p> <table border="1" data-bbox="766 1197 819 1263"> <tr> <td>R</td> </tr> <tr> <td>L</td> </tr> </table>	R	L	<p>K-12 POWER WINDOW MOTOR REAR RH (DR4)</p> <table border="1" data-bbox="1008 1197 1060 1263"> <tr> <td>R</td> </tr> <tr> <td>L</td> </tr> </table>	R	L																														
R																																				
L																																				
R																																				
L																																				





06U0SX-047



06U0SX-048

Power windows (except driver's side) cannot be operated by main switch

Turn ignition switch ON

Note
 • Use only the main switch during the checking operation.

Check for 12V at terminal of power window switch connector while operating main switch (driver's side)

Door	Operation	Wire
Passenger side	Up	"G/W"
	Down	"R/W"
Rear left side (except MX-6)	Up	"L/W"
	Down	"Y/W"
Rear right side (except MX-6)	Up	"G/Y"
	Down	"W/R"

NG → Check power window switch (driver's side) (Refer to page S-34)

OK

Check for 12V at terminal to each door power window switch connector (5-pin) while operating main switch (driver's side)

Door	Operation	Wire
Passenger side	Up	"G/W"
	Down	"R/W"
Rear left side (except MX-6)	Up	"L/W"
	Down	"Y/W"
Rear right side (except MX-6)	Up	"L/W"
	Down	"Y/W"

NG → Repair harness (Main switch—Switch on each door)

OK

Check for 12V at "R" terminal and "G" terminal of each door switch connector (5-pin) while operating main switch (driver's side)

- Up: "R" terminal
- Down: "G" terminal

NG → Check switch on each door (Refer to page S-35)


OK

Check for 12V at "R" terminal and "G" terminal of each motor connector (2-pin) while operating main switch (driver's side)


- Up: "R" terminal
- Down: "G" terminal

NG → Repair harness (Switch on each door—Motor)

OK → Check motor (Refer to page S-35)



06U0SX-050



96U15X-084

INSPECTION


Driver's Side Power Window Switch (Sedan)

Check for continuity between terminals of the switch.

Main switch


Position \ Terminal	h	i
Lock		
Unlock	○—○	○—○

○—○: Indicates continuity




Switch \ Terminal	Driver's side				Passenger's side				Rear left				Rear right			
Position	h	f	d	a	h	f	m	j	h	f	e	b	h	f	n	k
UP	○			○	○		○		○			○	○		○	
OFF		○—○		○		○—○		○		○—○		○		○—○		○
DOWN	○			○	○		○		○			○	○		○	


○—○: Indicates continuity




96U15X-085




86U15X-118



96U15X-086



96U15X-087



86U15X-121

(MX-6)

Check for continuity between terminals of the switch.

Main switch

Terminal	a	c
Position		
Lock		
Unlock	○—○	○—○

○—○: Indicates continuity

Switch	Driver's side				Passenger's side				
	Terminal	a	b	h	g	a	b	d	f
UP		○—○	○—○	○—○	○—○		○—○	○—○	○—○
OFF			○—○	○—○			○—○	○—○	○—○
DOWN	○—○		○—○	○—○	○—○		○—○	○—○	○—○

○—○: Indicates continuity

Switch on Each Side

(Sedan)

Check for continuity between terminals of the switch.

Terminal	a	b	d	e	f
UP	○—○	○—○	○—○	○—○	
OFF	○—○		○—○	○—○	○—○
DOWN		○—○	○—○	○—○	○—○

○—○: Indicates continuity

(MX-6)

Check for continuity between terminals of the switch.

Terminal	a	b	d	f	h
UP	○—○	○—○	○—○	○—○	
OFF	○—○		○—○	○—○	○—○
DOWN		○—○	○—○	○—○	○—○

○—○: Indicates continuity


Power Window Motor

1. Connect 12V to the "a" terminal and ground the "b" terminal of the motor connector, and check that the motor operates.
2. Reverse the above connections and check for reverse operation of the motor.

TRUNK-LID LOCK REMOTE RELEASE

REMOVAL / INSTALLATION

1. Remove in the sequence shown in the figure.
2. Install in the reverse order of removal.



A	B	C	D

86U14X-108

1. Screws
2. Scuff plate
3. Screws


4. Cover
5. Bolts
6. Release lever

7. Release wire

FUEL FILLER LID REMOTE RELEASE

REMOVAL / INSTALLATION

1. Remove in the sequence shown in the figure.
2. Install in the reverse order of removal.



1. Screws
2. Scuff plate
3. Screws


4. Cover
5. Bolts
6. Release lever

7. Release wire

86U14X-109

FRONT BUMPER

STRUCTURAL VIEW




N-m (m-kg, ft-lb)

86U14X-056


1. Bumper stay
2. Set plate

3. Reinforcement
4. Energy absorbing foam


5. Bumper
6. Front airdam skirt




86U14X-057



86U14X-058



69G14X-099



86U14X-059

REMOVAL

1. Remove the under cover mounting screws.

2. Remove the bumper mounting screws.

3. Disconnect the side turn signal light connector.

4. Remove the front side bumper stay mounting bolts and loosen the rear side bolts.

INSTALLATION


Install the front side bumper stay mounting bolts and tighten the rear side bolts.

Tightening torque:

31—46 N·m (3.2—4.7 m·kg, 23—34 ft·lb)

REAR BUMPER

STRUCTURAL VIEW




86U14X-060


- 1. Flap
- 2. Splash shield
- 3. Bolts

- 4. Set plate
- 5. Reinforcement
- 6. Energy absorbing foam


- 7. Bumper



86U14X-061



86U14X-062



86U14X-063

REMOVAL

1. Remove the screws shown in the figure.

2. Remove the bumper mounting nuts.

3. Remove the nuts and fasteners shown in the figure and remove the reinforcement from the bumper.

INSTALLATION

Install in the reverse order of removal.


Tightening torque:

Bumper stay installation nuts:

31—46 N·m (3.2—4.7 m·kg, 23—34 ft·lb)


MOLDING AND GARNISH

STRUCTURAL VIEW



06U0SX-054

- | | | |
|---|---|---|
| <p>1. Windshield molding
Removal /
Installation page S-43</p> <p>2. Windshield lower molding
Removal /
Installation page S-43</p> <p>3. Drip molding
Removal /
Installation page S-43</p> <p>4. Beltline molding
Removal /
Installation page S-43</p> <p>5. Quarter window molding
Removal /
Installation page S-44</p> <p>6. Back window lower molding
(Sedan and MX-6)
Removal /
Installation page S-44</p> | <p>7. Back window side molding
(Sedan and MX-6)
Removal /
Installation page S-43</p> <p>8. Front lower molding
Removal /
Installation page S-45</p> <p>9. Trunk lid molding
Removal /
Installation page S-44</p> <p>10. Back window upper molding
(Sedan and MX-6)
Removal /
Installation page S-44</p> <p>11. Center pillar garnish
Removal /
Installation page S-45</p> <p>12. Rear finisher
Removal /
Installation page S-45</p> | <p>13. Sail garnish
Removal /
Installation page S-45</p> <p>14. Side protector molding
Structural view.. page S-46
Removal page S-46
Installation page S-46</p> |
|---|---|---|




06U0SX-059

REMOVAL/INSTALLATION

Windshield Molding


1. Remove the windshield molding. (Refer to page S-60.)
2. Install the windshield molding. (Refer to page S-62.)



06U0SX-060

Windshield Lower Molding

1. Remove the wiper arms.
2. Remove the lower molding screws and remove the lower molding.
3. Install in the reverse order of removal.



06U0SX-061


Drip Molding

1. Insert a screwdriver between the roof rail and drip molding and slightly loosen the end of the molding.

Note

- **Be careful not to scratch the molding.**


2. Remove the molding by twisting upward with both hands.
3. Install in the reverse order of removal.



06U0SX-062

Beltline Molding


1. Remove the door mirror.
2. Remove the screw from the end of the beltline molding, then pull the molding up to remove it.
3. Install in the reverse order of removal.



06U0SX-063

Back Window Side Molding (Sedan)


1. Remove the rear side seat back bolt, then remove the rear side seat back.
2. Remove the rear pillar trim.
3. Remove the window side molding nuts, then remove the window side molding.
4. Install in the reverse order of removal.



06U0SX-064

Back Window Lower Molding (Sedan and MX-6)


1. Remove the back window lower molding screws, then remove the back window lower molding.
2. Install in the reverse order of removal.



06U0SX-065

Back Window Upper Molding (Sedan and MX-6)


1. Remove the back window side molding. (Refer to pages S-43, 44.)
2. Remove the back window upper molding.
3. Install in the reverse order of removal.



06U0SX-067

Quarter Window Molding (MX-6)


1. Remove the seat belt upper anchor bolts.
2. Remove the screws and remove the rear header trim.
3. Remove the screws and remove the rear side trim.
4. Remove the screws and remove the rear pillar trim.
5. Remove the quarter window molding installation nuts.
6. Remove the screws and remove the quarter window molding.
7. Install in the reverse order of removal.



06U0SX-069

Quarter Window Molding (Sedan)


1. Remove the screws and remove the rear header trim.
2. Remove the bolt and remove the rear side seat back.
3. Remove the rear pillar trim.
4. Remove the nuts and remove the quarter window molding.
5. Install in the reverse order of removal.



06U0SX-070

Back Window Side Molding (MX-6)


1. Remove the seat belt upper anchor bolts.
2. Remove the screws and remove the rear header trim.
3. Remove the screws and remove the rear side trim.
4. Remove the screws and remove the rear pillar trim.
5. Remove the nuts and remove the back window side molding.
6. Install in the reverse order of removal.



06U0SX-071

Trunk Lid Molding (Sedan)


1. Remove the rear finisher.
2. Remove the nuts and screws and remove the trunk lid molding.
3. Install in the reverse order of removal.



06U0SX-072

Center Pillar Garnish (Sedan)


1. Remove the seat belts.
2. Remove the front and rear header trims.
3. Remove the front and rear pillar trims.
4. Remove the nuts with a deep socket wrench, then remove the garnish.
5. Install in the reverse order of removal.



06U0SX-073

Rear Finisher (MX-6 and Sedan)


1. Remove the nuts and remove the rear finisher.
2. Install in the reverse order of removal.



06U0SX-075

Sail Garnish (Sedan)

1. Remove the sail inner garnish.
2. Remove the screws and remove the sail garnish.
3. Install in the reverse order of removal.




06U0SX-076

Front Lower Molding (Sedan)

1. Remove the front lower molding screws, and remove the front lower molding.
2. Install in the reverse order of removal.

SIDE PROTECTOR MOLDING

Structural View




86U14X-102

1. Side protector A molding

2. Side protector B molding

3. Side protector C molding




7BU14X-034

Removal

1. Using a screwdriver or knife, twist the molding end, being careful not to damage the painted surface, and separate the adhesive for **20—30mm (0.79—1.18 in)**.
2. Pull the separated portion to remove it.
3. Use a knife to remove any adhesive remaining on the body or molding.

Note


- Remove as much adhesive as possible without damaging the painted surface.



7BU14X-036

Installation

1. Remove any grease or dirt from the molding adhesion surface and the body surface.
2. Mark the installation position on the body with masking tape.
3. Attach double-sided adhesive tape to the molding adhesion surface.



7BU14X-037

4. Align the molding on the body, and attach it securely.


Note

- Adhesion conditions deteriorate if air temperature is **20°C (68°F) or less**; heating of the body is thus recommended.

RADIATOR GRILLE

REMOVAL / INSTALLATION

1. Remove in the sequence shown in the figure, referring to removal note for the specially marked parts.
2. Install in the reverse order of removal, referring to installation note for the specially marked parts.




86U14X-065

1. Screw

2. Fasteners

3. Radiator grille



86U14X-066

**Removal Note
Fasteners**


Push the tabs of the fasteners (5) with a small screwdriver.


Installation Note

Insert the fasteners into the grille, then align with the installation holes in the body and press in the grille.

DOOR MIRROR

TROUBLESHOOTING






16U0SX-001

REMOTE CONTROL MIRROR SWITCH Inspection

1. Remove the negative battery cable.
2. Remove the remote control mirror switch.
3. Check for continuity between the terminals using an ohmmeter.




06U0SX-079

Position	Operation	g	h	a	b	f	d	c
Left	Up	○	○—○	○—○	○—○	○		
	Down	○	○—○	○—○	○—○	○		
	Left	○	○—○	○—○	○—○	○		
	Right	○	○—○	○—○	○—○	○		
Right	Up	○	○—○	○—○	○—○	○	○—○	○—○
	Down	○	○—○	○—○	○—○	○	○—○	○—○
	Left	○	○—○	○—○	○—○	○	○—○	○—○
	Right	○	○—○	○—○	○—○	○	○—○	○—○

○—○: Indicates continuity


4. If continuity is not as specified, replace the remote control mirror switch.



06U0SX-080

DOOR MIRROR Disassembly


1. Warm the frame and the mirror glass with a hot air blower.



86U14X-104

2. Insert a scraper between the mirror glass and the frame, then pry the mirror loose.


3. Remove any remaining adhesive.



06U0SX-081

Assembly

1. Warm the frame with a hot air blower.




86U14X-107

2. Install the glass in the frame, then gently press it in to secure it.

WINDSHIELD WIPER AND WASHER

STRUCTURAL VIEW




Note


• The wiper arms not interchangeable.

06U0SX-082


1. Wiper blade		5. Wiper motor	
2. Wiper arm		Inspection	page S-57
Removal	page S-57	Removal	page S-57
Installation	page S-57	Installation	page S-56
Adjustment	page S-58	6. Link assembly	
3. Lower molding		Removal	page S-57
Removal	page S-44	Installation	page S-57
Installation	page S-44	7. Washer tank	
4. Cover		8. Hose	
Removal	page S-57	9. Washer nozzle	
Installation	page S-57	Adjustment	page S-58
		10. Washer motor	
		Inspection	page S-56




06U0SX-084




06U0SX-085




06U0SX-086




06U0SX-087




06U0SX-088




06U0SX-089




06U0SX-090



06U0SX-091



96U15X-103



06U0SX-092

WIPER MOTOR

Inspection

Check for continuity between the terminals when wiper is in normal resting position.

Terminals	Continuity
b—a	Yes
b—c	Yes
b—d	Yes
f—d	No

Checking Operation


Check operation by applying 12V as shown to the motor connector.

Terminal		Operation speed
12V	Ground	
b	a	Low
	c	High


WASHER MOTOR

Inspection


1. Check for continuity of the motor with an ohmmeter.
2. Connect 12V to the "b" terminal and ground the "a" terminal. Verify that the motor operates.




86U14X-168




86U14X-169



86U14X-170



86U14X-171



86U14X-172

REMOVAL

1. Disconnect the negative battery cable.
2. Remove the wiper arms.
3. Remove the lower molding.
4. Remove the cover.
5. Disconnect the wiper link from the motor.

Caution

- Do not remove the motor arm unless necessary. The motor arm position on the motor shaft decides the automatic stop position. (lowest position of the wiper arm)

6. Disconnect the connector.
7. Remove the wiper motor.


8. Remove the wiper link assembly mounting bolts.
9. Lift the wiper link assembly out from the left side (driver's side) service hole.

INSTALLATION

Install in the reverse order of removal.

Note


- The wiper arms are identified by marks on the arms.
DL: driver side
PL: passenger side



86U14X-173

ADJUSTMENT**Arm Height**

Set the arm height as shown in the figure.




86U14X-174

Adjustment of washer spray

Insert a needle or similar object into the nozzle hole and bend to change the spray direction.


WINDSHIELD GLASS

PREPARATION
SST

<p>49 0305 807A Tool set, window</p>		<p>For removal and installation of windshield glass</p>
--	---	---

06U0SX-102


STRUCTURAL VIEW




06U0SX-103

- 1. Rear view mirror
- 2. Sunvisor
- 3. Front header trim
- 4. Front pillar trim
- 5. Wiper arm


- 6. Lower molding
- 7. Front windshield molding
- 8. Windshield glass
- 9. Spacer




86U14X-111




86U14X-112



86U14X-113



86U14X-114



86U14X-115

REMOVAL

1. Remove the rearview mirror, sunvisors, front pillar trim, and front header trim.
2. Remove the wiper arms and lower molding.
3. Remove the front window molding.

Caution

- Before removing the sealant, apply adhesive tape to the body and instrument panel to protect them from damage.

4. Make a small hole through the sealant.
5. Pass the piano wire through the hole.
6. Wind each end of the wire around a bar.
7. Pull the wire to and fro, and saw through the sealant around the edge of the glass. Then remove the glass.

Caution

- Use a long sawing action to spread the work over the whole length of wire to prevent it from breaking.
- Be careful that the wire does not rub on the body or instrument panel.


Note

- If the glass is not to be reused, a tool like that shown in the figure may be used.


Insert the blade in the sealant, and pull on the bars.

INSTALLATION


1. Cut away the old sealant with a sharp knife so that 1 to 2mm (0.04 to 0.08 in) thickness of sealant remains around the circumference of the frame. If all the sealant has come off in any one place, apply some primer after degreasing, and allow it 30 minutes to dry. Then put on new sealant to build up to a 2mm (0.08 in) layer.




86U14X-116




86U14X-117



86U14X-118



86U14X-119



7BU14X-026

2. Carefully clean a **5 cm (1.97 in)** wide area around the circumference of the glass and the bond on the body.
3. Bond a new dam along the circumference of the glass **5mm (0.20 in)** from the edge.

Caution

- **Securely bond the dam and allow it to dry.**

4. Apply primer with a brush to the bonding area of the glass and the body, and allow it to dry for **approx. 30 minutes**.

Caution

- **Keep the area free of dirt. Do not touch the surface. If primer gets on the hands, remove it immediately.**

5. Bond the spacers to the body as shown.

Caution

- **Damaged clips must be replaced.**


6. Prepare the nozzle of the sealant gun so that it has a flange that can run along the edge of the glass, and a V from which the sealant can flow. Once the primer is dry, apply the sealant around the entire circumference to fill the gap between the dam and the edge of the glass with a ridge of sealant **11mm (0.43 in)** high.

Keep the bead of sealant smooth and even, reshaping it where necessary with a spatula.


7. Lift the glass into place. Push it in lightly toward the vehicle to compress the sealant.

Caution


- **Open the windows to prevent the glass from being pushed out by air pressure if a door is closed.**




96U14X-099




86U14X-120



86U14X-121



86U14X-122



86U14X-123

Hardening time of repair seal

Temperature	Surface hardening time	Time required until car can be put in service
5°C (41°F)	Approx. 1.5 hrs	12 hrs
20°C (68°F)	Approx. 1 hr	4 hrs
35°C (95°F)	Approx. 10 min.	2 hrs

8. Use a scraper to smooth away any sealant that oozes out. Add more sealant to any points of poor contact.

9. Check for water leaks. If a leak is found, wipe the water off well and add **repair seal** (B001 77 739) where needed.


10. Align the alignment mark of the molding with that on the lap of the glass and push the molding into place along the top.

Caution

- Apply primer with a brush to the bonding area of the molding, and allow it to dry for approx. 30 minutes.
- Use a new window molding.

11. Insert the molding ends into the flanges of the lower molding. Then push it in along the sides.

12. After checking for water leakage, mount the pillar garnish.




86U14X-124

13. Attach the front header trim, pillar trim, sunvisors, and rear-view mirror.


REAR WINDOW GLASS

PREPARATION
SST

<p>49 0305 807A Tool set, window</p>		<p>For removal and installation of rear window glass</p>
--	---	--

06U0SX-104


STRUCTURAL VIEW



06U0SX-105


- | | | |
|---|--|--|
| <p>1. Rear package tray
2. Rear header trim
3. Rear pillar trim</p> | <p>4. Back window side molding
5. Back window lower molding
6. Back window upper molding</p> | <p>7. Rear window glass
8. Spacer
9. Seat belt bolts</p> |
|---|--|--|

MX-6




96U14X-071


- | | | |
|--------------------------------|------------------------------|------------------------------|
| 1. Seat belt upper anchor bolt | 5. Back window side molding | 8. Back window lower molding |
| 2. Rear side trim | 6. Rear package tray | 9. Rear window glass |
| 3. Rear header trim | 7. Back window upper molding | 10. Spacer |
| 4. Rear pillar trim | | |




96U14X-072




96U14X-073



96U14X-074



96U14X-075



96U14X-076

REMOVAL


1. Disconnect the negative battery cable.
2. Disconnect the defroster connectors.
3. Remove the seat belt upper anchor bolts.
4. Remove the screws and remove the rear header trim.
5. Remove the screws and remove the rear side trims (MX-6).

6. Remove the screws and remove the rear pillar trims.


7. Remove the nuts and remove the back window side moldings.

8. Remove the fasteners, and remove the rear package tray.


9. Remove the lower and upper window moldings.




86U14X-132




16U0SX-012



86U14X-134



63U14X-064



63U14X-065

10. Use an awl to make a hole in the sealant. Pass the end of a piece of the piano wire (**about 40 cm 15.7 in**) through the hole, and attach bars to both ends.
11. Apply protective tape along the edge of the body to the glass as shown.
12. Two people should hold the bars, one inside and one outside the vehicle, and then "saw" the sealant from around the glass.
13. Remove the glass from the body.

Caution

- Cut along the border between the glass and the sealant.
- If too much heat develops, the piano wire may break, so cool it occasionally or don't work on one place too long.
- If the glass is not to be reused, a tool like that shown in the figure may be used.

Insert the blade in the sealant, pull on the bars, and cut the sealant.

INSTALLATION

1. Use a knife to smoothly trim the sealant on the body. Leave a layer about **1 or 2mm (0.04 to 0.08 in)** thick.

Caution

- If some sealant flakes off, use new sealant to patch it.

2. Carefully clean and remove any grease from a **5 cm (1.97 in)** wide area around the circumference of the glass and the remaining bond on the body.
3. Bond a dam along the circumference of the glass **8mm (0.31 in)** from the edge.


Caution

- Securely bond the dam and let it dry.


4. Apply primer with a brush to the circumference of the glass and the body and allow them to naturally dry for 20 to 30 minutes.

Caution


- Be sure not to allow dirt, water, oil, or similar materials to come into contact with the coated surfaces, and do not touch them by hand.




63U14X-066




16U0SX-013



86U14X-135



63U14X-069



63U14X-070

5. Install the spacers at the positions shown in the figure.

Caution

- Spacers with flaws must be replaced.

6. When the primer has dried, apply an 11mm (0.43 in) thick bead of repair seal (B001 77 739) 11mm (0.43 in) from the edge of the window glass using a sealant gun.

Caution

- Cut the nozzle of the repair seal cartridge as illustrated in the figure.
- If necessary, smooth the repair seal to correct any irregularities.

7. Attach the rear window glass to the body.

Caution

- Keep the door glass open until the repair seal hardens to some degree to prevent pressure from being exerted on the rear glass if the door is closed quickly.

Hardening time of repair seal

Temperature	Surface hardening time	Time required until car can be put in service
5°C (41°F)	Approx. 1.5 hrs	12 hrs
20°C (68°F)	Approx. 1 hr	4 hrs
35°C (95°F)	Approx. 10 min.	2 hrs

8. Remove any excess or add repair seal where necessary.


9. Check for water leaks. If a leak is found, wipe the water off well and add repair seal (B001 77 739).

10. After checking for water leakage, install the moldings and trims.

11. Connect the defroster connectors.


QUARTER WINDOW GLASS

PREPARATION
SST

<p>49 0305 870A Tool set, window</p>		<p>For removal and installation of quarter window glass</p>
--	---	---

06U0SX-109

STRUCTURAL VIEW




06U0SX-110

- 1. Bolt
- 2. Rear side seat back

- 3. Rear header trim screw
- 4. Rear pillar trim


- 5. Nuts
- 6. Quarter window molding
- 7. Quarter window glass
- 8. Dam

MX-6




96U14X-080


- | | | |
|--------------------------------|---------------------|----------------------------|
| 1. Seat belt upper anchor bolt | 5. Screw | 9. Drip molding |
| 2. Screw | 6. Rear pillar trim | 10. Quarter window molding |
| 3. Screw | 7. Nut | 11. Quarter window glass |
| 4. Side trim | 8. Screw | 12. Dam |




96U14X-081




86U14X-151



86U14X-152



86U14X-153



86U14X-154

REMOVAL

1. Fold down the rear seat back, and remove the rear side seat back. (Touring sedan)
2. Remove the rear side trim and the package side shelf. (Touring sedan)
3. Remove the seat belt upper anchor bolt(s).
4. Remove the rear header and rear pillar trims.
5. Remove the mounting nuts and fastener, and remove the quarter window molding.
6. Make a small hole through the sealant.
7. Pass the piano wire through the hole.
8. Wind each end of the wire around a bar.
9. Pull the wire to and fro, and saw through the sealant around the edge of the glass. Then remove the glass.

Caution

- Use a long sawing action to spread the work over the whole length of wire to prevent it from breaking.
- Be careful that the wire does not rub on the vehicle paint.

INSTALLATION

1. Use the knife to smoothly cut the sealant on the body side, leaving a layer about **1 or 2mm (0.04 to 0.08 in)** thick.
2. Carefully clean around the edge of the quarter window glass (**up to approx. 5 cm (0.2 in) from the edge**), and the adhesion surface at the body side.


3. Attach a **dam (G043 50 762)** around the glass, **approx. 7mm (0.28 in)** from the edge.

4. Apply a thin coat of primer to the bonding area of the body and glass, and **allow 30 minutes** for it to dry.


Caution

- Keep the area free of dirt. Do not touch the surface. If primer gets on the hands, remove it immediately.


QUARTER WINDOW GLASS




86U14X-155



86U14X-156



86U14X-157



96U14X-082

5. After the primer dries, apply a bead of repair seal to a height of **10mm (0.4 in) min.** around the edge of the glass.

6. Attach the glass to the body.


7. Remove excess sealant. Add sealant where necessary.

8. Check for water leaks. If a leak is found, wipe the water off well and add **repair seal** (B001 77 739).


9. Install the remaining parts in the reverse order of removal.

HEADLIGHT CLEANER

TROUBLESHOOTING




06U0SX-111



Cont'd


Cont'd



06U0SX-112


REMOVAL / INSTALLATION

1. Remove in the sequence shown in the figure.
2. Install in the reverse order of removal.



06U0SX-113

- | | | |
|----------------------|---------------------------|----------------|
| 1. Bracket | 4. Washer motor | 7. Hose |
| 2. Coolant reservoir | Inspection..... page S-75 | 8. Joint |
| 3. Bracket | 5. Washer nozzles | 9. Washer tank |
| | 6. Clips | |



06U0SX-114

HEADLIGHT CLEANER SWITCH


Inspection

1. Check for continuity between the terminals using an ohmmeter.

Position \ Terminal	a	b	c	d
OFF	○	⊗		
ON	○	⊗	○	○

○—○: Indicates continuity

2. If continuity is not as specified, replace the switch.



06U0SX-115


WASHER MOTOR (HEADLIGHT CLEANER)

Inspection

1. Check for continuity of the motor with an ohmmeter.
2. Connect 12V to the "b" terminal and ground the "a" terminal. Verify that the motor operates.

SLIDING SUNROOF


STRUCTURAL VIEW





06U0SX-116

- | | | |
|--------------------------------|---------------------------------|---------------------------|
| 1. Sunshade (Moonroof) | 8. Lower panel | 14. Guide rails |
| 2. Sliding roof trim (Sunroof) | 9. Lower panel (Moonroof) | 15. Guide |
| 3. Slide panel | 10. Decoration cover (Moonroof) | 16. Packing |
| 4. Weatherstrip | 11. Motor assembly | 17. Tube assembly |
| 5. Deflector | Inspection..... page S-79 | 18. Frame assembly |
| 6. Set plate | 12. Guide brackets (rear) | 19. Sunroof relay |
| 7. Drip rail | 13. Guide bracket (front) | Inspection..... page S-79 |

TROUBLESHOOTING







96U15X-192

INSPECTION



Switch

Use an ohmmeter to check the continuity of the terminals of the switch.

If continuity is not as indicated, replace the switch.

Position		Terminal	2a	2b	6a	6b	6c	6d	6e	6f
OFF			○	—	○					
Slide SW	OPEN							○	—	○
	CLOSE						○	—	○	
Tilt SW	UP				○	—	○			
	DOWN								○	—


○—○: Indicates continuity



96U15X-115

Relay


1. Check for continuity between terminals a—b and c—f.
2. Apply 12V to terminal a.
3. Ground terminal b.
4. Check for continuity between terminals c—e.
5. If not correct, replace the relay.



96U15X-116

Motor

1. Disconnect the motor connector terminal-wire (Y/R).
2. Apply 12V to Y/R and ground terminal-wire (Y).
3. Check that motor turns from tilt-up, to closed, to open position.
4. Reverse the connections and check that the motor turns from open, to closed, to tilt-up position.




96U15X-117

Limit Switch

1. Use emergency handle furnished in the glove box to set the sunroof in the positions shown.

SLIDING SUNROOF



96U15X-118

2. Use an ohmmeter to check the continuity of the terminals of the switch.

SW	LS1		LS2		
Terminal/color	e	d	a	b	c
Roof condition	L	L/G	Y/G	L/W	L/Y
Open			○—○	○—○	
Close			○—○	○—○	○—○
Tilt-up	○—○	○—○	○—○	○—○	○—○


○—○: Indicates continuity

REMOVAL


Note

- Steps 1—10 are removal procedures for moonroof only.
- Steps 11—15 are removal procedures for sunroof only.


96U14X-089




96U14X-090



96U14X-091



76U14X-045




76U14X-046

1. Slide the sunshade all the way to the rear.
2. Fully close the sliding panel.


3. Remove the left and right decoration covers and lower panel cover.

4. Remove the installation nuts for the sliding panel and lower panel.
5. Remove the sliding panel by pushing it upward from inside the vehicle.


6. Fully close the sunshade.




76U14X-047




76U14X-048



76U14X-049



96U14X-092



96U14X-093

7. Turn the handle and move the sunshade **5—10mm (0.19—0.39 in)** to the rear.

8. Use a flat-tip screwdriver to lift the sunshade stopper at the rear of the cable holder, then release the stopper and move the sunshade toward the front.

9. Turn the handle to fully open the lower panel. (Leave the sunshade fully closed.)

10. Open the sunshade halfway and remove the set plate cap. Pull out the sunshade from the notch of the set plate.

11. Open the slide panel **about 10 cm (3.94 in)**.

12. Remove the sliding roof trim.

(1) Pull down the front to detach faster.


(2) Pull the trim forward.

(3) Remove the trim lifting it up, out of the vehicle.

13. Close the slide panel fully, and remove the installation nuts for the slide panel and lower panel.

14. Remove the slide panel by pushing it upward.

15. Open the lower panel halfway.




96U14X-094

16. Use a flat-tip screwdriver to pry up the connector at the rear of the deflector link, being careful not to scratch it, and remove the deflector link.
17. Remove the screws and remove the deflector.

Note

- Because force is applied to the deflector by the spring in the direction of opening, hold so that the deflector doesn't contact the roof panel, then pull out the deflector link.




96U14X-095

18. Completely close the lower panel.


Note

- Because the lower panel will move forward out of place, turn the motor using the handle while pushing to the rear to close fully.




96U14X-096

19. After removing the screw and the drip rail joint link, push the drip rail backward and inward.
20. After removing the installation screw of the guide bracket assembly (rear), remove the right side of the guide (front).
21. Remove the lower panel.




96U14X-097

22. Remove the rearview mirror, overhead console, and seaming welt.




16U0SX-014

23. Remove the screws, remove the motor and disconnect the harness connector.



96U14X-099



96U14X-100

24. Push the rear guide bracket backward and downward about **10 cm (3.94 in)**.
25. Remove the screw and the set plate.


26. Move the rear guide bracket all the way forward, and pull out while lifting from the rear.
27. Move the drip rail forward, then pull out from the notch of the guide rail.

INSTALLATION

Note

- Steps 16, 17, 22 are installation procedures for moonroof only.
- Steps 23, 24 are installation procedures for sunroof only.

96U14X-101




96U14X-102

1. Insert the drip rail.

Note

- Paying attention to the direction of the rail, push in from the open part to the position where it is not visible.




76U14X-058


2. Insert the drive cable into the tube.

Note


- Apply a liberal coat of grease to the drive cable and the sliding part of the guide bracket assembly (rear), then push the cable all the way forward.




96U14X-103




76U14X-060



16U0SX-015



76U14X-062



76U14X-063

3. After moving the guide bracket assembly slightly toward the rear, tighten the screws, taking care regarding the direction the set plate faces.

4. Align the projection of the tilting cam and the slit in the set plate.

5. Check that the limit switches (LS1 and LS2) of the motor are as shown in the figure at the OFF position.

Note

- Verify the position of the cam.
- Use the handle to position it correctly.

6. Install the motor assembly.


Note

- There are 2 types of screws, long and short. Be sure to use the correct ones.

7. Connect the wiring of the motor assembly and the motor switch.


8. Install the lower panel and tighten the screws.

9. Install the guide front and tighten the screws.



76U14X-064

10. Pull out the drip rail from the rear, and secure the link by the screw.




76U14X-065

11. Using the handle turn the motor to fully open the lower panel.


Note

- Because the roof panel and lower panel might interfere with each other when the lower panel is opened, check as shown in the figure, that the guide roller is completely fitted into the guide rail.
- Turn the motor while pushing the cable.




96U14X-104

12. Secure the deflector by tightening the screws, and then install the deflector link.
13. Turn the motor using the handle, and visually check the sliding, tilt-down and tilt-up operations.




76U14X-067

14. Fully close the lower panel.
15. Install the slide panel to the lower panel, and tighten securely.



76U14X-068

16. Insert the sunshade from the notch in the set plate, and push it all the way back.
17. Insert the set plate cap.




96U14X-105

18. Adjust the height of the slide panel.

(Cross-section A-A)


Adjust so that the height difference between the slide panel and roof panel is **1.5mm (0.06 in) max.**



16U0SX-016

(Cross-section B-B adjustment)


- (1) Loosen installation screws (1) and (2).
If the adjustment is only about **2mm (0.08 in)** don't loosen screw (1).
- (2) Turn the screws to adjust.
Turning to the right raises, to the left lowers.
- (3) Tighten installation screws (1) and (2).



96U14X-106


(Cross-section C-C adjustment)

- (1) Loosen the adjusting screw.
- (2) Adjust by moving the slide panel from the inside or outside.
- (3) Tighten the adjusting screw.



06U0SX-131

19. Uncrimp the pawl washer and loosen the locknut as shown in the figure, then adjust the torque.



16U0SX-017


20. Install the torque wrench to the locknut.

Tightening torque:

2.9—3.9 N·m (30—40 cm·kg, 26—35 in·lb)

Caution

- After adjustment, be sure to lock the nut with the pawl washer.




96U14X-109

21. Fit in the trim.

Push the inner trim from above, all the way in between the frame and lower panel.

Caution


- Be careful not to scratch the surface of the trim on the edge of the guide rail or rail cover.



96U14X-110

22. Open the slide panel about **10 cm (3.94 in)** and install the trim.


23. Install the surrounding front parts.



96U14X-111

24. After installation is completed, check the operation.

- (1) Is the battery voltage correct?
- (2) Is there any foreign material on the sliding parts?
- (3) When the slide panel is opened, does the roof panel interfere with the rear part? If so, open the slide panel fully and move the set plate forward.




96U14X-112

Caution

- If the stopper is moved too far forward, there might be a malfunction or leaking. Do not leave a gap of more than **6.4mm (0.25 in)** between the slide panel and roof panel.

INSTRUMENT PANEL

STRUCTURAL VIEW




86U14X-174


- 1. Rear console
- 2. Upper plate
- 3. Front console
- 4. Glove compartment
- 5. Side cover
- 6. Side cover
- 7. Box

- 8. Ashtray
- 9. Center panel
- 10. Heater control assembly
- 11. Steering wheel ornament
- 12. Steering wheel
- 13. Column cover
- 14. Switch panel


- 15. Cap
- 16. Meter hood
- 17. Duct
- 18. Duct and under cover
- 19. Under cover
- 20. Duct
- 21. Meter assembly
- 22. Instrument panel

INSTALLATION VIEW







86U14X-175




86U14X-176



86U14X-178




86U14X-179



86U14X-299


REMOVAL

1. Remove the screws and remove the shift lever knob (ATX).
2. Remove the shift lever knob (MTX).
3. Remove the rear console mounting screws.
4. Pull the console rearward and remove it.
5. Remove the front console mounting screws.
6. Remove the steering wheel ornament.




86U14X-180

7. Remove the steering wheel mounting nut.




86U14X-181

8. Remove the screws and the steering wheel cap.




86U14X-182

9. Remove the steering wheel with a steering wheel puller.




86U14X-183

10. Remove the screws and remove the column covers (upper and lower).




86U14X-184

11. Remove the screws and remove the under cover.
Loosen the nut and remove the hood release knob.




86U14X-185

12. Remove the screws and pull out the meter hood.
13. Disconnect the connectors and remove the meter hood.




96U14X-087

14. Remove the screws and pull the meter assembly outward.
15. Disconnect the speedometer cable at the speedometer.
16. Disconnect the meter connectors.
17. Remove the meter assembly.




86U14X-187

18. Remove the screws and pull the panel outward.
19. Disconnect the connectors and remove the switch panel.



86U14X-188

20. Remove the screws and remove the glove box.
21. Disconnect the glove box light connector.




86U14X-189

22. Remove the center panel.
23. Remove the screws and slide out the heater control assembly.
24. Disconnect the control wires at the DEF, MAX—COLD and REC positions (lever type control).


Note

- **Disconnect the connectors at the rear of the control (Logicon type).**




86U14X-190

25. Remove the center cap.
26. Remove the instrument panel mounting bolt.



86U14X-191

27. Remove the instrument panel side mounting bolts.




86U14X-192

28. Remove the instrument panel center bracket mounting bolts.




86U14X-193

29. Remove the steering shaft mounting bolts.




86U14X-194


30. Disconnect the dash harness connectors.
31. Remove the instrument panel.




86U14X-195



69G14X-224



69G14X-225



69G14X-226

INSTALLATION

Install in the reverse order of removal, noting the following.

1. Tightening torque:

Bolt	Torque	N·m (m·kg, ft·lb)
①		4.22—6.18 (0.43—0.63, 3.10—4.54)
② ③		8.8—14 (0.9—1.4, 6.5—10)
④ ⑤		8.8—14 (0.9—1.4, 6.5—10)
⑥ ⑦		8.8—14 (0.9—1.4, 6.5—10)
Steering wheel		39—49 (4.0—5.0, 29—36)

2. Air-mix door control wire

- Set TEMP lever at MAX—COLD position.
- Connect the control wire and clamp it with the shutter lever on the heater unit all the way to the right side.

Caution

- Move the temperature control lever to check that the wire is secured. Also, check that it moves the full stroke between HOT and COLD.

3. Mode control wire

- Set MODE control lever to DEF position.
- Connect the control wire and clamp it with the shutter lever on the heater unit at its closest point.

Caution

- Move the mode lever to check that the wire is secured. Also, check that it moves the full stroke between DEF and VENT.

4. REC-FRESH air selector wire


- Set the selector lever to REC position.
- Connect the control wire and clamp it with the shutter lever on the blower unit at its closest point.

Caution

- Move the recirculate-fresh air switch lever to check that the wire is secured. Also, check that it moves the full stroke between REC and FRESH.

SEAT

STRUCTURAL VIEW




- 1. Seat side cover
- 2. Lifter lever
- 3. Reclining knuckle
- 4. Lumbar support lever

- 5. Seat adjuster
- 6. Front seat cushion
- 7. Headrest
- 8. Headrest pole

- 9. Front seat back
- 10. Rear seat cushion
- 11. Rear seat back
- 12. Seat side

N-m (m-kg, ft-lb)

06UOSX-119



06U0SX-120


FRONT SEAT**Inspection**

1. Check that the seat adjuster lever and recliner knuckle lever move smoothly.
2. Check the seat mounting bolts for looseness. If necessary, tighten the bolts to the specified torque.

Tightening torque:**Seat mounting bolt:**

38—51 N·m (3.9—5.2 m·kg, 28—38 ft·lb)


3. Apply grease to the moving parts.
4. Check the seat adjuster lever for wear.



96U14X-113


REAR SEAT**Removal (as equipped on MX-6 and 4-door sedan only)**

1. Push the locks as shown in the figure to release the cushion, then lift the seat cushion out of the vehicle.



69G14X-236

2. Remove the end bolts, and lift the seat back off the hooks.



86U14X-184

3. Remove the fastener.
4. Remove the seat back.

Installation


Install in the reverse order of removal.

Tightening torque:**Seat back:**

16—23 N·m (1.6—2.3 m·kg, 12—17 ft·lb)

PASSIVE SHOULDER BELT


STRUCTURAL VIEW




N-m (m-kg, ft-lb)


06U0SX-121

- | | |
|--|------------|
| 1. Passive shoulder belt control unit | |
| 2. Passive shoulder belt retractor | |
| Inspection | page S-102 |
| 3. Inner buckle | |
| Inspection | page S-102 |
| 4. Outer lap belt | |
| 5. Passive shoulder belt motor and rail | |
| Inspection | page S-101 |
| 6. Limit switch (Rear) | |
| Inspection | page S-101 |
| 7. Seat belt warning switch | |
| Inspection | page S-102 |
| 8. Limit switch (Front) | |
| Inspection | page S-101 |
| 9. Door catch switch (in the door lock assembly) | |
| Inspection | page S-101 |





06UOSX-123



06U0SX-124


INSPECTION

Passive Shoulder Belt Motor

1. Remove the front and center pillar trim and disconnect the passive shoulder belt motor connector.
2. Connect 12V to terminal a and ground terminal b. Verify that the motor rotates in the forward direction (release).
3. Reverse the above connection, and check that the motor rotates in the rearward direction (lock).

Caution

- Do not operate the motor for an extended period of time.





06U0SX-125

Limit Switch

1. Remove the front and center pillar trim, disconnect the passive shoulder belt motor connector (MX-6) or rear limit switch connector (626) and the front limit switch connector.
2. Position the shoulder belt as shown using the emergency handle.
3. Check for continuity between the limit switch terminals using an ohmmeter.

Limit switch	Front		Rear			
			MX-6		626	
	a	b	c	d	a	c
Shoulder belt position						
Released (Front)	○	○				
Moving						
Locked (Rear)			○	○	○	○

○—○: Indicates continuity




06U0SX-126

Door Catch Switch (in front door lock assembly)

1. Remove the door trim and screen.
(Refer to page S-10; steps 1-3.)
2. Disconnect the door catch switch connector.
3. Check for continuity between the terminals using an ohmmeter.

Door position	Terminal	
	a	b
Open	○	○
Close		

○—○: Indicates continuity




96U15X-149

Buckle Switch (Lap Belt)

1. Disconnect the buckle switch connector.
2. Check continuity of the switch with an ohmmeter.

Lap belt	Terminal	a	b
Unfastened		○	○
Fastened			

○—○: Indicates continuity




06U0SX-127

Shoulder Belt Warning Switch

1. Remove the center pillar trim, and disconnect the passive shoulder belt motor connector.
2. Check continuity between the terminals with an ohmmeter passive shoulder belt is at the rear locked position.

Shoulder belt position	Terminal	MX-6		626	
		d	f	b	c
Locked	Belt fastened	○	○	○	○
	Belt unfastened				

○—○: Indicates continuity




06U0SX-128

Emergency Lock Retractor (ELR)

Caution

- Do not disassemble the buckle and retractor assembly.

1. Verify that the belt can be pulled out smoothly and that it moves smoothly when worn.
2. Verify that the retractor locks when quickly pulling the belt.



96U14X-038

3. Remove the retractor.
4. Hold the retractor as it is installed.
5. Slowly incline the retractor while pulling out the belt.
6. Verify that the retractor locks at **approx. 30 degrees** inclination.

Webbing

Inspect the webbing for scars, tears, and wear and for deformation of the fittings.

PASSIVE SHOULDER BELT

S


Terminal Voltage of Passive Shoulder Belt Control Unit

Terminal	Wire color	Connection	Test condition		Voltage	Action	
A	(R)	Passive shoulder belt motor (RH)	Shoulder belt (RH) moving from rear to front		Approx. 12V	Check passive shoulder belt motor (RH) (Refer to page S-101)	
			Other conditions		0V		
B	(G)	Passive shoulder belt motor (RH)	Shoulder belt (RH) moving from front to rear		Approx. 12V		
			Other conditions		0V		
C	(L/Y)	Limit switch (RR)	IGN ON	Shoulder belt (RH) locked (Rear)	0V	Check limit switch (RR) (Refer to page S-101)	
				Other conditions			Approx. 2V
D	(Y/G)	Door catch switch (RH)	Door (RH) open		0V	Check door catch switch (RH) (Refer to page S-101)	
			Door (RH) closed	IGN ON or door (LH) open			Approx. 2V
				IGN OFF and door (LH) closed			Approx. 12V
E	(L/B)	Deflection sensor (RH) (MX-6 only)	—		—	—	
F	(G/L)	Limit switch (FR)	Shoulder belt (RH) released (Front)		0V	Check limit switch (FR) (Refer to page S-101)	
			IGN ON	BELT warning lamp ON			Approx. 2V
				BELT warning lamp OFF			Approx. 12V
G	(B/Y)	Ignition switch (IG1)	Ignition switch ON		Approx. 12V	Repair wire (B/Y)	
			Ignition switch OFF		0V		
H	(B/L)	TWS	Buzzer sounds		Approx. 0.7V	Check CPU (Refer to Section T)	
			Buzzer does not sound		Approx. 12V		
I	(G/R)	Speed sensor	IGN ON	Vehicle speed above 8 km/h (16 mph)	0-5V	Check speed sensor (Refer to Section T)	
				Vehicle stopped			Approx. 5V
J	(W/R)	BELT 30A fuse	Constant		Approx. 12V	Repair wire	
L	(BR/B)	BELT warning lamp	IGN ON	BELT warning lamp ON		Approx. 0.1V	Check meter (Refer to Section T)
				BELT warning lamp OFF		Approx. 12V	
N	(B)	Ground	Constant		0V	Repair wire (B)	
O	(L/R)	Warning switch (LH)	Locked (Rear)	Shoulder belt (LH) fastened		0V	Check warning switch (LH) (Refer to page S-102)
				Shoulder belt (LH) unfastened		Approx. 2V	
P	(LG/B)	Warning switch (RH)	Locked (Rear)	Shoulder belt (RH) fastened		0V	Check warning switch (RH) (Refer to page S-102)
				Shoulder belt (RH) unfastened		Approx. 2V	
Q	(L)	Deflection sensor (LH) (MX-6 only)	—		—	—	
R	(Y/L)	Limit switch (FL)	Shoulder belt (LH) released (Front)		0V	Check limit switch (FL) (Refer to page S-101)	
			IGN ON	BELT warning lamp ON			Approx. 2V
				BELT warning lamp OFF			Approx. 12V
S	(L/W)	Limit switch (RL)	IGN ON	Shoulder belt (LH) locked (Rear)	0V	Check limit switch (RL) (Refer to page S-101)	
				Other conditions			Approx. 2V
T	(G/R)	Door catch switch (LH)	Door (LH) open		0V	Check door catch switch (RH) (Refer to page S-101)	
			Door (LH) closed	IGN ON or door (RH) open			Approx. 2V
				IGN OFF and door (RH) closed			Approx. 12V
U	(Y)	Passive shoulder belt motor (LH)	Shoulder belt (LH) moving from rear to front		Approx. 12V	Check passive shoulder belt motor (LH) (Refer to page S-101)	
			Other conditions		0V		
V	(L)	Passive shoulder belt motor (LH)	Shoulder belt (LH) moving from front to rear		Approx. 12V		
			Other conditions		0V		


Terminal location

U	S	Q	O	M		I	G	E	C	A
Y	L/W	(L) *	L/R	*		G/R	B/Y	(L/B) *	L/Y	R
L	G/R	Y/L	LG/B	B	BR/B	W/R	B/L	G/L	Y/G	G
V	T	R	P	N	L	J	H	F	D	B


()... MX-6

PASSIVE SHOULDER BELT

06U0SX-129



86U14X-191



06U0SX-130

REMOVAL

1. Remove the front pillar trim.

2. Remove the rear pillar trim and side trim.

3. Remove the mounting bolts.

4. Remove the passive shoulder belt motor and rail.


INSTALLATION

Install in the reverse order of removal.

SEAT BELTS

STRUCTURAL VIEW

STANDARD SHOULDER BELT



N-m (m-kg, ft-lb)


96U14X-035

1. Buckles
2. Front seat belts


3. Rear seat belts
4. Retractors

5. Retractors

SEAT BELTS



96U14X-037



96U14X-038

INSPECTION

Caution

- Do not disassemble the buckle and retractor assembly.

Emergency Lock Retractor (ELR)

1. Verify that the belt can be pulled out smoothly and that it moves smoothly when worn.
2. Verify that the retractor locks when quickly pulling the belt.

3. Remove the retractor.
4. Hold the retractor as it is installed.
5. Slowly incline the retractor while pulling out the belt.
6. Verify that the retractor locks at **approx. 30 degrees** inclination.

Webbing


Inspect the webbing for scars, tears, and wear and for deformation of the fittings.

HEADLINER

STRUCTURAL VIEW

MX-6

SLIDING SUNROOF



- 1. Rearview mirror and overhead console
- 2. Sunvisor
- 3. Center adapter



- 4. Assist handle
- 5. Interior light
- 6. Front header trim
- 7. Front pillar trim

- 8. Rear pillar trim
- 9. Rear header trim
- 10. Insulator
- 11. Headliner

86U14X-159

SEDAN

SLIDING SUNROOF




- 1. Rearview mirror and overhead console
- 2. Sunvisor
- 3. Center adapter


- 4. Assist handle
- 5. Interior light
- 6. Front header trim
- 7. Front pillar trim

- 8. Rear pillar trim
- 9. Rear header trim
- 10. Insulator
- 11. Headliner


86U14X-160




86U14X-161




69G14X-241



86U14X-162




86U14X-163



86U14X-164


REMOVAL

1. Remove the overhead console cover.
2. Remove the rearview mirror.
3. Remove the overhead console mounting screws.
4. Disconnect the connectors and remove the overhead console.
5. Remove the sunvisors.
6. Remove the center adapters.
7. Remove the interior light lens with a protected small screwdriver.
8. Remove the interior light mounting screws and disconnect the connector.
9. Remove the interior light.
10. Remove the caps and screws at the ends of the front header trim.




86U14X-165

11. Remove the caps and screws at the ends of the rear header trim.




96U14X-083

12. Remove the rear side trims.




96U14X-084

13. Remove the seat belt upper anchor bolts.




96U14X-085

14. Remove the rear pillar trims with a protected standard screwdriver.




96U14X-086

15. Remove the front pillar trims with a protected standard screwdriver.




86U14X-170

16. Remove the assist handles.




86U14X-171

17. Remove the sliding sunroof seaming welt.



86U14X-172

18. Remove the fasteners and remove the headliner.



86U14X-173

INSTALLATION

Install in the reverse order of removal, noting the following.


Note

- Align the trim and clip positions, then install the clips by striking them lightly.

- A: Frame mounting nut (M10)
- B: Front fender panel mounting nut (M6)
- C: Front member mounting bolt (M12)
- D: Front mounting block
- E: Steering bracket mounting nut (M12)
- F: Front fender panel mounting nut (M6)
- G: Frame mounting bolt (M12)

- H: Front frame, lower standard hole (8 ϕ)
- I : Front frame [c], lower standard hole (12 ϕ)
- J : Crossmember mounting nut (M10)
- K: Rear mounting block
- L : Crossmember mounting nut (M10)
- M: Rear frame, lower standard hole(10 ϕ)
- N: Rear bumper mounting hole (14 ϕ)
(outside,lower)

16USX-018



- A: Frame mounting nut (M10)
 B: Front member mounting bolt (M12)
 C: Frame mounting bolt (M12)
 D: Front frame, lower standard hole (8 ϕ)

- E: Front frame [c], lower standard hole (12 ϕ)
 F: Crossmember mounting nut (M10)
 G: Rear frame, lower standard hole (10 ϕ)